

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [HOMCOM](#) /

› [HOMCOM Tall Pantry Cabinet \(Model CA83A-428V80WT0231\) User Manual](#)

HOMCOM CA83A-428V80WT0231

HOMCOM Tall Pantry Cabinet (Model CA83A-428V80WT0231) User Manual

Your comprehensive guide to assembly, operation, and care.

1. INTRODUCTION

Thank you for choosing the HOMCOM Tall Pantry Cabinet, Model CA83A-428V80WT0231. This versatile storage solution is designed to enhance your kitchen, dining room, or living room with its farmhouse style and practical features. This manual provides detailed instructions to ensure safe assembly, proper use, and effective maintenance of your new cabinet.





Image 1.1: The HOMCOM Tall Pantry Cabinet, a white freestanding unit with two upper and two lower doors, and two central drawers, offering ample storage.

2. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions carefully before assembly and use.
- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all connections are securely tightened before use. Periodically check and re-tighten as necessary.
- **Anti-Tipping Kit:** This cabinet includes an anti-tipping kit. It is crucial to install this kit to prevent the cabinet from tipping over, especially in households with children or pets. Secure the cabinet to a wall stud using the provided hardware.
- Do not overload shelves or drawers. Refer to the 'Specifications' section for weight capacities.
- Do not climb on or allow children to play on the cabinet.



Image 2.1: Illustration of the anti-tipping hardware installation, emphasizing the importance of securing the cabinet to the wall for stability and safety.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Cabinet Panels (various sizes)
- Adjustable Shelves
- Drawer Components
- Hardware Pack (screws, dowels, cam locks, hinges, drawer glides, handles, anti-tipping kit)
- Assembly Instructions Manual

4. SETUP AND ASSEMBLY

Assembly typically requires two adults. Tools required: Phillips head screwdriver, hammer (optional), and a drill for wall mounting the anti-tipping kit.

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface. Identify each part using the provided parts list.
2. **Assemble Base:** Connect the side panels to the bottom panel using the provided hardware. Ensure the grooves for the back panel are correctly aligned.
3. **Install Drawer Glides:** Attach the drawer glides to the cabinet side panels and the drawer boxes as per the instructions.
4. **Assemble Drawers:** Construct the two drawers and insert them into the installed glides.
5. **Attach Back Panel:** Slide the back panel into the grooves and secure it.
6. **Install Shelves:** Insert shelf pins into the desired holes for the adjustable shelves. Place the shelves onto the pins.
7. **Attach Doors:** Secure the hinges to the doors and then to the cabinet frame. Adjust hinges for proper door alignment.
8. **Install Handles:** Attach the alloy handles to the doors and drawers.
9. **Install Anti-Tipping Kit:** Position the cabinet in its final location. Secure the anti-tipping strap to the top rear of the cabinet and then to a wall stud using appropriate wall anchors and screws. This step is critical for safety.



Image 4.1: Detailed dimensions of the cabinet, illustrating its overall size and internal storage capacities.

Farmhouse Charm

Arched Doors

Beadboard Design

Alloy Handles

Image 4.2: Focus on the durable alloy hinges and smooth-gliding drawer mechanisms, highlighting key construction details.

Assembly Video Reference

Your browser does not support the video tag.

Video 4.1: An overview of a similar HOMCOM kitchen pantry cabinet (Model 83A-425V80WT), demonstrating its features and storage capabilities. While not the exact model, it provides a visual reference for general functionality.

5. OPERATING INSTRUCTIONS

Adjustable Shelves

The cabinet features two adjustable shelves with three height settings, allowing you to customize the storage space to fit items of various sizes.

1. **To Adjust:** Empty the shelf of all contents.
2. Remove the shelf pins from their current holes.
3. Insert the shelf pins into the desired new height holes. Ensure all four pins are at the same level.

4. Carefully place the shelf onto the new pins.



Image 5.1: Detail of the adjustable shelf mechanism, showing the multiple pinholes for customizing shelf height.

Drawers

The two smooth-gliding drawers provide convenient storage for smaller items. To open, gently pull the handle. To close, push the drawer firmly until it is fully seated.

6. MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood and melamine surfaces.
- **Hardware:** Periodically check all screws, hinges, and drawer glides to ensure they are tight. Re-tighten as needed to maintain stability and smooth operation.
- **Environment:** Avoid placing the cabinet in direct sunlight or near heat sources, which can cause fading or warping. Maintain a stable humidity level to prevent material expansion or contraction.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet is wobbly	Loose connections; uneven floor	Check and tighten all screws. Ensure the cabinet is on a level surface; use shims if necessary. Verify anti-tipping kit is securely installed.
Drawers stick or don't close smoothly	Misaligned glides; overloaded drawer; debris in glides	Check drawer glide alignment and re-adjust if needed. Reduce drawer contents. Clean glides of any dust or debris.
Doors are misaligned or don't close properly	Loose hinges; uneven cabinet placement	Adjust the door hinges (refer to hinge manufacturer's instructions if specific adjustments are needed). Ensure the cabinet is level.

8. SPECIFICATIONS

- **Model Number:** CA83A-428V80WT0231
- **Brand:** HOMCOM
- **Colour:** White
- **Material:** Engineered Wood, Melamine
- **Overall Dimensions:** 23.6" W x 11.8" D x 67.1" H (60 x 30 x 170.5 cm)
- **Item Weight:** 28.6 kg (63 lbs)
- **Maximum Weight Capacity:** 22 lbs/10 kg (per shelf), 17.6 lbs/8 kg (per drawer), 123 lbs/56 kg (total)
- **Special Features:** Adjustable Shelf, Anti-Tipping, Scratch Resistant
- **Mounting Type:** Floor Mount (with wall anchor for anti-tipping)
- **Style:** Farmhouse
- **Room Type:** Dining Room, Kitchen, Living Room
- **Door Style:** Arched

9. WARRANTY AND SUPPORT

This HOMCOM product is manufactured by Aosom Canada. For any questions, missing parts, or concerns regarding your Tall Pantry Cabinet, please contact Aosom Canada customer support.

- **Returns/Refunds:** Eligible for return or refund within 30 days of receipt. Please refer to the retailer's return policy for detailed terms and conditions.
- **Manufacturer Contact:** Aosom Canada, Markham, Ontario, CA. Tel: 1-416-792-6088.