

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Jocoevol](#) /

› [Jocoevol Fluted Kitchen Pantry Storage Cabinet with LED Light and Charging Station \(Model: kitchen pantry cabinet\)](#)

## Jocoevol kitchen pantry cabinet

# Jocoevol Fluted Kitchen Pantry Storage Cabinet User Manual

Model: kitchen pantry cabinet

## INTRODUCTION

Thank you for choosing the Jocoevol Fluted Kitchen Pantry Storage Cabinet. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new cabinet. Please read this manual thoroughly before assembly and retain it for future reference.

## SAFETY INFORMATION

- Always assemble the cabinet on a clean, soft surface to prevent scratches.
- Ensure all parts and hardware are present before beginning assembly. Contact customer service if any parts are missing.
- Do not overtighten screws during assembly to avoid damaging the wood.
- Use the included anti-tipping kit to secure the cabinet to a wall, preventing accidental tipping and potential injury.
- Keep small parts away from children during assembly.
- Do not exceed the weight capacity of shelves or drawers.
- Ensure the power cord for the charging station and LED light is not pinched or damaged during assembly or use.

## PACKAGE CONTENTS

Before assembly, verify that all components and hardware listed in the assembly diagram are present. Refer to the diagram below for a visual representation of the parts.

# Product Information



## Color

Wood color & black

## Dimension

L x W x H  
15.7" x 47.2" x 70.9"

## Weight Capacity



Image: Detailed diagram of all cabinet components, dimensions, and included screws and tools.

## ASSEMBLY INSTRUCTIONS

Follow these step-by-step instructions for assembling your Jocoevol Fluted Kitchen Pantry Storage Cabinet. It is recommended to have two people for assembly.

### Assembly Video Guide

Your browser does not support the video tag.

Video: A comprehensive installation guide for the Jocoevol Fluted Kitchen Pantry Storage Cabinet, demonstrating each step of the assembly process.

### Step-by-Step Written Guide

- 1. Prepare the Top Section:** Begin by assembling the upper cabinet frame. Attach the side panels to the top and bottom shelves using the designated hardware. Ensure all connections are secure.
- 2. Install LED Light Strip:** Carefully adhere the LED light strip to the underside of the middle shelf in the upper section. Route the power cable through the designated opening.
- 3. Attach Hooks:** Secure the six hooks to the back panel of the upper section, below the LED light strip,

using the provided screws.

4. **Assemble Base Section:** Construct the lower cabinet frame by attaching the side panels to the base and middle shelves.
5. **Integrate Charging Station:** Install the charging station into the pre-cut opening on the countertop of the lower section. Secure it with screws and connect its power cord.
6. **Assemble Drawers:** Follow the specific instructions for assembling the two drawers, ensuring the drawer slides are correctly installed on both the drawer and the cabinet frame.
7. **Attach Doors:** Mount the hinges to the cabinet doors and then attach the doors to the corresponding cabinet sections. Adjust hinges as needed for proper alignment.
8. **Install Back Panels:** Secure the back panels to both the upper and lower cabinet sections using the small nails or screws provided.
9. **Connect Sections:** Carefully lift the assembled upper section and place it onto the lower section, aligning the pre-drilled holes. Secure the two sections together with the appropriate connectors.
10. **Install Anti-Tipping Kit:** For safety, attach the anti-tipping kit to the top rear of the cabinet and secure it to a wall stud using appropriate wall anchors (not always included, depending on wall type).

## OPERATING INSTRUCTIONS

---

### LED Lighting

The integrated LED light strip offers multiple colors and flashing modes. To operate:

- Connect the LED light's USB cable to a compatible USB power source (e.g., the cabinet's charging station USB port or a separate USB adapter).
- Use the inline controller on the cable to cycle through different colors, adjust brightness, and select flashing modes.

### Charging Station

The cabinet features a built-in charging hub with 2 AC outlets and 3 USB ports.

- Plug the cabinet's 1.5-meter power cord into a standard wall outlet.
- Use the AC outlets for small appliances like coffee makers or toasters.
- Use the USB ports to charge mobile devices or other USB-powered gadgets.
- Ensure devices are compatible with the charging station's power output.

**1**

## LED Light Strip

Tailor the lighting effect to match your current mood, existing decor, or personal preference.

**2**

## Large Storage with Drawer

A thoughtfully designed for organizing tableware and kitchen essentials

**3**

## Hassle-Free Charging

With 2AC outlet, 3USB Port, Easily charge small appliances on the countertop

Image: Detailed view of the LED light strip, spacious drawer, charging station, and extended power cord.

## MAINTENANCE

### Cleaning

- Wipe surfaces with a soft, damp cloth.
- Avoid using harsh chemicals or abrasive cleaners, as these can damage the finish.
- For spills, wipe immediately to prevent staining. The countertop is scratch-resistant and waterproof for easy cleaning.

### General Care

- Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- Avoid placing excessively hot items directly on the surface without protection.
- Keep the cabinet away from direct sunlight and excessive moisture to prevent warping or discoloration.

## TROUBLESHOOTING

---

**Issue: Cabinet doors do not close properly or are uneven.**

**Solution:** Adjust the hinges on the doors. Most hinges allow for minor adjustments in three directions (up/down, left/right, in/out) using a screwdriver. Refer to the hinge manufacturer's instructions if specific adjustments are unclear.

**Issue: LED light is not working.**

**Solution:** Ensure the USB cable is securely connected to both the light strip and a working power source. Check if the power source (e.g., wall adapter or cabinet's USB port) is active. Test the light with a different USB power source if possible.

**Issue: Charging station outlets/USB ports are not providing power.**

**Solution:** Verify that the cabinet's main power cord is firmly plugged into a functional wall outlet. Check if the wall outlet itself is receiving power by testing with another device. Ensure the charging station is properly seated and connected within its opening.

**Issue: Drawers are stiff or do not slide smoothly.**

**Solution:** Check that the drawer slides are correctly installed and aligned. Ensure no debris is obstructing the slides. Lightly lubricate the slides with a silicone-based lubricant if necessary.

## SPECIFICATIONS

---

<b>Brand</b>	Jocoevol
<b>Model Name</b>	kitchen pantry cabinet
<b>Color</b>	Natural
<b>Product Dimensions</b>	47"W x 15.7"D x 71"H
<b>Item Weight</b>	60 Pounds
<b>Material</b>	Engineered Wood
<b>Number of Shelves</b>	5 (Adjustable)
<b>Special Features</b>	Adjustable Shelf, LED Light, Charging Station (2 AC outlets, 3 USB ports), Anti-tipping kit
<b>Assembly Required</b>	Yes

## WARRANTY AND SUPPORT

---



For warranty information or assistance with your Jocoevol Fluted Kitchen Pantry Storage Cabinet, please contact Jocoevol customer service. Our dedicated team is available to help with any questions or concerns you may have regarding assembly, missing parts, or product functionality.


Please retain your proof of purchase for warranty claims.

**Customer Service Contact:** Refer to your purchase documentation or the Jocoevol brand store on Amazon for the most current contact information.

You can visit the official Jocoevol Store at: [Jocoevol Store](#)

## Related Documents - kitchen pantry cabinet

<p><b>Kitchen Pantry Cabinet</b></p> <p><small>Assembly Instructions - Please keep for future reference</small></p>  <p><b>Important - Please read these instructions fully before starting assembly</b></p>	<p><b><a href="#">Kitchen Pantry Cabinet Assembly Instructions</a></b></p> <p>Comprehensive assembly guide for the Kitchen Pantry Cabinet, featuring safety precautions, a detailed parts list, and step-by-step instructions with textual descriptions of diagrams. Includes guidance on using camlocks and important warnings.</p>
<p><b>Jocoevol</b> <b>ASSEMBLY INSTRUCTIONS</b></p>  <p><b>12x12FT Greenhouse</b></p> <p><small>Retain this manual for future use. And read carefully.</small></p>	<p><b><a href="#">Jocoevol 12x12FT Greenhouse Assembly Instructions</a></b></p> <p>Comprehensive assembly guide for the Jocoevol 12x12FT Greenhouse, featuring detailed step-by-step instructions, parts inventory, and hardware lists to facilitate construction.</p>
<p><b>Display Cabinet</b></p>  <p><small>Actual size (2' W x 6' H x 1' D) PRINTED</small></p>	<p><b><a href="#">Display Cabinet Assembly Instructions and Warranty Information</a></b></p> <p>Comprehensive guide for assembling a FUFU&amp;GAGA display cabinet, including detailed steps, parts list, and warranty information. Learn how to safely assemble and maintain your furniture.</p>
<p><b>Ebern Designs 47.3" Storage Cabinet</b></p>  <p><small>Actual size (23.6" W x 11.8" H x 7.3" D) PRINTED</small></p> <p><b>Important</b> Thank you for your purchase. Please open it carefully. If you encounter any problems, please contact us. Service team - a middle manager to enjoy high quality service.</p>	<p><b><a href="#">Ebern Designs 47.3" Storage Cabinet Assembly Instructions</a></b></p> <p>Detailed assembly instructions, parts list, and troubleshooting guide for the Ebern Designs 47.3-inch tall storage cabinet. Learn how to assemble your new cabinet with clear, step-by-step instructions and visual descriptions.</p>
<p><small>Your total satisfaction is our #1 priority. Customer Service and Warranty Information</small></p> <p><small>* Should you have a concern or need more information concerning the warranty, please contact the place of purchase.</small></p> <p><small>** We are committed to the highest customer satisfaction and believe in a commitment to the customer. Details as mentioned in this warranty refer to any manufacturer's defect in materials or workmanship. The manufacturer's defect is limited to the replacement of materials and parts necessary for the use of the product.</small></p> <p><small>*** Damage caused by any part that is not supplied. The warranty applies only conditions of normal use and does not cover damage caused by misuse, abuse, negligence, commercial use, accident, natural disaster, or any other causes.</small></p> <p><small>** Our reserves the right to request proof of purchase to document a warranty claim. We are not responsible for any damage or loss to your property or personal property in the course of assembly or use of the product.</small></p>	<p><b><a href="#">Hokku Designs 2-Door Pantry Cabinet Assembly Guide</a></b></p> <p>Detailed assembly instructions for the Hokku Designs 2-Door Pantry Cabinet, including raised panel and glass door options. Covers pre-assembly, parts list, step-by-step installation, and hinge adjustment.</p>



### [Winston Porter Fluted Arched Pantry Cabinet Installation Guide](#)

Detailed installation and assembly instructions for the Winston Porter Fluted Arched Pantry Cabinet, including parts list, hardware guide, and step-by-step assembly procedures.