

[Manuals.plus](#) /

› [E-YEEGER](#) /

› E-YEEGER V100Pro Dash Cam User Manual

E-YEEGER V100Pro

E-YEEGER V100Pro Dash Cam User Manual

Model: V100Pro

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your E-YEEGER V100Pro Dash Cam. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience. The V100Pro is designed to record your journeys in high definition, offering features such as 2.5K 1440P resolution, WiFi connectivity for app control, G-Sensor for incident detection, loop recording, and 24-hour parking monitoring.

WHAT'S IN THE BOX

Verify that all items are present in the package:

- Mini Dash Cam (V100Pro)
- Car Charger (11.5ft cable)
- Quick Guide
- User Manual
- Electrostatic Sticker
- Easy Pry Tool
- 32GB Micro SD Card (pre-installed or included)




Image: Package contents of the E-YEEGER V100Pro Dash Cam.

PRODUCT OVERVIEW

The E-YEEGER V100Pro Dash Cam is a compact and feature-rich device designed for reliable vehicle recording. Key features include:

- **2.5K 1440P Recording:** Captures video at 2560x1440 resolution at 30 frames per second, providing clear and detailed footage.
- **160° Wide-Angle Lens:** Offers a broad field of view to minimize blind spots and cover multiple lanes.
- **Enhanced Night Vision:** F1.8 large aperture and advanced sensor technology improve light intake for clear recordings in low-light conditions.
- **Built-in WiFi & App Control:** Connects to a dedicated smartphone app (iOS/Android) for live viewing, video download, settings adjustment, and sharing.
- **G-Sensor:** Automatically detects sudden impacts or collisions and locks the current video file to prevent overwriting.
- **Loop Recording:** Continuously records by overwriting the oldest unlocked files when the memory card is full, ensuring uninterrupted recording.
- **24H Parking Monitor:** Provides continuous surveillance when the vehicle is parked (requires optional hardwire kit).
- **Support for up to 256GB Micro SD Card:** Allows for extended recording times.
- **Compact Design:** Small form factor ensures it does not obstruct the driver's view.
- **1.47" Display:** For direct viewing of recordings and menu navigation.




Image: The V100Pro Dash Cam highlighting its 2.5K recording capability.



Image: Illustration of the 160-degree wide-angle field of view.




Image: Night vision capability of the dash cam.

SETUP

1. Micro SD Card Installation

1. Ensure the dash cam is powered off.
2. Insert a high-quality U3 or higher-grade Micro SD card (up to 256GB) into the card slot until it clicks into place. A 32GB card is typically included.
3. Upon first use or if issues occur, format the SD card via the dash cam's settings menu or the mobile app.




Image: Inserting the Micro SD card into the dash cam.

2. Mounting the Dash Cam

1. Clean the chosen area on your windshield thoroughly.
2. Apply the electrostatic sticker to the cleaned area. This allows for easier removal without leaving residue.
3. Attach the dash cam to the electrostatic sticker using its adhesive pad. Ensure the lens has a clear view of the road and does not obstruct your driving vision.
4. Use the included pry tool to neatly tuck the power cable along the windshield edge and dashboard to the car's power outlet.



Image: Dash cam installation on the windshield.

3. Power Connection

- Connect the included car charger to the dash cam's Type-C port and plug the other end into your vehicle's cigarette lighter socket.
- The dash cam will power on automatically when the vehicle starts and begin recording. It will power off when the vehicle is turned off.

4. App Connection (WiFi)

1. Download the dedicated "VeeCar" app from the App Store (iOS) or Google Play Store (Android).
2. Turn on the dash cam.

3. On your smartphone, go to WiFi settings and connect to the dash cam's WiFi network (SSID and password can be found in the dash cam's settings or quick guide).
4. Open the VeeCar app. You should now be able to view live footage, access recordings, and adjust settings.




Image: Connecting the dash cam to the mobile app via WiFi.

OPERATING INSTRUCTIONS

Basic Recording

- Once powered on, the dash cam automatically begins continuous loop recording.
- Recordings are saved in segments (e.g., 1, 3, or 5 minutes) to the Micro SD card.

Loop Recording

- When the Micro SD card reaches its capacity, the oldest unlocked video files are automatically overwritten by new recordings.
- This ensures continuous recording without manual intervention.



Image: Visual representation of loop recording functionality.

G-Sensor (Emergency Recording)

- The built-in G-Sensor detects sudden acceleration, braking, or collisions.

- Upon detection, the current video segment is automatically locked and saved to a protected folder, preventing it from being overwritten by loop recording.
- These emergency files are crucial for evidence in case of an incident.



Image: G-Sensor automatically locks video footage during impacts.

24-Hour Parking Monitor

- To enable 24-hour parking monitoring, an additional hardwire kit is required (ASIN: B0D9NJHBYW, not included).
- When properly installed, the dash cam will automatically switch to parking mode when your car is turned off.
- In parking mode, the camera can record continuously at a low frame rate (time-lapse) or activate upon detecting motion or impact, providing surveillance against theft or vandalism.




Image: 24-hour parking monitoring feature (requires hardwire kit).

Voice Prompts

- The dash cam provides smart voice alerts for various statuses, such as "Start Recording," "Stop Recording," "This video was locked," and "WiFi Connected."
- These prompts help you stay informed about the device's operation without needing to look at the screen.



Image: Smart voice prompt feature for operational status.

MAINTENANCE

SD Card Management

- Regularly format the Micro SD card (at least once a month) to ensure optimal performance and prevent data corruption. This can be done through the dash cam's menu or the mobile app.
- Use only high-quality, reputable brand U3 or higher-grade Micro SD cards. Inferior cards may lead to recording errors or device malfunction.

Cleaning

- Wipe the dash cam lens with a soft, lint-free cloth to ensure clear video quality. Avoid abrasive materials or harsh chemicals.
- Keep the device free from dust and debris.

Temperature Considerations

- The dash cam is designed to operate within a temperature range of 14°F to 150°F (-10°C to 65°C).
- Avoid prolonged exposure to extreme temperatures outside this range to prevent damage to the device.



Image: Internal design features for durability and temperature resistance.

TROUBLESHOOTING

Problem	Possible Cause / Solution
Dash cam does not power on.	<ul style="list-style-type: none">• Check if the car charger is properly connected to both the dash cam and the car's power outlet.• Ensure the vehicle's power outlet is functioning.• Verify the car charger cable is not damaged.
Recording stops or footage is corrupted.	<ul style="list-style-type: none">• The Micro SD card may be full. Format the card regularly.• The Micro SD card may be of low quality or incompatible. Use a U3 or higher-grade card from a reputable brand.• The card may be faulty. Replace the Micro SD card.
WiFi connection issues with the app.	<ul style="list-style-type: none">• Ensure the dash cam's WiFi is enabled.• Verify you are connected to the dash cam's specific WiFi network on your phone.• Restart both the dash cam and your smartphone.• Ensure the VeeCar app is updated to the latest version.
Parking monitor not working.	<ul style="list-style-type: none">• The 24-hour parking monitor requires an additional hardwire kit (ASIN: B0D9NJHBYW). Ensure it is correctly installed.• Check parking mode settings in the dash cam menu or app.
Video quality is poor.	<ul style="list-style-type: none">• Clean the dash cam lens.• Ensure the protective film has been removed from the lens.• Check video resolution settings in the app or dash cam menu.

SPECIFICATIONS

Feature	Detail
Model Name	V100Pro
Video Capture Resolution	1440p (2.5K)
Frame Rate	30 fps
Field of View	160 degrees
Screen Size	1.47 inches
Connectivity Technology	Wi-Fi
Mounting Type	Dashboard Mount
Compatible Devices	Car, Truck, SUV, Smartphone

Feature	Detail
Included Memory Card Size	32 GB
Flash Memory Supported Size Maximum	256 GB
Product Dimensions	2.54 x 8.13 x 3.81 cm
Item Weight	54.43 g
Manufacturer	E-YEEGER
Color	Jet Black

WARRANTY AND SUPPORT

Warranty Information

The E-YEEGER V100Pro Dash Cam comes with a **1-Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact E-YEEGER customer support. Refer to the contact information provided on the product packaging or the official E-YEEGER website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question