

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [FUNYET](#) /

› [FUNYET NY-12 15.6-inch Laptop Computer User Manual](#)

## FUNYET NY-12

# FUNYET NY-12 15.6-inch Laptop Computer User Manual

Model: NY-12 | Brand: FUNYET

## 1. PRODUCT OVERVIEW

The FUNYET NY-12 is a 15.6-inch laptop designed for efficient performance and portability. It features an Intel Core i5-7Y54 processor, 16GB RAM, and a 512GB SSD, providing smooth operation for daily tasks. The laptop includes a 1920x1080 Full HD display, a backlit keyboard with a numeric keypad, and various connectivity options.




Image 1.1: Key features of the FUNYET NY-12 laptop, highlighting its processor, display size, wireless capabilities, cooling system, battery, and storage.

# 180° Opening and Closing

Lightweight and easy to carry

 **Weight**  
3.61 lbs

 **Size**  
14.1\*8.9\*0.8 Inch



Image 1.2: The laptop's design, showcasing its 180-degree hinge, lightweight build (3.61 lbs), and compact dimensions (14.1 x 8.9 x 0.8 inches).

## 2. WHAT'S IN THE Box

- Laptop
- Adapter
- User Manual

## 3. SETUP GUIDE

### 3.1 Initial Charging

Before first use, connect the provided power adapter to the laptop's DC 19V/3.42A port and a power outlet. Allow the laptop to charge for at least 3 hours to ensure a full battery. The charging indicator light will typically change color or turn off when fully charged.

### 3.2 Powering On

Press and hold the power button located on the keyboard until the screen illuminates. The laptop will boot into the Windows 11 Pro operating system.

### 3.3 Initial Windows Setup

Follow the on-screen prompts to complete the Windows 11 Pro setup. This includes selecting your region, language, connecting to a Wi-Fi network, and creating a user account. Ensure you have your Wi-Fi password ready.

### 3.4 Connecting Peripherals

Utilize the available ports to connect external devices:

- **USB 3.0 Ports:** For connecting USB devices such as mice, keyboards, or external storage.
- **Mini HDMI:** For connecting to external displays or projectors.
- **TF Card Slot:** For expanding storage with a TF (MicroSD) card.
- **3.5mm Headphone Jack:** For connecting headphones or external speakers.



Image 3.1: Overview of the laptop's various ports and their functions for connecting external devices.

## 4. OPERATING INSTRUCTIONS

### 4.1 Keyboard and Touchpad

The laptop features a full-size backlit keyboard and a responsive touchpad. The backlit keyboard's brightness can be adjusted using the function keys (e.g., Fn + F5) for comfortable typing in various lighting conditions. The integrated numeric keypad simplifies data entry.



Image 4.1: The laptop's backlit keyboard and numeric keypad, illustrating how to activate the backlight.

### 4.2 Wireless Connectivity

The laptop supports WiFi 5 (802.11a/b/g/n/ac) and Bluetooth 4.2. To connect to a Wi-Fi network, click the network icon in the taskbar, select your desired network, and enter the password. For Bluetooth devices, enable Bluetooth in Windows settings and pair with your device.

### 4.3 Display Settings

The 15.6-inch Full HD (1920x1080) IPS display provides clear visuals. You can adjust display settings such as resolution, brightness, and color temperature through Windows Display Settings. For external displays, connect via Mini HDMI and configure display modes (duplicate, extend, second screen only) in Windows settings.



Image 4.2: The laptop's 15.6-inch Full HD display, highlighting its visual quality and features.

#### 4.4 Battery Management

The laptop is equipped with a 5000mAh battery. To optimize battery life, adjust power settings in Windows, reduce screen brightness, and close unnecessary applications. For prolonged storage, ensure the battery is charged to approximately 50-70%.

# Long Battery Life Without Worry

48 hours low standby power consumption, 5 hours long life span



Image 4.3: Details of the laptop's 5000mAh battery and its expected operational duration.

## 5. MAINTENANCE

### 5.1 Cleaning

Regularly clean the laptop's screen, keyboard, and chassis. Use a soft, lint-free cloth for the screen, and a slightly damp cloth for other surfaces. Avoid harsh chemicals or abrasive materials. Ensure the laptop is powered off and unplugged before cleaning.

### 5.2 Software Updates

Keep your Windows operating system and drivers updated to ensure optimal performance and security. Access Windows Update through the Settings menu.

### 5.3 Storage and Handling

Store the laptop in a cool, dry environment away from direct sunlight and extreme temperatures. Avoid placing heavy objects on the laptop or exposing it to liquids. When transporting, use a protective sleeve or bag.

## 6. TROUBLESHOOTING

---

### 6.1 Power Issues

- **Laptop not turning on:** Ensure the power adapter is securely connected and the battery has sufficient charge. Try a different power outlet.
- **Battery not charging:** Verify the adapter and cable are not damaged. Ensure the charging port is clean.

### 6.2 Display Problems

- **Blank screen:** Check if the laptop is powered on. Connect to an external monitor via Mini HDMI to determine if the internal display is faulty.
- **Flickering screen:** Update graphics drivers. Adjust display refresh rate in Windows settings.

### 6.3 Connectivity Issues

- **Wi-Fi not connecting:** Restart the laptop and your router. Ensure Wi-Fi is enabled in Windows settings.
- **Bluetooth device not pairing:** Ensure Bluetooth is enabled on both devices and they are in pairing mode. Check device compatibility.

### 6.4 General Performance

- **Slow performance:** Close unnecessary applications. Check for malware. Ensure sufficient free space on the SSD.
- **Overheating:** Ensure ventilation vents are clear. Use the laptop on a hard, flat surface.

## 7. SPECIFICATIONS

---

Feature	Detail
Standing Screen Display Size	15.6 Inches
Screen Resolution	1920 x 1080 pixels (Full HD)
Processor	Intel Core i5-7Y54 (1.6 GHz, up to 3.2GHz Turbo)
RAM	16 GB DDR3
Hard Drive	512 GB SSD
Graphics Coprocessor	Intel HD Graphics 615
Wireless Type	802.11a/b/g/n/ac (WiFi 5), Bluetooth 4.2
USB 3.0 Ports	2
Operating System	Windows 11 Pro
Item Weight	3.61 lbs (1.64 kg)
Product Dimensions	14.1 x 9.1 x 0.8 inches
Battery	1 x 12V battery (included), 5000mAh capacity
Special Features	Backlit Keyboard, HD Audio, Lightweight, Numeric Keypad

# Powerful Intel Core i5-7Y54

**3.2 GHz**

Turbo frequency

**2 Core**

4 Threads

**Intel HD 615**

900MHz

**14 nm**

Process Size




Image 7.1: Detailed specifications of the Intel Core i5-7Y54 processor integrated into the laptop.

## 8. WARRANTY AND SUPPORT

FUNYET provides a **2-year official warranty** for this product. Additionally, 24/7 customer service is available to assist with any issues or questions regarding your laptop. FUNYET is committed to producing cost-effective electronic products and offers 180 days free exchange and 2 year free repair for all products.

If you encounter any problems, please contact FUNYET support for prompt and efficient assistance. They aim to reply within 24 hours.

### 8.1 Official Product Video

Your browser does not support the video tag.

Video 8.1: An official product video from FUNYET Direct showcasing the features and design of the FUNYET Windows 11 Pro Laptop.

