

Manuals.plus /

› Pastigio /

› Pastigio 10.1 Inch Frameo Digital Picture Frame User Manual

Pastigio 10.1 Inch Digital Picture Frame

Pastigio 10.1 Inch Frameo Digital Picture Frame User Manual

Model: 10.1 Inch Digital Picture Frame

1. INTRODUCTION

Welcome to the instruction manual for your Pastigio 10.1 Inch Frameo Digital Picture Frame. This guide provides essential information for setting up, operating, and maintaining your device to ensure a seamless experience in sharing and displaying your cherished memories.

What's in the Box

- Pastigio 10.1 Inch Frameo Digital Picture Frame
- Power adapter
- User Manual
- Desktop Stand
- Wall Mounting Screws

2. PRODUCT OVERVIEW

The Pastigio 10.1 Inch Frameo Digital Picture Frame features a vibrant 1280*800 IPS touch screen for clear photo and video display. It supports Wi-Fi connectivity for instant sharing and offers multiple options for media transfer.

Physical Components

Familiarize yourself with the frame's ports and buttons for optimal use.

Pastigio

Frameo 10.1 Inch Digital Picture Frame

A Smarter Way to Relive Memories



Image: Pastigio 10.1 Inch Frameo Digital Picture Frame highlighting its 10.1" large display, Frameo reliable app, 32GB built-in storage, and 800P HD touchscreen.

- **Touch Screen:** Interact directly with the frame's interface.
- **Power Button:** Located on the back, used to turn the frame on/off.
- **DC IN Port:** Connect the power adapter here.
- **USB-C Port:** For connecting to a computer or USB-C drive for media transfer.
- **Micro SD Card Slot:** Insert a Micro SD card for additional storage or direct media playback.
- **Wall Mounting Holes:** For securing the frame to a wall in either portrait or landscape orientation.

3. SETUP

3.1 Powering On

1. Connect the power adapter to the DC IN port on the back of the frame.
2. Plug the adapter into a power outlet. The frame will automatically power on.
3. Follow the on-screen prompts for initial setup, including language selection, time zone, and date/time.

3.2 Connecting to Wi-Fi

Wi-Fi connectivity is essential for using the Frameo app and its instant sharing features.

1. During initial setup, select your Wi-Fi network from the list.
2. Enter your Wi-Fi password using the on-screen keyboard.
3. Once connected, the frame will display a confirmation message.

3.3 Initial Configuration

Customize your frame's basic settings:

- **Frame Name:** Assign a unique name to your frame.
- **Frame Location:** Specify the location (e.g., Living Room, Kitchen).
- **Language:** Select your preferred language.
- **Weather Location:** Set your local weather display.

Your browser does not support the video tag.

Video: A seller demonstrates the simple setup process and ease of use for the digital picture frame, including initial power-on and basic settings configuration.

4. OPERATING THE FRAME

4.1 Using the Frameo App for Instant Sharing

The Frameo app allows you to send photos and 15-second videos directly to your frame from anywhere with a Wi-Fi connection.



Image: The Frameo app on a smartphone is shown connected to a digital frame, illustrating the ease of sharing photos and videos instantly.

1. Download the official Frameo app from your smartphone's app store.
2. Create an account and connect to your digital picture frame using the unique code displayed on the frame.
3. Select photos or videos from your phone's gallery within the app.
4. Add captions and select the important part of the photo/video for optimal display.
5. Send the media to your frame. You can also invite friends and family to send photos to your frame.

Your browser does not support the video tag.

Video: A detailed guide on how to send photos and videos to the digital picture frame using the Frameo app, including selecting media, adding captions, and choosing recipients.

4.2 Non-Wi-Fi Transmission

For offline media transfer, the frame supports Micro SD cards and USB-C drives (FAT32 format only).




Image: This diagram illustrates diverse methods for transferring photos and videos, including Micro SD card, USB-C drive (Windows only), and exporting photos.

- **Micro SD Card:** Insert a Micro SD card (up to 32GB) directly into the frame's SD card slot. The frame can use it as external storage or import media.
- **USB-C Drive:** Connect a USB-C drive (FAT32 format) to the USB-C port for media transfer.
- **Computer Connection:** Use a USB-C cable to connect the frame to a personal computer for direct file transfer.

4.3 Managing Photos and Videos

The touch screen interface allows for easy management of your media.



Image: The digital frame screen shows an 'Album' option, allowing users to categorize and organize their memories.

- **Create Albums:** Organize your photos and videos into custom albums.
- **React:** Send emojis to photos to express your feelings.
- **Hide/Delete:** Manage your media by hiding or deleting unwanted items.
- **Adjust Photo:** Crop, zoom, and rotate photos to fit the screen perfectly.

4.4 Display Settings

Customize the visual experience of your digital frame.



Image: A finger interacts with the digital frame's 1280*800 HD touchscreen, highlighting its vivid IPS True Color display and smooth touch functionality.

- **Brightness:** Adjust the screen brightness to suit your environment.
- **Eco Sleep Mode:** Set a schedule for the frame to dim or turn off to save power.
- **Auto-Rotate:** The frame automatically adjusts media orientation (portrait/landscape) based on its physical position.

4.5 Slideshow Options

Enhance your slideshow with various features.

Discover More Fun Features




Image: The digital frame's screen shows a menu of 'Fun Features' including options for captions, frame fitting, clock, weather, reactions, sleep mode, brightness, slideshow timing, and photo visibility.

- **Slideshow Timer:** Adjust the duration each photo is displayed.
- **Show Caption:** Display captions added to your photos.
- **Show Clock/Weather:** Integrate time and weather information into your slideshow.

5. MAINTENANCE

5.1 Cleaning Instructions

To keep your digital picture frame in optimal condition:

- Gently wipe the screen with a soft, lint-free cloth. Avoid abrasive materials or harsh chemicals.
- For stubborn smudges, lightly dampen the cloth with water or a screen-safe cleaner.
- Keep the frame away from excessive dust and moisture.

5.2 Software Updates

The Frameo app and your digital frame regularly receive software updates to improve performance and add new features. Ensure your frame is connected to Wi-Fi to receive these updates automatically.

6. TROUBLESHOOTING

If you encounter any issues with your Pastigio Digital Picture Frame, refer to the following common solutions:

- **Frame not turning on:** Ensure the power adapter is securely connected to both the frame and a working power outlet.
- **Cannot connect to Wi-Fi:** Verify your Wi-Fi password and ensure the frame is within range of your router. Try restarting your router and the frame.
- **Photos not appearing on frame:** Check your internet connection on both your phone and the frame. Ensure the Frameo app is updated and you are sending photos to the correct frame.
- **Screen unresponsive:** Try restarting the frame by unplugging and re-plugging the power adapter.

Your browser does not support the video tag.

Video: A seller provides honest feedback and demonstrates the features of the digital frame, which can be helpful for troubleshooting common user queries.

7. SPECIFICATIONS

Feature	Detail
Screen Size	10.1 Inches
Resolution	1280p
Product Dimensions	10.2 x 7.05 x 0.99 inches
Item Weight	2.2 pounds
Internal Memory	32GB (supports up to 32GB expansion via Micro SD/USB-C)
Connectivity	Wi-Fi, USB-C, Micro SD Card
Compatible Devices	Personal Computer, Smartphones (via Frameo app)
Manufacturer	Pastigio

8. WARRANTY AND SUPPORT

Your Pastigio Digital Picture Frame comes with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included in your product packaging or contact customer support.

Customer Support

If you require further assistance or have questions not covered in this manual, please contact Pastigio customer support through the official website or the contact information provided in your product documentation.

9. SAFETY INFORMATION

Please read and follow all safety instructions to prevent injury or damage to your device:

- Do not expose the frame to water or moisture.
- Avoid placing the frame in direct sunlight or near heat sources.
- Use only the provided power adapter.
- Keep the frame out of reach of small children.
- Do not attempt to disassemble or repair the frame yourself. Contact qualified service personnel.