



[Manuals.plus](#) /

› [LAUDLIFE](#) /

› LAUDLIFE Cordless Electric Knife Instruction Manual (Model B0FYBPB16B5)

LAUDLIFE B0FYBPB16B5

LAUDLIFE Cordless Electric Knife Instruction Manual

Model: B0FYBPB16B5

INTRODUCTION

Thank you for choosing the LAUDLIFE Cordless Electric Knife. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new electric knife. Please read all instructions carefully before first use and retain this manual for future reference.



Image: The LAUDLIFE Cordless Electric Knife, including the main unit, two interchangeable blade sets, and a carving fork, presented in its packaging.

IMPORTANT SAFETY INSTRUCTIONS

- Always keep blades out of reach of children.
- Exercise extreme caution when handling sharp blades.
- Ensure the safety lock is engaged when not in use or when changing blades.
- Do not immerse the motor unit in water or other liquids.
- Only use the provided charging cable and batteries.
- Avoid contact with moving parts.
- Do not attempt to sharpen the serrated blades.
- Unplug the charger when not in use and before cleaning.

SETUP AND ASSEMBLY

1. Charging the Battery

The LAUDLIFE Cordless Electric Knife is powered by a rechargeable Lithium-Ion battery. Ensure the battery is fully charged before first use for optimal performance.

1. Connect the magnetic charging cable to the charging port on the knife handle.
2. Plug the USB end of the charging cable into a compatible AC adapter (not included).

3. The battery indicator on the handle will show charging status. Charge until fully indicated.

Cordless Electric Knife

Freedom to Cut Anywhere



Image: Close-up of the magnetic charging port on the base of the electric knife handle, showing the charging cable connecting.

2. Attaching the Blades

Your electric knife comes with two sets of 420 stainless steel blades: an 8-inch blade for tougher meats and a 6-inch blade for delicate items like bread.

1. Ensure the knife is powered off and the safety lock is engaged.

2. Align the two blade sections together, ensuring they interlock correctly at the base.
3. Insert the assembled blade set into the blade slot on the knife handle until it clicks securely into place. The blade lock tab will snap into the groove on the blade.




Image: A visual guide demonstrating the correct method for assembling the two blade pieces and inserting them into the electric knife handle until they lock.

OPERATING INSTRUCTIONS

1. Powering On and Safety

The LAUDLIFE electric knife features a dual safety trigger to prevent accidental activation.

1. To activate the knife, simultaneously pull the main trigger and push the child safety lock button.
2. Release both buttons to stop the blades.



Image: A hand demonstrating how to engage the dual safety trigger by pressing the child lock and main trigger simultaneously.

2. Speed Settings

The knife offers two power speeds for versatile cutting:

- **Low Speed (First Gear):** Ideal for delicate items such as soft bread, cakes, and pastries. Use the 6-inch blade for best results.

- **High Speed (Second Gear):** Suitable for tougher items like turkey, pork, beef, sashimi, and other meats. The 8-inch blade is recommended for these tasks.

Two Speed Settings

Meet Your More Versatile Cutting

1

Low Speed
Precise Cutting of Bread and Soft Foods

2

High Speed
Tougher Meats, Poultry, Fish, and Hardy Vegetables

Image: A diagram illustrating the two speed settings on the electric knife, with visual examples of foods best suited for low speed (bread, sandwiches) and high speed (ham, turkey, steak).

3. Cutting Techniques

- For even slices, allow the knife to do the work. Guide it gently through the food without applying excessive pressure.

- Use the included carving fork to stabilize larger items like roasts or poultry while slicing.
- The cordless design allows for use anywhere, from the kitchen to outdoor barbecues.

Fast and Evenly **Slicing**

With Reciprocating Serrated Edge Blades



Image: A close-up of the electric knife effortlessly slicing through a loaf of bread, highlighting the reciprocating action of the serrated blades.

Effortless Slicing, Guest-Approved

Perfect for Carves
Ham, Turkey, Roasts and Other Meats



Image: A person using the electric knife and carving fork to carve a roasted turkey, demonstrating its use for large meats.

CARE AND MAINTENANCE

1. Cleaning the Blades

1. Ensure the knife is powered off and unplugged (if applicable).
2. To remove the blades, rotate the safety lock and gently pull the blade set out from the handle.

3. Separate the two blade sections for thorough cleaning.
4. The detachable blades are dishwasher safe. Alternatively, wash by hand with warm, soapy water and dry immediately.
5. Store blades with their protective covers in the provided case.



Image: Hands demonstrating the removal of the electric knife blades by rotating the safety lock mechanism on the handle.

2. Cleaning the Handle

- Wipe the handle with a damp cloth. Do not immerse the handle in water.
- Ensure the handle is completely dry before storing or recharging.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Knife does not turn on.	Battery is not charged or not properly inserted. Safety lock not disengaged.	Ensure battery is fully charged and correctly inserted. Simultaneously pull the trigger and push the safety lock.
Blades are not cutting effectively.	Incorrect blade type for food. Blades are dull or dirty.	Use the appropriate 8-inch (meat) or 6-inch (bread) blade. Clean blades thoroughly. Blades are not designed to be sharpened by the user.
Knife stops during use.	Battery low or depleted. Overheating.	Recharge the battery. Allow the knife to cool down before resuming use.

SPECIFICATIONS

Feature	Detail
Brand	LAUDLIFE
Model	B0FYPB16B5
Blade Material	420 Stainless Steel
Included Blades	One 8-inch blade, One 6-inch blade
Power Source	Rechargeable Lithium Ion Battery (included)
Special Features	Ergonomic Handle, Dual Safety Lock, Two Speed Settings, Magnetic Charging
Item Weight	2.89 ounces
Handle Material	Acrylonitrile Butadiene Styrene (ABS)

WARRANTY AND SUPPORT

The LAUDLIFE Cordless Electric Knife comes with a **1-year warranty service**. If you receive a defective electric carving knife or are not satisfied with your product, please contact LAUDLIFE customer support for assistance. We are committed to providing the best solution.

For further assistance or inquiries, please visit the [LAUDLIFE Store on Amazon](#).

OFFICIAL PRODUCT VIDEOS

Laudlife Electric Knife Cordless

Your browser does not support the video tag.

Video Description: An overview of the LAUDLIFE Cordless Electric Knife, demonstrating its features and cordless operation. This video is provided by the seller, Xiaogian Trading.

Perfect for cutting through meats or bread with ease.

Your browser does not support the video tag.

Video Description: A short demonstration of the electric knife's effectiveness in slicing various foods, including meats and bread. This video is provided by the seller, The Bargain Sisters.