

RIOWOIS DS6441G2 Pro

RIOWOIS DS6441G2 Pro 3.1ch Sound Bar System User Manual

Model: DS6441G2 Pro

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your RIOWOIS Sound Bar System. Keep this manual for future reference.

- Do not expose this appliance to dripping or splashing liquids.
- Do not place objects filled with liquids, such as vases, on the apparatus.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

2. PACKAGE CONTENTS

Carefully unpack your RIOWOIS Sound Bar System and ensure all items listed below are present and in good condition:

- 17-inch Sound Bar
- 5.25-inch Wired Subwoofer
- Remote Control
- Power Adapter
- AUX Cable
- Optical Cable
- Quick Start Guide & User Manual
- Wall Mount Kits (screws and anchors)





Image: RIOWOIS Sound Bar System package contents, including the sound bar, wired subwoofer, remote, cables, and wall mount kit.

3. PRODUCT OVERVIEW

The RIOWOIS DS6441G2 Pro is a 3.1-channel sound bar system designed to deliver immersive surround sound with powerful deep bass. It features upgraded bass drivers, silk dome horn tweeters, and a dedicated wired subwoofer for a rich audio experience across movies, music, and gaming.



Image: The RIOWOIS Sound Bar and its wired subwoofer positioned in a living room environment, enhancing the television audio.



Here's what customers are saying



It's a very sleek looking soundbar and was easy to setup! The audio quality is much higher than the tv itself and has great clarity, it works very well. 🍌❤️



This is a fantastic soundbar! I appreciate that it has both a volume button and a button so that you can adjust the bass in the subwoofer up and down.



Currently using for my living room TV, definitely adds life to movies and video games! It's so compact and out the way as well. This soundbar system was totally worth buying. 🤩



Image: An exploded view of the sound bar's internal components, highlighting the dual upgraded woofers and silk dome horn tweeters, along with a curved bass reflex port for optimized airflow.




Image: The 5.25-inch wired subwoofer, emphasizing its 40W deep bass capability and 10-level adjustable bass control for precise audio customization.

4. SETUP GUIDE

4.1 Connecting the Subwoofer

Connect the wired subwoofer to the sound bar using the dedicated subwoofer cable. Ensure the connection is secure to guarantee optimal bass performance and prevent audio lag.

4.2 Power Connection

Connect the power adapter to the sound bar's DC IN port and then plug it into a wall outlet.

4.3 Connecting to TV/Devices

The sound bar offers multiple connectivity options to suit various devices:

- **Optical Input:** Use the included optical cable to connect the sound bar to your TV's optical output. This provides high-quality digital audio.
- **3.5mm AUX Input:** Use the included AUX cable for analog audio connection to devices with a 3.5mm audio jack.
- **TV ARC:** Connect an HDMI cable (not included) from the sound bar's ARC IN port to your TV's HDMI ARC port for digital audio and control.
- **Bluetooth 5.3:** Wirelessly connect your smartphone, tablet, or other Bluetooth-enabled devices for audio streaming.



Image: Rear view of the sound bar displaying the various input ports: DC IN, OPT IN (Optical), AUX IN, ARC IN (HDMI ARC), and SUB OUT for the wired subwoofer.



Image: A four-step visual guide demonstrating how to configure TV audio settings for optical output, including selecting 'Optical' as sound output and disabling Dolby/DTS on streaming apps to prevent silent or noisy output.

4.4 Wall Mounting

The sound bar can be wall-mounted using the included wall mount kits. Refer to the Quick Start Guide for detailed instructions on secure installation.



Image: The RIOWOIS Sound Bar neatly installed on a wall beneath a television, showcasing a clean and space-saving setup.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Functions

Use the provided remote control to manage your sound bar system. The remote allows for:

- Power On/Off
- Input Source Selection (Optical, AUX, TV ARC, Bluetooth)
- Volume Up/Down

- Mute/Unmute
- Bass Level Adjustment (10 levels)
- Sound Mode Selection (Movie, News, Music)



Image: The sound bar's remote control, indicating its compatibility with Fire TV/Stick, Google Chromecast, and Apple TV remotes, with additional Roku compatibility available upon request.

5.2 Sound Modes

Optimize your audio experience with three distinct sound effect modes:

- **Movie Mode:** Enhances cinematic soundscapes with dynamic range and surround effects.
- **News Mode:** Optimizes vocal clarity for clear dialogue.
- **Music Mode:** Provides balanced audio for rich musical reproduction.



Image: A visual representation of the three sound effect modes: Movies, News, and Music, showing different content types optimized for each setting.

5.3 Bluetooth Pairing

To pair a Bluetooth device:

1. Turn on the sound bar and select Bluetooth input mode using the remote or control panel.

2. Enable Bluetooth on your device (e.g., smartphone, tablet).
3. Search for "RIOWOIS DS6441G2 Pro" in your device's Bluetooth settings and select it to pair.
4. Once connected, the sound bar will indicate successful pairing, and you can stream audio wirelessly.



Image: A person comfortably streaming music from their smartphone to the RIOWOIS Sound Bar via Bluetooth 5.3, illustrating effortless wireless connectivity.

6. MAINTENANCE

To ensure the longevity and optimal performance of your sound bar system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the sound bar and subwoofer. Do not use liquid cleaners or aerosol sprays.
- **Ventilation:** Ensure that the ventilation openings are not blocked to prevent overheating.
- **Placement:** Avoid placing the unit in direct sunlight, near heat sources, or in areas with high humidity or dust.
- **Power:** Unplug the power adapter from the wall outlet if the unit will be unused for an extended period.

7. TROUBLESHOOTING

If you encounter any issues with your RIOWOIS Sound Bar System, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet not working	Ensure power adapter is securely connected to the sound bar and a working power outlet.

Problem	Possible Cause	Solution
No sound	Incorrect input source; Volume too low; Cables not connected properly; TV audio settings incorrect	Select the correct input source. Increase volume. Check all audio cable connections. Adjust TV audio output settings (e.g., PCM for Optical).
Distorted sound	Volume too high; Poor cable connection; Interference	Lower the volume. Re-seat audio cables. Move away from other electronic devices.
Bluetooth pairing fails	Sound bar not in pairing mode; Device too far; Interference	Ensure sound bar is in Bluetooth mode. Place device closer to sound bar. Disconnect other Bluetooth devices.
Remote control not working	Batteries depleted; Obstruction; Remote out of range	Replace batteries. Remove any obstructions between remote and sound bar. Ensure remote is within operating range.

8. SPECIFICATIONS

Feature	Detail
Model Name	DS6441G2 Pro Soundbar with Wired Subwoofer
Speaker Type	Soundbar
Special Feature	Bass Boost, Wired Subwoofer
Recommended Uses	For Computers, For Gaming Consoles, For Music Players, For Smartphones or Tablets, For Surround Sound Systems, For Televisions
Compatible Devices	Desktop, Gaming Console, Home Theater, Smartphone, Television
Subwoofer Diameter	5.25 Inches
Surround Sound Channel Configuration	2.1 (Note: Product title states 3.1ch, but specifications list 2.1. Please refer to product packaging for definitive channel configuration.)
Product Dimensions	2.5"D x 17"W x 4"H
Control Method	Push Button, Remote
Wireless Communication Technology	Bluetooth
Audio Driver Type	Dynamic Driver
Subwoofer Connectivity Technology	Wired
Specific Uses	Gaming, Home Theatre, Party
Indoor/Outdoor Usage	Indoor

Feature	Detail
Item Weight	5.99 pounds
Speaker Maximum Output Power	150 Watts
Connectivity Technology	Auxiliary, Bluetooth, Optical, TV-ARC, Wired Subwoofer
Audio Output Mode	Stereo
Mounting Type	Wall Mount

9. WARRANTY AND SUPPORT

RIOWOIS is committed to providing excellent customer service. As our valued customer, you are entitled to:

- Professional 24-hour and 7-day service.
- Free remote replacement services.
- Free product replacement within one year of purchase.

For any inquiries or support needs, please contact our customer service team.

© 2026 RIOWOIS. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question