



[Manuals.plus](#) /

> [EasyCom](#) /

> EasyCom PS-DC205-41-BK 41-inch Heavy Duty Dog Crate Instruction Manual

EasyCom PS-DC205-41-BK

EasyCom PS-DC205-41-BK 41-inch Heavy Duty Dog Crate Instruction Manual

Model: PS-DC205-41-BK

1. SAFETY INSTRUCTIONS

Read all instructions carefully before assembly and use. Keep this manual for future reference.

- Ensure all parts are securely fastened before placing your pet inside the crate.
- Regularly inspect the crate for any damage or loose parts. Do not use if damaged.
- This crate is designed for pet containment. Do not use for any other purpose.
- Keep children away from the crate during assembly and ensure they do not play inside the crate unsupervised.
- The materials used are non-toxic and safe for pets.
- Always ensure adequate ventilation for your pet.

2. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Crate Panels (Side panels, Front doors, Rear panel, Bottom panel, Top panels)
- Lockable Wheels (x4)
- Stainless Steel Pet Bowls (x2)
- Pet Name Tag
- Removable Leak-Proof Plastic Tray
- Assembly Hardware (Screws, Allen Wrench)

3. SETUP AND ASSEMBLY

Follow these steps to assemble your EasyCom Heavy Duty Dog Crate:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches. Identify each component using the parts list.
2. **Assemble Base:** Connect the side panels to the bottom panel using the provided screws and Allen wrench. Ensure all connections are snug but do not overtighten.



Image: Initial assembly of the crate base, connecting side panels.

3. **Attach Rear Panel:** Secure the rear panel to the assembled base and side panels.
4. **Install Front Doors:** Attach the double front doors to the front of the crate. Ensure the hinges are correctly aligned and the 4 heavy-duty escape-proof locks function smoothly.



Image: Double front doors with secure locking latches.

5. **Secure Top Panels:** Place the top panels onto the crate structure. The top access door should be positioned for easy interaction. Secure all top panel connections.



Open Roof Top

Expand space for dogs
anytime dog interaction & training



Image: Crate with the open roof top feature.

6. **Install Wheels:** Attach the four lockable metal casters to the bottom of the crate. Ensure they are tightened securely for stability.
7. **Insert Tray and Bowls:** Slide the removable leak-proof plastic tray into the designated slot beneath the perforated floor. Attach the 360° rotating dog bowls to the side of the crate at your desired height.



Image: Built-in adjustable and rotating dog bowls.

8. **Personalize:** Attach the pet name tag to the front of the crate.

4. KEY FEATURES

- **Indestructible & Spacious Design:** Constructed with heavy-duty alloy steel, this crate offers sturdiness and durability. Its extra tall and roomy interior allows large dogs to stand, turn, and stretch freely.
- **Open Top Access:** The top door provides convenient access for interaction, feeding, and training without needing to open the main front doors.
- **Escape-Proof Security:** Equipped with 4 heavy-duty escape-proof locks and reinforced steel latches on double doors, ensuring your pet remains securely contained.
- **Paw-Safe Floor:** Features a smooth round hole steel floor designed to prevent paw snags and tangled fur, protecting your dog's paws from injury.
- **360° Rotating Dog Bowls:** Two integrated stainless steel bowls can be rotated outwards for easy refilling of food and water. They lock firmly in place to prevent tipping and spilling and are adjustable in height.

- **Easy Cleaning:** The removable leak-proof plastic tray slides out easily for quick cleanup of spills and waste. The entire steel structure is designed for long-term use without deformation.
- **Lockable Wheels:** Heavy-duty lockable metal casters allow for smooth movement of the crate and can be locked to ensure stable placement on any surface.



Image: Overview of key features including door design, locks, and wheels.

Heavy Duty Dog Steel Crate

Dog Crate Service
Life: 5–8 Years (Normal Use)



600 μ m Ultimate Durability

Unbendable steel
beats rain/snow/chewing




Non-Toxic




Bite-safe

2 \times powder
coating

600 μ m



Strong Steel
Breathable Panel



Reinforced load-bearing
Steel pipe design

Image: Detail of the heavy-duty steel construction for durability.

5. OPERATING INSTRUCTIONS

- **Opening/Closing Front Doors:** To open, slide the top and bottom latches on each door. Swing the doors outwards. To close, swing the doors inwards and slide the latches into place to secure.
- **Using Top Access Door:** To open, unlatch the top door mechanism and lift the panel upwards. This allows for direct interaction with your pet or for easier cleaning. Securely latch the top door when not in use.
- **Feeding with Rotating Bowls:** To refill food or water, pull the small lever on the bowl holder to rotate the bowl outwards. Fill the bowl, then rotate it back into the crate until it locks into position. The bowls can be adjusted to different heights by repositioning their hanging hooks.
- **Moving the Crate:** To move the crate, unlock all four wheels by flipping their respective levers. Once moved to the desired location, lock the wheels to prevent accidental movement.

6. MAINTENANCE

- **Cleaning the Tray:** The leak-proof plastic tray can be easily slid out from beneath the crate for cleaning. Wash with mild soap and water, then dry thoroughly before reinserting.
- **Cleaning the Crate:** Wipe down the metal bars and panels with a damp cloth and mild, pet-safe cleaner as needed. Avoid abrasive cleaners that could damage the finish.
- **Inspecting Locks and Wheels:** Periodically check all door latches and wheel locking mechanisms to ensure they are functioning correctly and securely.

7. TROUBLESHOOTING

- **Doors not closing securely:** Ensure all latches are properly aligned with their receiving slots. Check for any obstructions or bent components.
- **Wheels not locking:** Verify that the locking levers on each wheel are fully engaged. Clean any debris from the wheel mechanisms if necessary.
- **Crate feels unstable:** Recheck all assembly screws to ensure they are tightened. Ensure the crate is on a flat, level surface.

8. SPECIFICATIONS

Model Number	PS-DC205-41-BK
Brand	EasyCom
Item Weight	63.8 pounds
Product Dimensions (LxWxH)	41.4"L x 28.3"W x 34.3"H
Material	Alloy Steel
Breed Recommendation	All Breed Sizes (suitable for large & medium breeds)
Max Load Capacity	400 lbs
Pet Bowl Capacity	800-900 ml
Special Features	Easy to Clean, Open Top, Lockable Wheels, Adjustable Bowls

Product Dimensions



Inner Size:

40.55"L × 27.56"W | 33.46" Max Ht

Outer Size:

41.33"L × 28.34"W | × 34.25" Max Ht

Max Load Capacity: 400lbs

Pet Bowl Capacity: 800-900ml

Image: Visual representation of product dimensions and capacities.



Find Your Dog's Perfect Fit



Allow 4-5" of Clearance in Length & Height
for Comfortable Movement



41" Dog Crate:

Weight: 50-70 lbs
Shoulder Height: <30"
Fits medium breeds



48" Dog Crate:

Weight: 70-100 lbs
Shoulder Height: <33.5"
Fits medium-to-large breeds



54" Dog Crate:

Weight: 100-150 lbs
Shoulder Height: <37"
Fits large-to-giant breeds




Image: Guide to finding the appropriate crate size for your dog.

9. WARRANTY AND SUPPORT

For warranty information or customer support regarding your EasyCom Heavy Duty Dog Crate, please contact EasyCom Official directly. Refer to your purchase documentation for specific warranty terms and contact details.