F69

Generic F69 Foldable Transparent Keyboard User Manual

Model: F69

1. Introduction

Thank you for choosing the Generic F69 Foldable Transparent Keyboard. This portable keyboard is designed for convenience and versatility, allowing seamless connection to multiple devices across various operating systems. Its compact, two-fold design and transparent aesthetic make it an ideal companion for on-the-go productivity. This manual provides essential information for setting up, operating, and maintaining your keyboard.

2. PRODUCT OVERVIEW

2.1 Key Features

- Transparent Design: Modern and stylish transparent body.
- Foldable & Portable: Two-fold mechanism for easy carrying and storage.
- **Multi-Device Connectivity:** Supports simultaneous pairing with up to three devices via Bluetooth 5.0.
- Wide Compatibility: Compatible with iOS, Android, and Windows operating systems.
- Long Battery Life: 80mAh lithium battery provides up to 10 hours of continuous use and 90 days of standby time.
- Quiet Typing: Scissor switch keys ensure a comfortable and silent typing experience.
- Stable Connection: Reliable Bluetooth connection with a working range of up to 10 meters.
- Type-C Interface: Modern Type-C port for charging.

2.2 Package Contents

- 1 x F69 Foldable Transparent Keyboard
- 1 x USB Charging Cable (Type-C)
- 1 x User Manual

2.3 Product Views



Image 1: The F69 Foldable Transparent Keyboard in its fully unfolded state, showcasing the key layout and transparent casing.



Image 2: The F69 Foldable Transparent Keyboard in its folded, compact state, showing the back panel with a textured surface.



Image 3: An angled view of the keyboard partially folded, highlighting its transparent body and compact design.

3. SETUP

3.1 Charging the Keyboard

- 1. Locate the Type-C charging port on the keyboard.
- 2. Connect the provided USB Type-C charging cable to the keyboard and the other end to a USB power source (e.g., computer, wall adapter).
- 3. The charging indicator light will illuminate. A full charge takes approximately 30 minutes.
- 4. Once fully charged, the indicator light may change color or turn off, depending on the model.

3.2 Power On/Off

- Power On: Unfold the keyboard completely. The keyboard will automatically power on.
- Power Off: Fold the keyboard. It will automatically power off to conserve battery.
- Wake-Up: If the keyboard enters standby mode, press any key to wake it up.

3.3 Bluetooth Pairing

- 1. Ensure the keyboard is powered on (unfolded).
- 2. On your device (smartphone, tablet, computer), enable Bluetooth.
- 3. Press and hold the **Fn** key along with one of the device selection keys **F1**, **F2**, or **F3**) for 3-5 seconds until the corresponding indicator light flashes, indicating pairing mode.
- 4. On your device, search for Bluetooth devices and select "F69 Keyboard" (or similar name) from the list.
- 5. Once connected, the indicator light will stop flashing and remain solid for a few seconds before turning off.
- 6. Repeat this process for up to two additional devices using Fn + F2 and Fn + F3.

4. OPERATING INSTRUCTIONS

4.1 Switching Between Connected Devices

The F69 keyboard supports simultaneous connection to three devices. To switch between them:

- Press Fn + F1 to switch to the first paired device.
- Press Fn + F2 to switch to the second paired device.
- Press Fn + F3 to switch to the third paired device.




Image 4: Illustration showing the keyboard connected to an iOS device, an Android device, and a Windows device, demonstrating its multi-device switching capability.

4.2 System Compatibility

The keyboard is fully compatible with major operating systems. Use the following key combinations to optimize for your specific system:

- Fn + Q: For iOS devices.
- Fn + W: For Android devices.
- Fn + E: For Windows devices.

4.3 Special Function Keys

The top row of keys (F1-F12) includes multimedia and function shortcuts. Press the **Fn** key simultaneously with the desired function key to activate its secondary function (e.g., volume control, media playback).

Notebook square key cap

Short key stroke, feedback sensitive fast, quiet and more comfortable



Image 5: A close-up view of the keyboard's square key caps, designed for a comfortable and responsive typing experience.

5. MAINTENANCE

5.1 Cleaning

- Ensure the keyboard is powered off before cleaning.
- Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution.
- · Avoid excessive moisture and do not spray cleaners directly onto the keyboard.
- · For dust and debris between keys, use compressed air.

5.2 Storage

- Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- Always fold the keyboard when not in use to protect the keys and conserve battery.
- · Avoid placing heavy objects on the folded keyboard.

6. TROUBLESHOOTING

- **Keyboard not powering on:** Ensure the keyboard is fully unfolded. Check battery level and charge if necessary.
- Unable to pair via Bluetooth:
 - Ensure the keyboard is in pairing mode (indicator light flashing).
 - Make sure Bluetooth is enabled on your device.
 - Move the keyboard closer to your device (within 10 meters).
 - Forget the keyboard from your device's Bluetooth settings and attempt to re-pair.
 - Restart both the keyboard (fold and unfold) and your device.
- **Keys not responding:** Check if the keyboard is connected to the correct device channel (F1, F2, F3). Ensure the battery is charged.
- **Connection drops frequently:** Ensure no strong interference sources are nearby. Keep the keyboard within the 10-meter operating range.

7. Specifications

Model	F69
Туре	Two-fold Transparent Keyboard
Connection Method	Bluetooth 5.0
Compatible Systems	iOS, Android, Windows (all systems)
Number of Connected Devices	Supports 3 simultaneous connections
Battery Capacity	80mAh Lithium Battery
Charging Interface	Type-C
Charging Time	Approximately 30 minutes
Continuous Use Time	Up to 10 hours
Standby Time	Up to 90 days (6 months in some descriptions)
Operating Voltage	3.7V
Operating Range	Up to 10 meters
Unfolded Dimensions	30cm x 10.3cm x 0.7cm
Folded Dimensions	15cm x 0.7cm x 1.4cm
Weight	177g

8. WARRANTY AND SUPPORT


This product comes with a standard manufacturer's warranty. Please refer to the packaging or contact your retailer for specific warranty terms and conditions. For technical support or inquiries, please contact the vendor or retailer from whom you purchased the product.

Related Documents - F69



Lenovo ThinkPad Regulatory Notice: Compliance and Safety Information

This document provides essential regulatory compliance and safety information for Lenovo ThinkPad laptops, detailing wireless module approvals and standards across various global regions. It covers FCC, ISED, EU, and country-specific regulations.




Инструкция по эксплуатации механических часов Orient

Полное руководство по эксплуатации, уходу и настройке механических часов Orient. Включает информацию о водонепроницаемости, технических характеристиках, механизмах завода и установке времени/даты.



Инструкция по эксплуатации часов Orient

Подробное руководство по эксплуатации и обслуживанию часов Orient, включая информацию о водонепроницаемости, технических характеристиках и настройке времени и календаря.



Orient Mechanical Watches Instruction Manual

Comprehensive guide for Orient mechanical watches, covering operation, maintenance, safety precautions, and specifications for models AA, AC, AG, AP.



Orient Watch Instruction Manual

Comprehensive instruction manual for Orient mechanical watches, covering operation, maintenance, safety precautions, and technical specifications.



ORIENT Mechanical Watch User Manual and Instructions

A comprehensive guide for ORIENT mechanical watches, detailing safety precautions, water resistance, care, technical specifications, and operating instructions for various calibers.