

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Proscenic](#) /

› [Proscenic F10 Ultra Cordless Wet Dry Vacuum Cleaner Instruction Manual](#)

Proscenic F10 Ultra

Proscenic F10 Ultra Cordless Wet Dry Vacuum Cleaner

Model: F10 Ultra | Brand: Proscenic

1. INTRODUCTION

Thank you for choosing the Proscenic F10 Ultra Cordless Wet Dry Vacuum Cleaner. This 3-in-1 device is designed to simplify your cleaning routine by vacuuming, mopping, and washing simultaneously. With its powerful suction, long battery life, and intelligent features, the F10 Ultra provides an efficient and thorough cleaning experience for various floor types. This manual provides essential information for safe operation, maintenance, and troubleshooting to ensure optimal performance of your device.

2. SAFETY INSTRUCTIONS

Please read all safety instructions carefully before using the appliance. Keep this manual for future reference.

- Ensure the power adapter is compatible with your local voltage.
- Do not immerse the main unit in water or other liquids.
- Keep hair, loose clothing, fingers, and all parts of the body away from openings and moving parts.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If the appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Always turn off the appliance before connecting or disconnecting the motorized brush.
- Store the appliance indoors in a cool, dry place.

3. PRODUCT OVERVIEW


The Proscenic F10 Ultra is a versatile cleaning solution designed for efficiency and convenience.

Key Features:

- **3-in-1 Cleaning:** Vacuums, mops, and washes simultaneously for comprehensive floor care.
- **Extended Runtime:** Up to 60 minutes of continuous cleaning on a single charge, covering up to 230 m².

- **Self-Propelled Design:** Lightweight (4.2 kg) and self-propelled for effortless maneuverability.
- **Automated Self-Cleaning:** One-touch self-cleaning function for the roller brush and internal air duct.
- **Dual Tank System:** Separate 750ml clean water tank and 550ml dirty water tank ensure cleaning with fresh water.
- **Edge-to-Edge Cleaning:** Narrow-sided roller brush cleans within 0.7mm of edges and corners.
- **Flexible Steering:** Swivel head and 170° reclinable range allow access to tight spaces and under furniture.
- **Quick Drying:** Achieves a 92% water recovery rate, leaving floors dry and streak-free.
- **Intelligent Alerts:** Notifies users when the dirty water tank is full and automatically shuts off when placed vertically during cleaning.
- **Multilingual Voice Prompts:** Switchable voice guidance for operational convenience.

Components Included:



What's in the box: Main Body, Handle, Charging Base, Adapter, Cleaning Brush, Cleaning Solution, User Manual.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Assemble:** Insert the handle into the main body until it clicks securely into place.
3. **Charge:** Place the assembled vacuum cleaner on the charging base. Connect the power adapter to the charging base and a power outlet. Ensure the device is fully charged before first use. The LED display will indicate charging status.
4. **Fill Clean Water Tank:** Remove the clean water tank, fill it with clean water (and a small amount of cleaning solution if desired), and reattach it securely.

5. OPERATING INSTRUCTIONS

The F10 Ultra offers multiple cleaning modes for various needs.

Power On/Off:

- Press the Power button on the handle to turn the device on or off.

Cleaning Modes:

Press the 'Mode' button on the handle to cycle through the available cleaning modes:

- **Smart Mode:** For regular daily cleaning. The device intelligently adjusts suction and water flow.
- **Max Mode:** Provides maximum suction and water for stubborn stains and heavy dirt.
- **Suction Mode:** For absorbing liquids only, without dispensing water. Ideal for spills.



Choose from Smart, Max, or Suction modes for versatile cleaning.



The 3-in-1 function handles various types of wet and dry messes.

Maneuverability:

- The self-propelled design makes pushing and pulling the vacuum effortless.
- The flexible head and 170° reclinable body allow you to reach under furniture and into tight corners.
- The narrow-sided roller brush ensures thorough edge-to-edge cleaning, getting within 0.7mm of walls and baseboards.



Automatic traction provides effortless movement during cleaning.



Edge-to-edge cleaning reaches within 0.7mm of walls.

Quick Drying:

The F10 Ultra boasts a 92% water recovery rate, ensuring your floors dry quickly without leaving streaks or residue.



Experience quick drying with no streaks after cleaning.

Multilingual Voice Prompts:

The device provides voice prompts for various operations and alerts. To switch languages, press and hold the 'Mode' button for 5 seconds. The screen will flash, and each short press will cycle through available languages (German, French, Italian, English, Spanish). To activate/deactivate voice commands, press and hold the 'Clean' button for 5 seconds, then power off the device.



Easily switch between multiple languages for voice prompts.

6. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your F10 Ultra.

Automated Self-Cleaning:

After each use, place the vacuum cleaner on its charging base. Press the dedicated self-cleaning button to initiate the automatic cleaning cycle. The roller brush will be thoroughly rinsed and dried, preventing odors and maintaining hygiene.



One-touch automatic self-cleaning for convenience.

Emptying Dirty Water Tank:

The device will alert you when the dirty water tank is full. Remove the tank, empty its contents, rinse it with clean water, and reattach it securely.



The dual tank system keeps clean and dirty water separate.

Filter Maintenance:

The HEPA filter is washable. Regularly remove and rinse the filter under running water. Allow it to air dry completely before reinserting to maintain optimal suction performance.

7. TROUBLESHOOTING

If you encounter any issues with your Proscenic F10 Ultra, please refer to the following common solutions:

- **No Power:** Ensure the device is fully charged and correctly placed on the charging base. Check the power adapter connection.
- **Weak Suction:** Check if the dirty water tank is full or if the filter is clogged. Clean the filter and empty the tank if necessary. Ensure the roller brush is free from obstructions.
- **Water Leaking:** Verify that both clean and dirty water tanks are correctly installed and sealed. Check for any cracks or damage to the tanks.
- **Self-Cleaning Not Working:** Ensure the device is properly seated on the charging base and has sufficient battery charge.
- **Unusual Noise:** Turn off the device and check the roller brush for any foreign objects or tangled hair.

For further assistance, please contact Proscenic customer support.

8. SPECIFICATIONS

Feature	Specification
Model Name	F10 Ultra
Brand	Proscenic
Power Source	Battery Powered (Cordless)
Battery Life	Up to 60 Minutes
Rated Power	350 Watts
Voltage	28.8 Volts
Clean Water Tank Capacity	750 ml
Dirty Water Tank Capacity	550 ml
Recommended Surfaces	All floor types (hardwood, tile, laminate, etc.)
Filter Type	HEPA Filter (Washable)
Noise Level	60 Decibels
Number of Speed/Power Levels	3
Item Weight	7.82 Kilograms
Dimensions (L x W x H)	25L x 20l x 110H cm
Usage Environment	Indoor

9. WARRANTY AND SUPPORT

Proscenic is committed to providing high-quality products and excellent customer service.

Warranty Information:

- The Proscenic F10 Ultra comes with up to a 24-month warranty from the date of purchase.
- A 30-day satisfaction guarantee is offered, allowing for refunds or replacements within this period.
- Please retain your proof of purchase for warranty claims.

Customer Support:

For any questions, technical assistance, or warranty claims, please contact our customer support team. We offer 24/7 support to assist you.

Politica di Servizio

-  Team di assistenza rapida 24/7
-  Garanzia soddisfatti o rimborsati entro 30 giorni
-  Fino a 24 mesi di garanzia
-  Spedizione veloce dai magazzini locali

Proscenic Service Policy highlights our commitment to customer satisfaction.

10. PRODUCT VIDEO OVERVIEW

Watch this video for a visual guide on the Proscenic F10 Ultra's features and operation.

Your browser does not support the video tag.

Official product demonstration video showcasing the Proscenic F10 Ultra's 3-in-1 cleaning, self-cleaning, and maneuverability.