

[Manuals.plus](#) /

› [LUXOAK](#) /

› LUXOAK 60" Glossy Burl Wood Sideboard Buffet with Storage (Model CBS009) - Instruction Manual

LUXOAK CBS009

LUXOAK 60" Glossy Burl Wood Sideboard Buffet with Storage

Model: CBS009

INTRODUCTION

Thank you for choosing the LUXOAK 60" Glossy Burl Wood Sideboard Buffet with Storage. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: Front view of the LUXOAK 60-inch Glossy Burl Wood Sideboard Buffet.

SAFETY INFORMATION

- Always assemble the unit on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as needed.
- An anti-tip kit is included to prevent accidental tipping. It is crucial to install this kit to protect your family's safety, especially in households with children or pets.
- Do not exceed the maximum weight capacity of 170 pounds for the entire unit.

PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Burl Wood Sideboard Buffet panels
- Hardware (screws, dowels, cam locks, etc.)
- Installation Kit (tools may be required, not always included)
- Shelves (adjustable)
- Anti-tip kit

ASSEMBLY INSTRUCTIONS

Assembly typically requires two people and can take approximately 1 to 4 hours, depending on experience. Follow the detailed instructions provided in the included installation kit. Ensure you have adequate space and the necessary tools (e.g., screwdriver, hammer) before starting.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface. Identify each part using the labels (A-S, if applicable) and the parts list in your installation guide.
2. **Assemble the Base Structure:** Begin by attaching the trapezoidal plank wood legs to the bottom panel. Ensure they are securely fastened.
3. **Construct the Main Frame:** Connect the side panels to the bottom and top panels using the provided hardware. Pay close attention to the orientation of each piece.
4. **Install Drawers:** Assemble the three drawers according to the instructions. Install the two-section silent slide rails into the cabinet frame and onto the drawers. Insert the drawers into their designated slots.
5. **Attach Cabinet Doors:** Mount the two cabinet doors using the large curved hinges. Adjust the hinges to ensure proper alignment and smooth opening/closing.
6. **Insert Adjustable Shelves:** Place the adjustable shelves into the cabinets at your desired height.
7. **Attach Handles:** Secure the circular brass metal handles to the drawers and cabinet doors.
8. **Install Anti-Tip Kit:** Follow the specific instructions for installing the anti-tip kit to a wall stud. This step is critical for safety.



Image: Product dimensions and weight capacities for the sideboard.



Image: Key features including brass metal ring handle, anti-tipping design, and trapezoidal wooden legs.

OPERATING INSTRUCTIONS

The LUXOAK Sideboard is designed for versatile use in various rooms such as dining rooms, living rooms, entryways, and hallways.

- **Drawers:** The three drawers feature circular brass metal handles and two-section silent slide rails for smooth operation. Use them to store smaller items, cutlery, or personal belongings.
- **Cabinets:** The two storage cabinets are equipped with adjustable shelves. To adjust a shelf, carefully lift it and reposition the shelf pins to the desired height. This allows for flexible storage of larger items, dishes, or decorative pieces.
- **Spacious Tabletop:** The top surface can accommodate various items, including media consoles, decorative accents, lamps, or serving dishes. It can support TVs up to 65 inches.

Two Enclosed Cabinets with Shelves

Spacious Tabletop



Three Drawers Provide Ample Storage

Image: Sideboard with drawers and cabinets open, illustrating storage capacity.

CUSTOMIZE YOUR SPACE

With Adjustable Shelves



Image: Adjustable shelves inside a cabinet.



Image: Illustration of the sideboard supporting a TV up to 65 inches.

Your browser does not support the video tag.

Video: A demonstration of the LUXOAK Mappa Burl Wood Sideboard Buffet Cabinet, showcasing its storage features and design.

MAINTENANCE

Proper care will help maintain the beauty and longevity of your sideboard.

- **Cleaning:** Wipe the high-gloss surface with a soft, dry cloth. For light cleaning, a slightly damp cloth can be used,

followed immediately by a dry cloth.

- **Avoid Harsh Chemicals:** Do not use harsh chemicals, abrasive cleaning materials, or polishes that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining or damage to the burl wood finish.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration.



Brass Metal Ring Handle

Anti-tipping Design



Trapezoidal Wooden Legs

Image: Example of unique burl wood patterns, highlighting natural variations.

TROUBLESHOOTING

If you encounter any issues during or after assembly, please refer to the following common solutions:

- **Wobbly Unit:** Ensure all screws and fasteners are fully tightened. Check that the adjustable feet are properly leveled on uneven floors.
- **Drawers Not Sliding Smoothly:** Verify that the drawer slides are installed correctly and are free of obstructions. Apply

- a silicone-based lubricant if necessary.
- **Doors Not Aligning:** Adjust the hinges on the cabinet doors to achieve proper alignment. Most hinges allow for minor adjustments in multiple directions.
 - **Missing Parts:** Double-check the package contents against the parts list in your installation guide. If parts are genuinely missing, contact customer support for replacements.

SPECIFICATIONS

Feature	Detail
Brand	LUXOAK
Model Number	CBS009
Color	Blond Burl
Material	Engineered Wood
Product Dimensions (D x W x H)	60.2" x 15.5" x 32.3"
Item Weight	122.8 pounds
Weight Capacity (Maximum)	170 pounds
Number of Drawers	3
Number of Doors	2
Number of Adjustable Shelves	2
Finish Type	Polished, High-Gloss
Hardware Color	Brass
Installation Type	Floor Mount
Assembly Required	Yes
Special Features	Adjustable Feet, Anti-tip kit included

WARRANTY AND SUPPORT

For warranty information or assistance with your LUXOAK product, please refer to the documentation included in your original packaging or contact the retailer where the product was purchased. Our customer support team is available to help with any questions or concerns you may have regarding assembly, missing parts, or product functionality.

Please have your model number (CBS009) and purchase details ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question