

[manuals.plus](#) /› [NARVI](#) /› [NARVI Air Fryer 4.5L - 1400W Instruction Manual](#)

## NARVI 4.5L - 1400W

# NARVI Air Fryer 4.5L - 1400W Instruction Manual

MODEL: 4.5L - 1400W

## 1. Important Safety Instructions

Please read all instructions carefully before using the appliance and retain them for future reference. Incorrect operation may cause damage to the appliance or personal injury.

- Always place the air fryer on a stable, heat-resistant surface, away from walls or other appliances to ensure proper ventilation.
- Do not immerse the appliance, cord, or plug in water or any other liquid.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Hot air is released through the air outlet opening. Keep your hands and face at a safe distance from the steam and from the air outlet openings.
- The appliance is equipped with an automatic shut-off function.
- This appliance is for household use only.
- The basket and crisper plate are free of BPA and PFOA.

## 2. Product Overview

### 2.1 Components

- Main Unit
- Removable Basket with Handle
- Crisper Plate



Image 1: Front view of the NARVI Air Fryer, showcasing its sleek black design and digital touch panel.

## 2.2 Key Features

- **Exclusive Visible Glass Basket:** Allows monitoring of the cooking process without opening the air fryer. The 100% heat-resistant glass window provides clear visibility of browning and cooking progress.
- **Extended Temperature Range:** Adjustable from 40°C to 260°C, suitable for various recipes including gratins, crispy meats, baking, and light dehydration.
- **Compact and Efficient 4.5L Capacity (1400W):** Ideal for small households or couples, consuming less energy than larger models while delivering crispy and uniform results.
- **Digital Touch Multimenu Panel:** Features a touch sensor with 10 automatic 360° cooking programs for frying, baking, reheating, and roasting with precise and uniform results.

- **Safe, Healthy, and Easy to Clean:** BPA and PFOA free, with a safety switch and overheating protection. The glass basket is dishwasher safe, and the unit has a non-slip base.

## 3. Setup

---

### 3.1 Unpacking and First Use

1. Remove all packaging materials, stickers, and labels from the appliance.
2. Clean the basket and crisper plate with hot water, some dishwashing liquid, and a non-abrasive sponge.
3. Wipe the inside and outside of the appliance with a moist cloth.
4. Place the crisper plate inside the basket.

### 3.2 Placement

Place the air fryer on a stable, horizontal, and heat-resistant surface. Ensure there is at least 10 cm of free space on the back and sides of the appliance, and 10 cm above it, to allow for adequate air circulation.

## 4. Operating Instructions

---

### 4.1 General Operation

1. Plug the appliance into a grounded wall outlet.
2. Carefully pull the basket out of the air fryer.
3. Place the ingredients in the air fryer basket. Do not exceed the MAX indication.
4. Slide the basket back into the air fryer.
5. Press the power button to turn on the appliance.



Image 2: A user interacting with the digital touch panel of the NARVI Air Fryer to select cooking settings.

#### 4.2 Pre-heating

For optimal results, it is recommended to pre-heat the air fryer for 3-5 minutes before adding ingredients. Select your desired temperature and time, then press start. The appliance will indicate when pre-heating is complete.

#### 4.3 Manual Cooking

After turning on the appliance, use the temperature and time control buttons on the digital panel to set your desired cooking parameters. The temperature can be adjusted from 40°C to 260°C, and the timer up to 60 minutes. Press the start button to begin cooking.

#### 4.4 Pre-set Programs

The NARVI Air Fryer features 10 pre-set cooking programs for common dishes. To use a pre-set program:

1. Press the 'Menu' button to cycle through the available programs (e.g., French Fries, Steak, Shrimp, Chicken Wings, Meat, Vegetables, Cake, Pizza).
2. Once the desired program is selected, the appliance will display the default temperature and time. These can be adjusted manually if needed.

3. Press the start button to begin the cooking cycle.

Your browser does not support the video tag.

*Video 1: Demonstration of the NARVI Air Fryer's digital controls, including programmable timer, adjustable cooking temperature, and quick pre-set options.*

## 5. Cleaning and Maintenance

Clean the appliance after every use.

### 5.1 Cleaning the Basket and Crisper Plate

- Allow the basket and crisper plate to cool down completely before cleaning.
- The glass basket and crisper plate are dishwasher safe.
- Alternatively, clean them with hot water, dishwashing liquid, and a non-abrasive sponge.
- For stubborn food residues, soak the basket in hot water with some dishwashing liquid for approximately 10 minutes.



*Image 3: The removable basket and crisper plate of the NARVI Air Fryer, designed for easy cleaning.*

### 5.2 Cleaning the Main Unit

- Wipe the outside of the appliance with a moist cloth.
- Never use abrasive cleaning agents or scouring pads.
- Clean the heating element with a cleaning brush to remove any food residues.

### 5.3 Storage

Unplug the appliance and let it cool down completely. Ensure all parts are clean and dry before storing. Store the air fryer in a dry, cool place.

## 6. Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not work.	The appliance is not plugged in.	Plug the main plug into a grounded wall socket.
Food is not cooked evenly.	Too many ingredients in the basket.	Reduce the amount of ingredients.
White smoke comes out of the appliance.	Grease residues from previous use.	Clean the basket and crisper plate thoroughly after each use.
Fresh fries are not crispy.	Not enough oil used.	Add a little oil to the fries for a crispier result.

## 7. Specifications

Specification	Value
Brand	NARVI
Model	4.5L - 1400W
Color	Black
Capacity	4.5 Liters
Power	1400 Watts
Material	Stainless Steel
Dimensions (L x W x H)	31 x 31 x 33 cm
Product Weight	3.9 kg
Special Feature	Temperature Control

## 8. Warranty and Support

This NARVI Air Fryer comes with a standard manufacturer's warranty. For detailed information regarding warranty terms, conditions, and duration, please refer to the warranty card included in the product packaging or contact NARVI customer support directly.

If you encounter any issues or have questions about your appliance, please contact our customer support team. Contact details can typically be found on the NARVI website or on the product packaging.

