

[Manuals.plus](#) /

> [Tangkula](#) /

> Tangkula 6-Piece Patio Dining Table Set User Manual (Model HW74379+HW74377WH-2+HW74378-1)

Tangkula HW74379+HW74377WH-2+HW74378-1

Tangkula 6-Piece Patio Dining Table Set User Manual

Model: HW74379+HW74377WH-2+HW74378-1

1. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these guidelines may result in injury or damage to the product.

- Always follow assembly instructions carefully to avoid injury.
- Do not leave the product outdoors in the rain for extended periods.
- Apply wood polish oil regularly to maintain the product's lifespan.
- Be cautious of sharp edges and heavy components during assembly and handling.
- Do not exceed the bench's weight capacity of 800 lbs/360 kg.
- Do not exceed the table's weight capacity of 165 lbs/75 kg.

2. PRODUCT OVERVIEW

The Tangkula 6-Piece Patio Dining Table Set provides a comfortable and functional outdoor dining solution. It includes a rectangular dining table, four armchairs, and one backless bench, designed to accommodate up to 6 people.



Image: The complete 6-piece patio dining set, featuring a rectangular table, four chairs, and a bench, positioned next to a swimming pool.

The set features a durable acacia wood frame and robust metal supports, ensuring stability and longevity. The chairs are designed for comfort with cushioned seats and ergonomic backrests.



Comfortably
Seat 5-6 People

Product Dimensions




Image: Visual representation of the dimensions and weight capacities for the dining table, bench, and chairs.

3. SETUP AND ASSEMBLY

Assembly is required for this dining set. All necessary hardware is included. A Phillips-head screwdriver or an electric drill is recommended for faster and easier assembly.

3.1 Assembly Steps

1. Unpack all components and verify against the parts list in the included user's manual.
2. Assemble the dining table by attaching the metal legs to the tabletop. Ensure all screws are tightened securely.
3. Assemble the bench by attaching its metal legs to the wooden seat.
4. Assemble each armchair by attaching the seat, backrest, and armrests to the frame.
5. Once assembled, place the furniture on a level surface.

3.2 Adjustable Foot Pads

The table and bench legs are equipped with adjustable foot pads. These can be rotated to stabilize the furniture on uneven surfaces, preventing wobbling.

Robust Metal Frame

Offer reliable support,
not easy to deform



Adjustable Foot Pads

Keep the table stable and
balanced even on the uneven floors

Image: Close-up view of the robust metal frame supporting the table and an adjustable foot pad for leveling.

4. OPERATING INSTRUCTIONS

4.1 Seating Capacity

This 6-piece dining set is designed to comfortably seat 5 to 6 individuals. The table accommodates four chairs and one bench.

4.2 Umbrella Hole Functionality

The center of the dining table features a 1.97-inch (5 cm) umbrella hole. This allows for the insertion of a standard patio umbrella (not included) to provide shade and sun protection. A protective wood cap is included to cover the hole when an umbrella is not in use.



1.97" Umbrella Hole

Secure your umbrella, provide shade and protection on sunny days



Image: The dining table with an umbrella inserted, and a detailed view of the 1.97-inch umbrella hole.

5. MAINTENANCE AND CARE

5.1 Acacia Wood Care

The dining set is constructed from acacia wood, known for its durability. To maintain its appearance and extend its lifespan:

- Regularly apply wood polish oil (not included) to the wood surface. This helps protect the wood from weathering and maintains its natural luster.
- Avoid leaving the furniture outdoors in the rain for prolonged periods. Excessive moisture can cause damage. Consider using a furniture cover during inclement weather or when not in use for extended periods.
- Clean the wood surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.

Premium Acacia Wood Frame



Natura



Wear-resistant




Reliable

Maintenance Tips

- ▶ Please apply wood polish oil (not included) to the wood surface regularly
- ▶ Please avoid leaving it outdoors in the rain to extend its lifespan

Image: Close-up of the acacia wood frame with icons indicating natural, wear-resistant, and reliable qualities, alongside maintenance tips.



Solid Acacia Wood
Warp-resistant, sturdy and reliable



Maintenance Tips
Apply wood polish oil (not included) to the wood surface

Image: A slatted bench seat with a close-up of the wood thickness and a hand applying wood polish oil.

5.2 Cushion Care

The armchairs include removable, sponge-padded seat cushions for comfort. The zippered cushion covers are washable for easy cleaning.

- Remove cushion covers before washing.
- Follow the care instructions on the cushion cover label for washing. Typically, machine wash cold on a gentle cycle and air dry.
- Ensure cushions are completely dry before reattaching to prevent mildew.

Comfy Sitting Experience

Breathable Slat Design



Ergonomic Tilt Backrest



Soft Sponge Cushion



Comfy Armrests



Washable Zippered Cover

Image: Detailed view of chair features, highlighting the breathable slat design, ergonomic backrest, soft sponge cushion, comfortable armrests, and the washable zippered cover.

6. TROUBLESHOOTING

This section addresses common issues you might encounter with your patio dining set.

6.1 Furniture Wobbles

- **Check Assembly:** Ensure all screws and bolts are securely tightened. Loose connections can cause instability.
- **Adjust Foot Pads:** Use the adjustable foot pads on the table and bench legs to level the furniture on uneven surfaces. Rotate them until stability is achieved.

6.2 Wood Appears Dry or Faded

- **Apply Wood Oil:** The acacia wood requires regular oiling to maintain its appearance and protect it from environmental factors. Apply a suitable wood polish oil (not included) as part of routine maintenance.
- **Protect from Elements:** Prolonged exposure to direct sunlight and rain can cause fading and drying. Use a furniture cover or store the set in a sheltered area when not in use.

7. SPECIFICATIONS

Feature	Detail
Model Number	HW74379+HW74377WH-2+HW74378-1
Color	Natural + Black
Material	Acacia Wood, Metal, Sponge, Non-woven Fabric
Dining Table Size (L x W x H)	63" x 32" x 30" (160 x 80 x 75 cm)
Bench Size (L x W x H)	48" x 14" x 18" (120 x 35 x 45 cm)
Dining Chair Size (L x W x H)	22.5" x 23" x 34" (57 x 58 x 86 cm)
Chair Seat Size (L x W)	19.5" x 18" (49 x 45.5 cm)
Chair Seat Height	16.5" (42 cm)
Bench Weight Capacity	800 lbs (360 kg)
Table Weight Capacity	165 lbs (75 kg)
Umbrella Hole Diameter	1.97" (5 cm)
Net Weight	141 lbs (64 kg)
Assembly Required	Yes

8. WARRANTY INFORMATION

Warranty details for the Tangkula 6-Piece Patio Dining Table Set are typically provided by the manufacturer at the time of purchase. Please refer to any documentation included with your product or contact Tangkula customer support for specific warranty terms and conditions.

9. CUSTOMER SUPPORT

For further assistance, questions, or to purchase replacement parts, please contact Tangkula customer support or visit their official store.

Tangkula Store: [Visit the Tangkula Store on Amazon](#)