

[Manuals.plus](#) /

› [FASDUNT](#) /

› FASDUNT CY1 Handheld Shower Head Replacement Filter Instruction Manual

FASDUNT SP8-US

FASDUNT CY1 Handheld Shower Head Replacement Filter Instruction Manual

Model: SP8-US

PRODUCT OVERVIEW

The FASDUNT replacement shower filter cartridges are designed specifically for the FASDUNT CY1 Handheld Shower Head. These filters feature a multi-stage filtration system to improve water quality for showering.

The multi-layer filter includes KDF 55, Vitamin C Balls, activated carbon, and calcium sulfite. This combination is engineered to effectively remove chlorine, fluoride, heavy metals, and other impurities from your shower water. The goal is to soften the water, which can contribute to healthier skin and reduced hair damage.

Regular replacement of these filters helps prevent clogging and limescale buildup, thereby extending the lifespan of your handheld shower head.

INSTALLATION INSTRUCTIONS

Follow these steps to replace the filter cartridge in your FASDUNT CY1 Handheld Shower Head.

Quick Release Filter Replacement

Step 1



Step 2



Step 3



Step 4



Note:

The markings on the handle of the handheld showerhead indicate the closing direction and closed status. The showerhead is closed when the two triangular symbols are aligned.

Image: Quick Release Filter Replacement Steps. This image illustrates the four steps for replacing the filter cartridge: opening the showerhead, removing the old filter, inserting the new filter, and closing the showerhead.

- Step 1: Open the Filtered Showerhead.** Turn the end knob counterclockwise in the direction of the arrow until it stops. Then, pull the end piece outward to open the showerhead.
- Step 2: Replace the Filter.** Remove the old filter cartridge from the showerhead. Insert the new FASDUNT replacement filter cartridge into the showerhead.
- Step 3: Close the Filtered Showerhead.** Align the triangular symbol on the showerhead with the "Close" marking. Insert the end piece back into the showerhead and rotate it clockwise along the arrow direction until the two triangular symbols align, indicating it is securely closed.

Your browser does not support the video tag.

Video: How to replace shower filter? This video demonstrates the step-by-step process of replacing the filter cartridge in the FASDUNT CY1 Handheld Shower Head, showing how to open, remove, insert, and close the unit.

OPERATING PRINCIPLES: MULTI-STAGE FILTRATION

The FASDUNT replacement filter utilizes a multi-stage filtration process to purify your shower water. Each stage targets specific impurities to enhance water quality.



Image: Superior Filtration Technology. This diagram shows the internal structure of the filter, detailing layers such as Micro-Porous PP Cotton, Calcium Sulfite Balls, Alkaline Balls, Mineralized Balls, VC Balls, Medical Stone, Activated Carbon, Ceramic Balls, and KDF-55, and their role in purifying tap water into filtered water.

- **Filtration Stage:** This initial stage removes chlorine, heavy metal sediments, and other harmful impurities from the water.
- **Soften Stage:** Water is energized with oxygen to improve skin and hair health, helping to maintain water and oil balance.
- **Rejuvenation Stage:** Beneficial elements, including Vitamin C, are infused into the water.



Image: Purify the Water, Protect Whole Family. This image illustrates the benefits of filtered water, including odor-free water (removes chlorine smell), hair repair (rejuvenates damaged hair), skin protection (reduces itching and dryness), and baby health care (improves skin immunity).

MAINTENANCE AND REPLACEMENT GUIDELINES

To ensure optimal performance and continued water purification, regular replacement of the filter cartridge is essential.

- For optimal performance, replace the filter cartridge every **3-4 months**.
- Actual replacement frequency may vary based on your local water quality conditions and usage. If your water contains high levels of chlorine or other impurities, you may need to change the filter more frequently.

TROUBLESHOOTING COMMON WATER QUALITY ISSUES

Unfiltered water can lead to various issues affecting your skin, hair, and overall shower experience. The FASDUNT filter is designed to address these common problems.



Image: Unfiltered Water Causes Multiple Problems. This image illustrates issues like skin problems, damaged hair, stinging eyes, and smelly water caused by chlorine and heavy metals in unfiltered water. It also shows the benefits of filtered water in preventing these issues.

Problems Addressed by Filtration:

- **Skin Problems:** Reduces dry skin, eczema, and irritation caused by chlorine and heavy metals.
- **Hair Damage:** Helps prevent dry, dull, and damaged hair, hair shedding, and changes in hair color.
- **Unpleasant Odors:** Eliminates chlorine smell and other unpleasant odors in shower water.
- **Clogging and Limescale:** Filters sediment and particles to prevent buildup in your showerhead.

If you experience these issues, ensuring your filter is correctly installed and replaced regularly can significantly improve your shower water quality.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	FASDUNT
Model Number	SP8-US
Compatible Shower Head	FASDUNT CY1 Handheld Shower Head
Included Components	Shower Filter Replacement *2
Item Weight	2.39 ounces
Product Dimensions	0.87 x 0.87 x 3.11 inches
Color	Blue
Manufacturer	FASDUNT

Product Dimensions

**Only Fits FASDUNT
CY1 Showerhead**



Image: Product Dimensions. This image displays the filter cartridge with its dimensions (0.87 inches diameter, 3.11 inches length) and indicates that it only fits the FASDUNT CY1 Showerhead.

WARRANTY AND SUPPORT

Information regarding specific warranty details or direct customer support contacts for this product is not provided in the available data. Please refer to the product packaging or the official FASDUNT website for warranty information and customer service inquiries.

You may also visit the [FASDUNT Store on Amazon](#) for additional product information and support resources.

