Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LELELINKY Set 1

LELELINKY 2-Tier Record Player Stand (Set 1) Instruction Manual

Model: Set 1

1. Introduction

Thank you for choosing the LELELINKY 2-Tier Record Player Stand. This stand is designed to provide organized storage for your vinyl records and a stable surface for your record player. It can also serve as a versatile end table, sofa side table, or bedroom nightstand. Please read this manual carefully before assembly and use to ensure proper setup and longevity of your product.



Image 1.1: The LELELINKY 2-Tier Record Player Stand, showcasing its design and capacity for a record player and vinyl records.

2. Package Contents

Before beginning assembly, please verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Top Shelf (1)
- Bottom Shelf (1)
- Side Panels/Legs (4)
- Record Dividers (2)
- Assembly Hardware (screws, dowels, adjustable foot pads)
- Assembly Tool (Allen wrench)
- Instruction Manual (this document)

3. Assembly Instructions

Assembly of this record player stand is straightforward. All necessary tools and labeled parts are included. Please follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Attach Side Panels to Bottom Shelf:** Identify the bottom shelf and the four side panels. Securely attach the side panels to the designated points on the bottom shelf using the provided screws. Ensure they are tightened but do not overtighten.
3. **Insert Record Dividers:** Slide the two record dividers into the slots on the bottom shelf. These dividers help organize and support your vinyl records.
4. **Attach Top Shelf:** Place the top shelf onto the upper ends of the side panels. Align the holes and secure the top shelf using the remaining screws.
5. **Install Adjustable Foot Pads:** Screw the adjustable foot pads into the bottom of each leg. These pads can be adjusted to stabilize the stand on uneven surfaces.

Once assembled, gently lift and place the stand in your desired location. Avoid dragging the stand to prevent damage.

4. Operating and Usage

The LELELINKY 2-Tier Record Player Stand is designed for versatile use:

- **Record Player Placement:** The spacious tabletop is suitable for various record player sizes. Place your record player centrally on the top shelf for stability.
- **Vinyl Record Storage:** The second tier, equipped with dividers, can hold up to 100 assorted records. Arrange your records vertically for easy access and to prevent warping.
- **Multifunctional Use:** Beyond a record player stand, this unit can function as an end table, a small printer stand, or a nightstand. Its compact design is ideal for small apartments or narrow spaces.



Image 4.1: The stand demonstrating its versatility as a printer stand, providing storage for books and office supplies.

5. Maintenance

To ensure the longevity and appearance of your record player stand, follow these maintenance guidelines:

- **Cleaning:** Wipe the surfaces with a soft, dry cloth. For stubborn marks, use a slightly damp cloth with mild soap, then dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Avoid Moisture:** Do not expose the stand to excessive moisture or direct sunlight, as this can cause warping or discoloration of the engineered wood.
- **Check Connections:** Periodically check and retighten all screws to ensure the stand remains stable.
- **Adjust Foot Pads:** If the stand wobbles, adjust the individual foot pads by rotating them until the stand is level and stable.

6. Troubleshooting

If you encounter any issues with your LELELINKY 2-Tier Record Player Stand, please refer to the following common solutions:

- **Stand is Wobbly:** Ensure all screws are securely tightened. Adjust the individual foot pads on the bottom of each leg to compensate for uneven flooring.
- **Parts Do Not Fit:** Double-check the assembly instructions and part labels. Some parts may appear similar but are designed for specific locations. Do not force parts together. If a part genuinely does not fit or is missing, contact customer support.
- **Scratches or Dents:** Minor scratches can sometimes be touched up with furniture repair markers that match the wood finish. For significant damage, contact customer support for advice.

7. Specifications



Image 7.1: Detailed dimensions of the record player stand, including overall height, width, depth, and shelf spacing.

Feature	Detail
Model	Set 1

Color	Grey White
Material	Engineered Wood
Product Dimensions (D x W x H)	11.81" x 15.75" x 20.87"
Number of Shelves	2
Item Weight	4.17 kg (9.19 lbs)
Mounting Type	Freestanding (assembly required)
Special Features	Rounded corners, solid wooden pillars, record dividers, adjustable feet



Image 7.2: Key design features including safe rounded corners, solid wooden pillars for support, classified storage with dividers, and 360-degree adjustable feet for stability.

8. Warranty and Support

This product is covered by a standard return policy. For specific warranty details, returns, or any product-related inquiries, please refer to the purchase platform or contact LELELINKY customer support directly. Keep your purchase receipt for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FZTJN771

More documents and user manuals: **https://manuals.plus/**