Z ZONAMA SG-508

Z ZONAMA Vacuum Storage Bags with Wireless Rechargeable Air Pump

Model: SG-508

Introduction

Thank you for choosing Z ZONAMA Vacuum Storage Bags with Wireless Rechargeable Air Pump. This system is designed to maximize space in your luggage and home storage by compressing clothing and other soft items. The included portable pump offers convenience and efficiency for both travel and everyday use. Please read this manual carefully to ensure proper use and maintenance of your product.



The Z ZONAMA Vacuum Storage Bags and Wireless Rechargeable Air Pump system.

Package Contents

Your Z ZONAMA Vacuum Storage Bags set includes the following items:

- 8 x Vacuum Storage Bags (in 4 versatile sizes)
- 1 x Travel Wireless Rechargeable Air Pump
- 1 x User Manual (this document)
- 1 x Carrying Pouch (for pump and cable)



All items included in your Z ZONAMA Vacuum Storage Bags package.

Product Features

- **Powerful Cordless Pump:** The Type-C rechargeable pump offers -4500Pa suction, compressing a bag in 10-15 seconds. Its 1500mAh battery can vacuum over 90 bags on a single charge.
- **Compact Design:** The slim and portable pump fits easily into luggage and comes with a carrying pouch for organization.
- **Versatile 4-Size Set:** Includes 8 bags in four sizes (15.75x21.65in, 15.75x23.62in, 19.39x29.53in, 19.69x31.5in) for various storage needs.
- **Durable Bags:** Crafted from extra-thick, tear-resistant PA+PE material for long-lasting reuse. Rounded corners prevent snags.
- **Smart Dual-View Design:** Bags feature a semi-transparent front for privacy and a clear back for easy content identification.
- **Superior Airtight Seal:** Equipped with a reliable double-zipper system and a secure valve to protect items from moisture and odors.



Detailed design features of the Z ZONAMA vacuum storage bags.

Setup

Charging the Wireless Air Pump

1. Locate the Type-C charging port on the side of the wireless air pump.
2. Connect the provided Type-C charging cable to the pump and a suitable USB power source (e.g., wall

adapter, power bank, computer USB port).

3. The LED indicator lights on the pump will illuminate to show charging status. A full charge is indicated when all lights are solid.
4. Ensure the pump is fully charged before first use for optimal performance.



The wireless air pump with its Type-C charging port and LED indicators.

Operating Instructions

Follow these steps to effectively use your vacuum storage bags and pump:

1. **Prepare Items:** Fold your clothes or other soft items neatly. Avoid overfilling the bag; leave enough space for the zipper to close easily.
2. **Fill the Bag:** Place the items inside the vacuum storage bag. For best results, distribute them evenly.
3. **Seal the Zipper:** Use the provided slider to firmly close the double zipper. Ensure the seal is completely airtight by running your fingers along the zipper multiple times.
4. **Open the Valve:** Unscrew the cap from the air valve on the bag.
5. **Vacuum Air:** Place the nozzle of the wireless air pump directly onto the air valve. Press the power button on the pump to start suction. The pump will automatically remove air from the bag.
6. **Monitor Compression:** Watch as the bag compresses. The pump will typically complete suction in 10-

15 seconds. Once the bag is fully compressed, turn off the pump and remove it from the valve.

7. **Close the Valve:** Immediately screw the cap back onto the air valve tightly to prevent air from re-entering.
8. **Store:** Your compressed bag is now ready for storage in your luggage, suitcase, backpack, or closet.

Your browser does not support the video tag.

Watch this video for a demonstration on how to use the ZONAMA Vacuum Bags with Rechargeable Air Pump.



Visual guide for the packing and vacuuming process.

Maintenance

Cleaning the Bags

- Wipe the bags with a damp cloth and mild soap if necessary.
- Do not machine wash or tumble dry the bags.
- Ensure bags are completely dry before storing or reusing.

Pump Care

- Keep the pump dry and clean.
- Store the pump and charging cable in the provided carrying pouch to prevent loss and damage.
- Avoid exposing the pump to extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Bag does not compress or re-inflates	Zipper not fully sealed, valve cap loose, or a hole in the bag.	Ensure the double zipper is completely sealed. Tighten the valve cap. Inspect the bag for any punctures or tears. If a bag is damaged, it may need to be replaced.
Air pump not turning on	Low battery or pump malfunction.	Charge the pump fully using the Type-C cable. If the issue persists after charging, contact customer support.
Slow suction from pump	Low battery or obstruction in the pump nozzle/valve.	Ensure the pump is fully charged. Check the pump nozzle and bag valve for any debris or obstructions.

Specifications

- **Brand:** Z ZONAMA
- **Model Number:** SG-508
- **Material:** PA+PE (Bags)
- **Color:** White Wireless Pump
- **Product Dimensions (Pump):** 7.5"L x 4.4"W x 11"H (approximate package dimensions)
- **Bag Sizes Included:** 15.75x21.65in, 15.75x23.62in, 19.39x29.53in, 19.69x31.5in (2 of each size)
- **Recommended Uses:** Bedding, Clothing (for travel and home storage)
- **Closure Type:** Zipper (Bags)
- **Number of Items:** 8 Bags + 1 Pump
- **Item Weight:** 1.68 pounds (total package)
- **Pump Battery:** 1 Lithium Ion battery (included), 1500mAh
- **Special Features:** Cordless & Type-C Rechargeable Pump, Carrying Pouch, Smart Dual-View Design, Superior Airtight Seal, Versatile 4-Size Set

Warranty and Support

For any questions, concerns, or support needs regarding your Z ZONAMA Vacuum Storage Bags and Wireless Rechargeable Air Pump, please contact our customer service team. We are committed to providing high-quality products and excellent support.

Please refer to your purchase documentation or the seller's information for specific warranty details and contact methods.

© 2026 Z ZONAMA. All rights reserved.