

## LongPlus CDK1-W1X5-B

# LongPlus 5MP 3K Smart Window Camera (CDK1-W1X5-B) Instruction Manual

Model: CDK1-W1X5-B

## 1. PRODUCT OVERVIEW

---

The LongPlus 5MP 3K Smart Window Camera is designed for home security, offering high-resolution video and advanced detection features. This camera is optimized for indoor window installation, providing clear views without glass reflections.

### Key Features:

- **3K 5MP HD Video:** Provides clear and detailed video footage.
- **Blacklight Color Night Vision:** Offers full-color night vision for enhanced visibility in low-light conditions.
- **AI Person/Car Detection:** Intelligently identifies human and vehicle motion, reducing false alerts.
- **Two-Way Talk:** Allows for real-time communication through the camera.
- **Dual-Band Wi-Fi:** Supports both 2.4 GHz and 5.0 GHz Wi-Fi networks for flexible connectivity.
- **24/7 Recording:** Continuous recording with an optional Micro SD card (up to 256GB, not included).



Image: The LongPlus 5MP 3K Smart Window Camera, a compact device designed for indoor security.

## 2. WHAT'S IN THE BOX

---

Please verify that all items are present in the package:

- Window Security Camera
- Quick-mount Bracket
- Charging Cable
- Instruction Manual

## 3. SETUP INSTRUCTIONS

---

Follow these steps to set up your LongPlus Smart Window Camera:

1. **Prepare the Camera:** Unpack the camera and ensure all components are present.
2. **Download the App:** Download the official LongPlus app from your smartphone's app store. Register an account using your phone number or email.
3. **Power On the Camera:** Connect the camera to a power source using the provided charging cable. The camera will announce, "Please use the mobile app to configure the Wi-Fi network." If it does not, press and hold the reset button for 3 seconds.
4. **Mount the Camera:** The camera features a quick-mount bracket with a strong magnetic connection. Clean the desired window surface. Attach the quick-mount bracket to the window, then magnetically attach the camera to the bracket. No drilling is required.
5. **Connect to Wi-Fi:** Follow the in-app instructions to connect the camera to your 2.4 GHz or 5.0 GHz Wi-Fi network.

Your browser does not support the video tag.

Video: A guide demonstrating the connection process for the LongPlus Window Camera.

# Install Effortlessly

No drills, no hassles, install in **60** seconds.

Share up to **5** users.



Image: Visual guide showing the effortless installation of the camera using its magnetic mount and USB power connection.

## Indoor Installation to Avoid Damage

Compared to outdoor dome cameras window cameras are less visible, preventing vandalism and theft. The indoor protection ensures the camera's durability and resistance to extreme weather conditions



Image: Illustrates the benefit of indoor installation for the camera, protecting it from theft, damage, and extreme weather conditions.

## 4. OPERATING INSTRUCTIONS

---

Once your camera is set up, you can utilize its various functions through the LongPlus app:

- **Live View:** Access real-time video streaming from your camera at any time.
- **Two-Way Audio:** Use the microphone and speaker functions within the app to communicate with individuals near the camera.
- **Motion Detection & Alerts:** Enable AI-powered person and car detection to receive instant notifications on your phone when motion is detected. You can customize alert sensitivity and zones.
- **Night Vision:** The camera automatically switches to Blacklight Full Color Night Vision in low-light conditions, providing clear, colored images.
- **Recording:** View recorded footage stored on a Micro SD card (if installed) or through the cloud storage service (7-day trial for new accounts).
- **Sharing Access:** Share camera access with up to 5 family members or friends through the app.

Your browser does not support the video tag.

Video: An overview of the 5MP 3K Window Camera's features for home security.

# Why install indoors?




Image: Compares the camera's Blacklight Full Color Night Vision with traditional starlight color and infrared black-and-white night vision, highlighting improved clarity.

## Phone Push Sound Alarm

The window camera uses AI-powered human and vehicle shape detection. If it detects a break-in, it will send a notification to your phone. Phone can control the camera to sound an alarm to scare off thieves



Image: Demonstrates the phone push sound alarm feature, where the camera sends notifications upon detection and can sound an alarm.

# More Vivid and Wide Angle View



**LongPlus**

Anti- Glare & Anti- Reflection AI-enhanced clarity



Image: Shows the camera's 118-degree wide-angle view with anti-glare and anti-reflection technology, providing a broader and clearer perspective compared to standard cameras.

## 5. MAINTENANCE

To ensure optimal performance and longevity of your camera:

- **Clean the Lens:** Gently wipe the camera lens with a soft, dry cloth to remove dust or smudges. Avoid abrasive cleaners.
- **Check Power Connection:** Ensure the charging cable is securely connected to the camera and power source.
- **Software Updates:** Regularly check the LongPlus app for available firmware updates to ensure your camera has the latest features and security enhancements.

- **Storage Management:** If using a Micro SD card, periodically review and manage stored footage to prevent the card from becoming full.

## 6. TROUBLESHOOTING

---

If you encounter issues with your camera, refer to the following common solutions:

- **Camera Not Connecting to Wi-Fi:**
  - Ensure your Wi-Fi network is 2.4 GHz or 5.0 GHz.
  - Verify the Wi-Fi password is correct.
  - Move the camera closer to your Wi-Fi router.
  - Reset the camera by pressing and holding the reset button for 3 seconds, then attempt to reconnect via the app.
- **No Notifications:**
  - Check app notification settings on your phone and within the LongPlus app.
  - Ensure motion detection is enabled and configured correctly in the app.
- **Poor Video Quality:**
  - Ensure the camera lens is clean.
  - Check your internet connection speed.
  - Adjust video quality settings in the app if available.
- **SD Card Not Recording:**
  - Ensure the Micro SD card is inserted correctly.
  - Verify the SD card is formatted correctly (usually FAT32).
  - Check if the SD card has sufficient storage space.
  - The camera supports up to 256GB Micro SD cards.

## 7. PRODUCT SPECIFICATIONS

---

Feature	Specification
Brand	LongPlus
Model Name	CDK1-W1X5-B
Connectivity Technology	Wired (Power), Wireless (Wi-Fi)
Special Features	2-Way Audio, 3K 5MP Color Night Vision, AI Motion Detection, Local Recording
Indoor/Outdoor Usage	Indoor
Compatible Devices	Smartphone
Controller Type	APP
Mount Type	Window Mount
Color	White

Enclosure Material	Acrylonitrile Butadiene Styrene (ABS)
Alert Type	Audio and Motion
Effective Still Resolution	5 MP
Photo Sensor Resolution	5 MP
Control Method	App
Power Source	Corded Electric (5 Volts)
Video Capture Format	MP4
Night Vision Range	33 Feet
Night Vision Type	Night Color
Flash Memory Type	Micro SD
Max Flash Memory Supported	512 GB
Video Capture Resolution	3K, 5MP
Frame Rate	Maximum 15fps
Viewing Angle	118 Degrees
Item Dimensions	2.1 x 2.5 x 1.2 inches

## 8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the official LongPlus website or contact their customer service directly. Keep your purchase receipt for warranty claims.