Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Decofy DC-BG07

Decofy Farmhouse Nightstand with Charging Station (Model: DC-BG07)

Instruction Manual

Overview Safety Package
Contents Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

1. Product Overview

The Decofy Farmhouse Nightstand is designed to provide convenient storage and charging capabilities for your bedroom or living space. This set includes two nightstands, each featuring a smart charging hub, a deep drawer, and an open bottom shelf. Its versatile design complements various decor styles.



Image 1.1: Two Decofy Farmhouse Nightstands in a bedroom setting.

2. Safety Information

- **Weight Capacity:** Do not exceed the maximum weight capacity for the tabletop (100 lbs / 45.4 kg), drawer (20 lbs / 9.1 kg), and open shelf (12 lbs / 5.4 kg). Overloading can cause instability and damage.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened securely before use. Loose connections can lead to structural failure.
- **Placement:** Place the nightstand on a flat, stable surface to prevent tipping.

- **Electrical Safety:** The integrated charging station is designed for standard use. Do not overload the outlets. Avoid exposing the charging station to liquids. Disconnect from power before cleaning or if any damage occurs.
- **Children and Pets:** Keep small parts and assembly tools away from children and pets. Do not allow children to climb on or play with the nightstand.



Image 2.1: Nightstand dimensions and weight capacities.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact

customer support.

Included Items (per nightstand):

- Nightstand Panels (various pieces for frame, drawer, shelf)
- Hardware Pack (screws, dowels, cam locks, drawer slides, handle)
- Charging Station Unit (with 2 AC outlets, 1 USB port, 1 Type-C port, and power cord)
- Assembly Guide
- Small Screwdriver (for assembly)

4. Setup and Assembly

Assembly is required for this product. Please follow the step-by-step instructions provided in the included assembly guide. All parts are pre-drilled and labeled for ease of installation. A screwdriver is recommended for assembly.

General Assembly Steps:

1. **Unpack:** Carefully remove all components from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Identify Parts:** Match each part to the corresponding labels in the assembly guide.
3. **Assemble Frame:** Connect the side panels, top, and bottom using the provided hardware. Ensure all connections are snug.
4. **Install Drawer:** Assemble the drawer components and install the drawer slides onto both the drawer and the nightstand frame.
5. **Integrate Charging Station:** Secure the charging station unit into the designated cutout on the top panel.
6. **Final Checks:** Verify all screws and fasteners are tightened. Place the nightstand in its desired location.

Your browser does not support the video tag.

Video 4.1: Official Decofy video demonstrating bedside table solutions, including assembly and features.

5. Operating Instructions

5.1. Smart Charging Hub

The nightstand is equipped with a built-in charging station to power your electronic devices.

- **Power Connection:** Plug the nightstand's power cord into a standard wall outlet.
- **Outlets:** Use the two standard AC outlets (125V-12A) for lamps, alarm clocks, or other small appliances.
- **USB Ports:** Utilize the 1 USB port (5V-2A) and 1 Type-C port (5V-2A) to charge smartphones, tablets, headphones, and other compatible devices.
- **Cable Management:** The design helps organize cables, reducing clutter on your tabletop.



Image 5.1: Detail of the built-in charging station.

5.2. Storage Features

The nightstand offers ample storage to keep your essentials organized.

- **Deep Drawer:** The smooth-sliding drawer (11.8"D x 13.6"W x 3.9"H) is ideal for storing remotes, personal items, or skincare products, keeping them out of sight.
- **Open Shelf:** The open bottom shelf provides easy access storage for books, magazines, or decorative items. It can also accommodate storage baskets for additional organization.




Image 5.2: The deep drawer with smooth slides and easy-grip handle.

6. Maintenance

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining or damage to the engineered wood.
- **Dusting:** Regularly dust with a dry, soft cloth to maintain appearance.
- **Fasteners:** Periodically check and tighten all screws and fasteners to ensure the nightstand remains stable.

- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.

7. Troubleshooting

Problem	Possible Cause	Solution
Nightstand is wobbly.	Loose fasteners; uneven floor.	Tighten all assembly screws. Ensure the nightstand is on a level surface. Use furniture pads if necessary.
Drawer does not slide smoothly or falls.	Incorrect drawer slide installation; obstruction; damaged slides.	Review assembly instructions for drawer slide installation. Check for any obstructions. If slides are damaged, contact customer support for replacements.
Charging station not working.	Not plugged in; power outage; faulty device; charging station issue.	Ensure the nightstand's power cord is securely plugged into a working wall outlet. Test with a different device. If issues persist, contact customer support.
Surface damage (chips, scratches).	Impact; abrasive cleaning; heavy objects.	Use furniture markers or repair kits for minor damage. Use coasters and avoid dragging objects across the surface.

8. Specifications

Brand: Decofy

Model Name: DC-BG07

Product Dimensions: 15.7"D x 17.7"W x 23.6"H (40cm D x 45cm W x 60cm H)

Item Weight: Approximately 38.4 pounds (per nightstand)

Material: Engineered Wood

Color: Walnut

Number of Drawers: 1 (per nightstand)

Charging Station:

- 2 Standard AC Outlets (125V-12A)
- 1 USB Port (5V-2A)
- 1 Type-C Port (5V-2A)
- Power Cord Length: 4.9 Feet

Weight Capacity:

- Tabletop: 100 lbs (45.4 kg)
- Drawer: 20 lbs (9.1 kg)
- Open Shelf: 12 lbs (5.4 kg)

Assembly Required: Yes (Tools Recommended: Screwdriver)

9. Warranty Information

For detailed warranty information, please refer to the documentation included with your purchase or contact Decofy

customer support directly. Warranty terms typically cover manufacturing defects and material flaws under normal use.

10. Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Decofy customer support.

Brand: Decofy

Online Support: Visit the official Decofy store on Amazon for FAQs and contact options:Decofy Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FZV88F9Y

More documents and user manuals: **https://manuals.plus/**