Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LINSY 8-Drawer Dresser, 15.7''D x 47''W x 43.6''H

LINSY Fluted Dresser for Bedroom with 8 Drawers

Model: Oak, 15.7"D x 47"W x 43.6"H (8 Drawers)

Brand: LINSY

1. Product Overview

The LINSY Fluted Dresser is designed to provide ample storage and a modern aesthetic for your bedroom, living room, or entryway. This 8-drawer model features a fluted panel design, gold metal handles, and sturdy construction for lasting use.



Image 1.1: The LINSY Fluted Dresser, showcasing its design and finish.

Your browser does not support the video tag.

Video 1.1: An overview of the LINSY Fluted Dresser for Bedroom, highlighting its features and aesthetic.

2. Product Specifications

Brand	LINSY
Material	Engineered Wood
Finish Type	Engineered Wood
Product Dimensions (D x W x H)	15.7" x 47" x 43.6"
Number of Drawers	8
Item Weight	134 Pounds

Color	Oak
Mounting Type	Floor Mount
Additional Features	Fluted Panel
Required Assembly	Yes



Image 2.1: Visual representation of the dresser's dimensions.

3. Safety Information

Your safety is paramount. Please adhere to the following guidelines:

- This dresser meets the latest ASTM 2057-2023 safety standards.
- Always use the provided anti-tip device to secure the dresser to a wall. This prevents accidental overturning, especially in households with children.
- Ensure all screws and fasteners are tightened securely during assembly and periodically check for looseness.
- Do not allow children to climb on the dresser or hang from the drawers.
- Place the dresser on a level surface to ensure stability.
- The dresser features smooth rounded edges and wide metal handles for enhanced safety.



Image 3.1: Instructions for installing the anti-tip device to secure the dresser to the wall.

4. Setup and Assembly

Assembly is required for this product. Please follow the step-by-step instructions carefully. It is recommended to have assistance for certain steps due to the item's weight.

- Unpack all components and verify against the parts list (refer to your included manual for a complete list).
- Lay out all parts on a soft, clean surface to prevent scratches.
- Use the provided tools or your own screwdriver and hammer for assembly.
- The dresser will be delivered in two separate packages, which may not arrive on the same day. Ensure both packages are received before starting assembly.

Your browser does not support the video tag.

Video 4.1: A detailed step-by-step installation video for the LINSY Fluted Dresser.

Key Assembly Steps:

1. **Prepare Drawer Slides:** Attach the drawer slides to the side panels of the drawers using the provided screws.
2. **Assemble Drawer Boxes:** Connect the drawer side panels to form the drawer boxes.
3. **Install Drawer Fronts:** Secure the fluted drawer fronts to the assembled drawer boxes.
4. **Attach Legs and Base:** Fasten the solid wood legs and the base support to the bottom panel of the dresser frame.
5. **Construct Main Frame:** Assemble the side and middle panels of the dresser frame.
6. **Secure Back Panel:** Attach the back panel to the dresser frame.
7. **Insert Drawers:** Carefully slide the assembled drawers into their respective tracks within the dresser frame.
8. **Install Anti-Tip Device:** Follow the instructions in the safety section to install the anti-tip device.



Image 4.2: Detail of the sturdy leg bracket for enhanced stability.

5. Operating Instructions

Drawer Use:

The dresser features high-quality slide rails for smooth drawer operation. To open a drawer, gently pull the gold metal handle. To close, push the drawer firmly until it is fully seated.

- Avoid forcing drawers open or closed if they encounter resistance.
- Distribute weight evenly within drawers to prevent strain on the slides.
- The drawers are designed for clothing, accessories, and personal items.




Image 5.1: Interior view of a drawer, demonstrating storage capacity and smooth operation.



Image 5.2: A drawer opened to show its internal capacity and organization possibilities.

6. Maintenance

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the engineered wood. The tabletop is designed to be waterproof and easy to clean.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.
- **Humidity:** Maintain a stable room temperature and humidity level to prevent warping or cracking.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten as necessary.

7. Troubleshooting

If you encounter any issues with your dresser, please refer to the following common solutions:

- **Drawers not closing smoothly:**
  - Check if the drawer slides are properly aligned and free of obstructions.
  - Ensure the drawer box is assembled correctly and not warped.
  - Verify that all screws securing the slides to both the drawer and the frame are tight.
- **Dresser feels unstable:**
  - Confirm that the dresser is placed on a flat, level surface.
  - Ensure all leg attachments and frame screws are securely tightened.
  - Verify the anti-tip device is correctly installed and anchored to the wall.
- **Lingering odor:**
  - New furniture may have a slight odor. Allow for adequate ventilation in the room for several days.
- **Damaged parts upon arrival:**
  - If any parts are damaged, contact customer support immediately for replacement.

8. Warranty and Support

This product is covered by a 30-day easy return policy through Amazon. For any assembly assistance, missing parts, or other inquiries, our friendly support team is available to help. Please contact us for a solution within 24 hours.
For further assistance, please visit the LINSY Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FZW6JF74

More documents and user manuals: **https://manuals.plus/**