Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OYLUS CE0233

OYLUS CE0233 Smart Countertop Nugget Ice Maker User Manual

Model: CE0233

1. Introduction

Thank you for choosing the OYLUS CE0233 Smart Countertop Nugget Ice Maker. This appliance is designed to provide high-quality, chewable nugget ice quickly and efficiently. Please read this manual thoroughly before operating your ice maker to ensure safe and optimal performance. Keep this manual for future reference.

Key Features:

- **Fast Ice Production:** Produces nugget ice in approximately 4 minutes.
- **High Capacity:** Up to 26 pounds of ice per 24 hours.
- **Chewable Nugget Ice:** Soft, crushed pebble ice that melts slowly.
- **Intuitive LCD Panel:** Touchscreen display with "Ice Full" and "Add Water" alerts.
- **Smart Scheduling:** Flexible delay start options (1/2/4/6/8 hours).
- **Self-Cleaning Function:** One-touch activation for easy maintenance.
- **Compact Design:** Space-saving dimensions (6.9"D x 13"W x 14.3"H) for versatile placement.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using this appliance:

- Read all instructions before use.
- Do not touch cold surfaces with wet hands.
- Ensure the appliance is properly grounded.
- Do not immerse the power cord, plug, or appliance in water or other liquids.
- Unplug the appliance before cleaning or when not in use.
- Do not operate any appliance with a damaged cord or plug.

- Use only potable water.
- Keep the appliance away from heat sources and direct sunlight.
- Ensure adequate ventilation around the unit (at least 6 inches clearance on all sides).
- This appliance is for household use only.

3. Package Contents

Verify that all items are included in your package:

- OYLUS CE0233 Nugget Ice Maker
- Ice Tongs
- Ice Scoop
- User Manual

4. Product Overview

Familiarize yourself with the components of your ice maker:



Figure 1: OYLUS CE0233 Nugget Ice Maker - Front View



Figure 2: Elite-Grade Design Features

- **LCD Touchscreen Display:** Located on the top panel, displays status and controls.
- **Viewing Window:** Transparent window on the front door to monitor ice production.
- **Ice Basket:** Removable basket inside the unit to collect produced ice.
- **Water Reservoir:** Located beneath the ice basket, holds water for ice production.
- **Drain Plug:** Located at the bottom of the unit for water drainage.
- **Air Vents:** Located on the sides for heat dissipation.

5. Setup

1. **Unpack:** Carefully remove the ice maker from its packaging. Remove all packing materials, including any tape or protective films.
2. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is at least 6 inches of clearance around the unit for proper ventilation.
3. **Initial Cleaning:** Before first use, perform a self-cleaning cycle. Fill the water reservoir with clean water up to the MAX line. Press the "Clean" button on the LCD panel. The cycle typically runs for 5-7 minutes. After the cycle, drain the water using the drain plug at the bottom and wipe the interior dry.
4. **Add Water:** Open the top lid and remove the ice basket. Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.

6. Operating Instructions



Figure 3: Intuitive Touchscreen LCD Display

1. **Power On:** Plug the ice maker into a grounded electrical outlet. Press the power button ⏻ on the LCD panel to turn on the unit.
2. **Start Ice Making:** Once powered on and water is added, the ice maker will automatically begin the ice-making cycle. The "Ice Making" indicator will illuminate. The first batch of ice will be ready in approximately 4 minutes.
3. **Ice Full Alert:** When the ice basket is full, the "Ice Full" indicator will light up, and the ice maker will pause production. Remove ice to resume production.
4. **Add Water Alert:** If the water level in the reservoir is too low, the "Add Water" indicator will light up. Add more water to the reservoir to continue ice production.

5. **Timer Function:** To schedule ice production, press the timer button () and select your desired delay start time (1/2/4/6/8 hours). The ice maker will start production after the set delay.
6. **Internal Light:** Press the light button () to turn the internal light on or off, allowing you to easily check ice levels.

7. Maintenance



Figure 4: Self-Cleaning in Progress

1. **Self-Cleaning:** To activate the self-cleaning mode, ensure the water reservoir is filled. Press the "Clean" button (↻) on the LCD panel. The cycle runs for approximately 5 minutes, circulating water to clean the internal components.
2. **Draining Water:** After a cleaning cycle or when storing the unit, drain all water from the reservoir. Locate the drain plug at the bottom of the ice maker, remove it, and allow the water to flow out. Replace the plug securely.
3. **Regular Cleaning:** Regularly wipe down the interior and exterior of the ice maker with a soft, damp cloth. For thorough cleaning, remove the ice basket and wash it with mild soap and water.
4. **Descaling:** If mineral deposits build up, use a descaling solution (e.g., citric acid descaling powder) as per the product instructions. Follow the self-cleaning steps with the descaling solution, then run several cycles with fresh water to rinse thoroughly.

8. Troubleshooting

Problem	Possible Cause	Solution
Ice maker not turning on	No power	Ensure the power cord is securely plugged into a grounded outlet. Check the circuit breaker.
"Add Water" indicator is on	Low water level	Add potable water to the reservoir up to the MAX line.
"Ice Full" indicator is on	Ice basket is full	Remove ice from the basket. Production will resume automatically.
No ice production	Insufficient water, high ambient temperature, or unit malfunction	Check water level. Ensure unit is in a cool, well-ventilated area. Contact customer support if problem persists.
Ice melts too quickly	High ambient temperature, lid not closed properly	Ensure the unit is in a cool environment. Close the lid securely. The ice maker is not a freezer; transfer ice to a freezer for long-term storage.
Unusual noise	Normal operation sounds (compressor, water pump, ice dropping) or obstruction	Some operational noise is normal. Check for any obstructions in the ice-making area. If noise is excessive or unusual, contact support.
Water leakage	Loose drain plug, cracked reservoir, or overfilling	Ensure the drain plug is tightly secured. Do not overfill the water reservoir. Inspect the reservoir for damage.

9. Specifications

Attribute	Value
Brand	OYLUS
Model Name	CE0233
Product Dimensions	6.9"D x 13"W x 14.3"H (19.2 Pounds)
Capacity	26 Pounds (per 24 hours)
Wattage	220 watts
ASIN	B0G11XSD2P
Manufacturer	OYLUS

10. Official Product Videos

Your browser does not support the video tag.

Video 1: Oylus Home Use Compact Nugget Ice Maker. This video demonstrates the compact size and ease of use of the OYLUS nugget ice maker in a home setting.

Your browser does not support the video tag.

Video 2: Oylus Nugget Ice Maker Countertop. This video highlights the countertop placement and features of the OYLUS nugget ice maker.

11. Warranty and Support

The OYLUS CE0233 Smart Countertop Nugget Ice Maker comes with a standard manufacturer's warranty. For detailed warranty information, product support, or troubleshooting assistance not covered in this manual, please refer to the contact information provided with your purchase or visit the official OYLUS website.

© 2025 OYLUS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G11XSD2P

More documents and user manuals: **https://manuals.plus/**