

[Manuals.plus](#) /

> [ocioc](#) /

> ocioc 44-inch Ceiling Fan with Lights and Remote (Model 90141) Instruction Manual

ocioc 90141

ocioc 44-inch Ceiling Fan with Lights and Remote

Model: 90141

INTRODUCTION

Thank you for choosing the ocioc 44-inch Ceiling Fan with Lights and Remote. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before beginning installation and retain them for future reference.



Image: The ocioc 44-inch ceiling fan, highlighting its dimmable light, 6-speed air flow, timer setting, reversible motor, remote control, and easy installation features.

SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Read all instructions before installing the fan.
- Ensure the installation site is structurally sound and can support the fan's weight (at least 35 lbs).
- All wiring must be in accordance with national and local electrical codes. Consult a qualified electrician if you are unsure.
- Disconnect power at the circuit breaker or fuse box before installation or servicing.

- Do not operate the fan with damaged blades or any visible defects.
- Keep hands, clothing, and other objects clear of the fan blades when the fan is in operation.
- This fan is suitable for indoor and covered outdoor use. Do not expose to direct water spray.

PACKAGE CONTENTS

Verify that all components listed below are included in your package:

- Ceiling Fan Motor Assembly
- Fan Blades (5x ABS Plastic)
- Integrated LED Light Kit
- Remote Control with Wall Mount
- Mounting Bracket
- Downrod (if applicable, for flush mount this is minimal)
- Hardware Pack (screws, wire nuts, washers)
- Instruction Manual

SPECIFICATIONS

Brand	ocioc
Model Number	90141
Size	44 inch
Color	Black
Product Dimensions	44"D x 44"W x 9"H
Material	Metal, Plastic (ABS Blades)
Motor Type	DC Reversible Motor
Number of Blades	5
Number of Speeds	6
Noise Level	28 Decibels
Wattage	45 watts
Voltage	120 Volts (AC)
Light Kit	Integrated LED, 3 Color Temperature (3000K, 4000K, 6500K), Dimmable
Control Method	Remote Control
Installation Type	Flush Mount
Indoor/Outdoor Usage	Indoor, Covered Outdoor

SETUP AND INSTALLATION

Before you begin: Ensure power is OFF at the circuit breaker. Read all safety warnings.

1. Mounting the Bracket

1. Secure the mounting bracket to the ceiling junction box using the provided screws and washers. Ensure the junction box is rated for ceiling fan support.
2. The mounting bracket includes hooks to temporarily hold the fan motor during wiring, simplifying installation.

2. Attaching Fan Blades

Carefully attach each of the five ABS fan blades to the motor housing using the screws provided. Ensure they are securely fastened.



Image: Diagram showing the correct method to fix fan blades to the motor, emphasizing that reversed installation can cause friction and noise.

3. Wiring the Fan

1. Hang the fan motor assembly onto the hooks of the mounting bracket.
2. Connect the fan's electrical wires to the household wiring according to the wiring diagram in the full manual. Typically, this involves connecting live, neutral, and ground wires. Use wire nuts to secure connections.

4. Securing the Fan

1. Once wiring is complete, carefully lift the fan and align it with the mounting bracket.
2. Secure the fan to the bracket using the remaining screws. Ensure all connections are tight and the fan is stable.

5. Installing the Light Kit

Connect the wires for the integrated LED light kit and secure the light cover to the fan motor housing. Ensure it is firmly attached.




Image: Detailed view of the ocioc ceiling fan's CCT LED integrated light kit, DC motor, ABS fan blades, 5-blade design, and the remote control.

OPERATING INSTRUCTIONS

Your ocioc ceiling fan is operated via the included remote control.

Remote Control Functions:

- **Power ON/OFF:** Turns the fan and light on or off.
- **Fan Speed:** Select from 6 fan speeds. Speeds 1-2 provide a soft breeze, 3-4 a comfortable wind, and 5-6 a strong cooling airflow.
- **Light ON/OFF:** Controls the integrated LED light independently.
- **Color Temperature (CCT) Adjustment:** Cycle through 3 color temperatures: Warm Light (3000K), Natural Light (4000K), and Cool White (6500K).
- **Dimming:** Adjust the brightness of the LED light from 10% to 100%.
- **Timer:** Set the fan to turn off automatically after 2, 4, or 8 hours.
- **Reversible Motor:** Change the direction of blade rotation for seasonal use.



Image: Illustration demonstrating the three color temperature options (3000K Warm White, 4000K Natural White, 6500K Cool White) available for the fan's integrated LED light.




Image: Visual representation of the dimmable light feature, showing brightness levels from 10% to 100%.

Reversible Motor Function:

The DC reversible motor allows for year-round comfort:

- **Summer Mode (Clockwise):** Pushes air downwards, creating a cooling breeze.
- **Winter Mode (Counter-clockwise):** Draws air upwards, circulating warm air trapped near the ceiling to balance indoor heating.



Image: Diagram illustrating the reversible DC motor, showing clockwise rotation for summer cooling and counter-clockwise rotation for winter heat circulation.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Dust the fan blades and motor housing periodically with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Blade Inspection:** Check fan blades for any cracks or damage. Replace damaged blades immediately.
- **Tightness:** Periodically check all screws and connections to ensure they are secure.
- **Light Kit:** The LED light kit is integrated and designed for long life. No bulb replacement is necessary.

TROUBLESHOOTING

If you encounter issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power; Loose wiring; Remote control issue	Check circuit breaker; Verify all wire connections; Replace remote batteries or re-pair remote.
Light does not work	Loose wiring; Remote control issue	Check light kit wiring; Replace remote batteries or re-pair remote.
Fan makes noise	Loose screws; Unbalanced blades; Reversed blade installation	Tighten all mounting screws; Ensure blades are balanced and correctly installed (refer to installation section).
Remote not responding	Dead batteries; Not paired correctly	Replace batteries; Refer to the full manual for remote pairing instructions.

If problems persist after attempting these solutions, please contact customer support.

WARRANTY AND SUPPORT

Your ocioc 44-inch Ceiling Fan comes with a **5-year worry-free warranty**. Additionally, we offer a **lifetime motor replacement service**. Should any accessories be damaged within 5 years of purchase, free replacements are available. For technical assistance, warranty claims, or to order replacement parts, please contact ocioc customer support through the retailer's platform or the official ocioc website. Please have your model number (90141) and purchase date ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question