

[Manuals.plus](#) /

› [Genérico](#) /

› Genérico JT-8695 Outdoor Security Camera User Manual

Genérico JT-8695

Genérico JT-8695 Outdoor Security Camera User Manual

Model: JT-8695

1. INTRODUCTION

Thank you for choosing the Genérico JT-8695 Outdoor Security Camera. This manual provides essential information for the proper installation, operation, and maintenance of your device. The JT-8695 features dual lenses, 4MP HD resolution, Wi-Fi connectivity, color night vision, two-way audio, and advanced motion detection with automatic tracking, making it ideal for comprehensive outdoor surveillance.

Please read this manual thoroughly before using the camera to ensure optimal performance and safety.

2. WHAT'S IN THE BOX

- 1 x Genérico JT-8695 Security Camera with Mounting Bracket
- 1 x Power Adapter (Bivolt 110V-220V)
- 1 x Installation Kit (screws, wall anchors, etc.)
- 1 x User Manual



Image of the Genérico JT-8695 outdoor security camera, showing its dual lens design and weatherproof casing.

3. SETUP

3.1 Physical Installation

1. Choose a suitable outdoor location for the camera, ensuring a clear field of view and access to a power outlet.
2. Use the provided mounting bracket and installation kit (screws, wall anchors) to securely attach the camera to the desired surface.
3. Adjust the camera's physical orientation as needed before final tightening.

3.2 Power Connection

- Connect the provided power adapter to the camera's power input.
- Plug the power adapter into a standard electrical outlet (110V-220V). The camera will power on and initiate its startup sequence.

3.3 App and Wi-Fi Configuration

1. Download the 'Yoosee' app from your smartphone's app store (iOS or Android).
2. Register for a new account or log in if you already have one.
3. Follow the in-app instructions to add your new camera. This typically involves scanning a QR code on the camera or manually entering its ID.
4. Connect the camera to your 2.4GHz Wi-Fi network.**Note: The camera does not support 5GHz Wi-Fi networks.**
5. Once connected, you will be able to view the live feed and control the camera through the Yoosee app.

3.4 SD Card Installation (Optional)

- Locate the SD card slot on the camera (refer to the camera diagram if available).
- Insert a microSD card (up to 128GB, not included) into the slot with the contacts facing the correct direction.
- Format the SD card through the Yoosee app settings for proper recording functionality.

4. OPERATING THE CAMERA

4.1 Live View and Remote Access

- Open the Yoosee app on your smartphone.
- Select your camera from the device list to access the live video feed.
- The camera supports P2P technology, allowing remote viewing from anywhere with an internet connection.

4.2 Pan and Tilt Control

- Within the live view interface of the Yoosee app, use the directional controls to rotate the camera.
- The camera offers 320° horizontal and 90° vertical rotation.

4.3 Motion Detection and Auto-Tracking

- Enable motion detection in the app settings.
- When motion is detected, the camera can automatically track the moving object and send real-time notifications to your smartphone.

4.4 Two-Way Audio

- The built-in microphone and speaker allow for two-way communication.
- Tap the microphone icon in the app to speak through the camera, and listen through your phone.

4.5 Color Night Vision

- The camera automatically switches to color night vision in low-light conditions, providing clear and detailed images even in the dark.

4.6 Recording and Storage

- Recordings can be stored on a local microSD card (up to 128GB) or optionally on cloud storage (subscription may be required).
- Access recorded footage through the Yoosee app's playback feature.

4.7 User Sharing

- You can share access to your camera with multiple users through the Yoosee app, allowing family members or trusted individuals to view the feed.

5. MAINTENANCE

5.1 Cleaning

- Periodically clean the camera lens and housing with a soft, damp cloth.
- Do not use harsh chemicals or abrasive cleaners, as these can damage the camera's weatherproof coating or lens.
- Ensure the camera is powered off before cleaning.

5.2 Firmware Updates

- Check the Yoosee app regularly for available firmware updates.
- Updating the firmware can improve performance, add new features, and enhance security. Follow the in-app instructions carefully during updates.

5.3 SD Card Management

- If using an SD card for storage, periodically check its status in the app.
- Format the SD card occasionally to maintain optimal recording performance.

6. TROUBLESHOOTING

6.1 Camera Not Powering On

- Check if the power adapter is securely connected to both the camera and the power outlet.
- Verify that the power outlet is functional by plugging in another device.

6.2 Unable to Connect to Wi-Fi

- Ensure your Wi-Fi network is 2.4GHz. The camera does not support 5GHz networks.
- Check your Wi-Fi password for accuracy.
- Move the camera closer to your Wi-Fi router to improve signal strength.
- Restart your Wi-Fi router and the camera.

6.3 Poor Image Quality

- Clean the camera lens for any dirt or smudges.
- Ensure there are no obstructions in the camera's field of view.
- Check your internet connection speed; a slow connection can affect streaming quality.

6.4 App Not Responding

- Close and restart the Yoosee app.
- Check for app updates in your smartphone's app store.
- Ensure your smartphone has a stable internet connection.

7. SPECIFICATIONS

Feature	Specification
Model Number	JT-8695 (Internal Model: Jt-8293)
Brand	Genérico
Video Capture Resolution	1080p (4MP HD)
Connectivity Protocol	Wi-Fi (2.4GHz only), Ethernet
Power Source	Wired Electric (Bivolt 110V-220V)
Indoor/Outdoor Environment	Outdoor
Pan/Tilt Rotation	320° Horizontal / 90° Vertical
Storage Options	MicroSD Card (up to 128GB), Cloud Storage (optional)
Included Components	Mounting screws
Item Dimensions (L x W x H)	10 x 10 x 16 cm

Manufacturer	DURAWELL
--------------	----------

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your purchase receipt as proof of purchase.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0G168HKPH>

More documents and user manuals: <https://manuals.plus/>