

MZK ET1712-BY-3

MZK ET1712-BY-3 3-in-1 Electric Leaf Blower, Vacuum, and Mulcher User Manual

Model: ET1712-BY-3 | Brand: MZK

1. INTRODUCTION

Thank you for choosing the MZK ET1712-BY-3 3-in-1 Electric Leaf Blower, Vacuum, and Mulcher. This versatile tool is designed to simplify your yard cleanup tasks by combining three essential functions: blowing, vacuuming, and mulching leaves and light debris. Please read this manual carefully before operating the device to ensure safe and efficient use. Keep this manual for future reference.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury. Failure to follow these instructions may result in serious injury or property damage.

- **Read All Instructions:** Familiarize yourself with the controls and proper use of the appliance.
- **Wear Eye and Ear Protection:** Always wear safety glasses or goggles and ear protection when operating the tool.
- **Dress Properly:** Do not wear loose clothing or jewelry that could get caught in moving parts. Wear sturdy footwear.
- **Keep Area Clear:** Ensure the work area is clear of bystanders, children, and pets.
- **Inspect Before Use:** Check for damaged parts, loose connections, or any other condition that may affect operation.
- **Avoid Wet Conditions:** Do not operate the tool in wet conditions or rain.
- **Unplug When Not in Use:** Disconnect the power cord from the outlet before making adjustments, changing accessories, or storing the tool.
- **Use Proper Extension Cord:** Ensure the extension cord is suitable for outdoor use and has adequate gauge for the tool's power requirements.

3. PRODUCT COMPONENTS

The MZK ET1712-BY-3 includes the following main components:

- Main Motor Unit

- Blower Tube
- Vacuum Tube
- Leaf Collection Bag (40L capacity)
- Ergonomic Handle
- Easy Roll Wheels
- Mode Switch (Blower/Vacuum)



Figure 1: Overview of the MZK 3-in-1 Electric Leaf Blower, Vacuum, and Mulcher.



Figure 2: The device demonstrating its three functions: blowing, vacuuming, and mulching.

4. SETUP AND ASSEMBLY

Follow these steps to assemble your MZK 3-in-1 tool:

1. **Attach Blower Tube:** Align the blower tube with the outlet on the main motor unit and twist until it locks securely into place.
2. **Attach Vacuum Tube (for vacuum/mulcher mode):** Remove the blower tube. Align the vacuum tube with the intake opening on the main motor unit and twist until it locks. Ensure the leaf collection bag is properly attached to the exhaust port.
3. **Attach Leaf Collection Bag:** Securely attach the 40L leaf collection bag to the exhaust port of the main unit. Ensure the zipper is closed before operation.
4. **Connect Power:** Plug the corded blower into a suitable outdoor extension cord, then plug the extension cord into a grounded electrical outlet.



LARGE 40L LEAF COLLECTION BAG

Figure 3: Proper attachment of the 40L leaf collection bag.

5. OPERATING INSTRUCTIONS

5.1. Blower Mode

To use the device as a leaf blower:

1. Ensure the blower tube is securely attached.
2. Set the mode switch to "Blower".
3. Point the blower tube away from yourself and others.
4. Press the power button to start the motor.
5. Sweep the blower from side to side to move leaves and debris into piles.



Figure 4: Operating the MZK tool in blower mode.

5.2. Vacuum and Mulcher Mode

To use the device for vacuuming and mulching leaves:

1. Ensure the vacuum tube and leaf collection bag are securely attached.
2. Set the mode switch to "Vacuum".
3. Hold the tool with the vacuum tube close to the ground, hovering over the leaves.
4. Press the power button to start the motor. The leaves will be drawn into the vacuum, mulched, and collected in the bag.
5. Empty the collection bag when full.

MZK

ERGONOMIC HANDLE



Figure 5: The 40L leaf collection bag and the 15:1 mulching ratio feature.

MZK



15:1 MULCH RATIO



TURN **15** BAGS OF LEAVES INTO 1

Figure 6: Visual representation of the 15:1 mulch ratio.

5.3. Quick Mode Switch

The tool features a quick mode switch for seamless transition between blower and vacuum functions. No tools are required to change modes.



Figure 7: The quick mode switch for changing between blower and vacuum functions.

6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your tool.

- **Cleaning:** After each use, unplug the tool and clean the exterior with a damp cloth. Remove any debris from the blower/vacuum tubes and the impeller area.
- **Collection Bag:** Empty and clean the leaf collection bag regularly. Inspect for tears or damage.
- **Storage:** Store the tool in a dry, secure location, out of reach of children.
- **Inspection:** Periodically check all screws, nuts, and bolts for tightness.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Tool does not start.	No power supply. Power button not pressed.	Check power cord connection and outlet. Ensure power button is fully engaged.
Reduced airflow/suction.	Tubes or impeller clogged. Collection bag full.	Unplug and clear any blockages. Empty the collection bag.
Excessive vibration.	Loose components. Debris in impeller.	Check all connections and tighten. Unplug and clear impeller area.

8. SPECIFICATIONS

Feature	Detail
Brand	MZK

Feature	Detail
Model Name	ET1712-BY-3
Power Source	AC Corded Electric
Air Volume (Blower)	Up to 400 CFM (Cubic Feet per Minute)
Wind Speed (Blower)	Up to 350 km/h (approx. 217 MPH)
Mulch Ratio	15:1
Collection Bag Capacity	40 Liters
Product Dimensions	18"L x 6"W x 15"H
Item Weight	7.45 pounds

9. CUSTOMER SUPPORT

If you have any questions, require assistance, or encounter issues with your MZK 3-in-1 Electric Leaf Blower, Vacuum, and Mulcher, please contact our customer support team. Refer to your product packaging or the MZK official website for contact details.

Our support team is ready to help with any inquiries regarding operation, maintenance, or parts.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question