GoodHome 101355589

GoodHome Hyssop Ceramic Inset Sink - User Manual

Model: 101355589

Introduction

This manual provides comprehensive instructions for the installation, operation, maintenance, and troubleshooting of your GoodHome Hyssop ceramic single bowl kitchen sink. Please read these instructions carefully before installation and use, and retain them for future reference.



Image: Top-down view of the GoodHome Hyssop ceramic sink, showcasing its single bowl design and white finish.

Setup and Installation

The GoodHome Hyssop sink is designed for either **inset** (drop-in) or **undermount** installation. A detailed instruction manual and all necessary fittings and fixings are included with your purchase. Please consult the included manual for specific cutting templates and detailed step-by-step installation procedures.

- **Installation Type:** Suitable for both inset and undermount applications.
- **Tap Hole:** Features one pre-drilled 32 mm tap hole.
- **Included Components:** 1 sink bowl, instruction manual, fittings, and fixings.



Image: Technical drawing illustrating the dimensions and installation requirements for the GoodHome Hyssop sink.

Operation

Your GoodHome Hyssop ceramic sink is designed for everyday kitchen use. Its large single bowl provides ample space for washing dishes, pots, and pans. The ceramic material is resistant to heat up to 180 °C, allowing for safe placement of hot items directly into the sink.

- **Capacity:** The single bowl measures 490 x 390 mm with a depth of 180 mm, optimizing washing capacity for large volumes.
- **Heat Resistance:** Withstands temperatures up to 180 °C.
- **Durability:** Resistant to shocks and scratches under normal use.



Image: The GoodHome Hyssop sink integrated into a kitchen countertop, featuring a gold faucet and drain.

Maintenance

Proper care will ensure the longevity and pristine appearance of your ceramic sink. The glossy finish and rounded edges are designed for simplified cleaning.

- **Daily Cleaning:** Wipe with a damp cloth after each use.
- **Stain Prevention:** Immediately wipe away spills of coffee, tea, and red wine to prevent staining.
- **Avoid Harsh Chemicals:** Do not use bleach or aggressive chemical cleaning products, as these can damage the ceramic surface.
- **Protect from Impact:** Avoid dropping heavy or sharp objects into the sink to prevent chips or cracks.



Image: A visual guide detailing essential care instructions for ceramic surfaces, including what to avoid.

Troubleshooting

This section addresses common issues you might encounter with your ceramic sink.

Problem	Possible Cause	Solution
Slow Drainage	Partial blockage in the drain pipe.	Use a standard drain cleaner suitable for ceramic sinks. Avoid harsh chemicals. If the problem persists, consult a plumber.
Surface Stains	Food or liquid residue left for extended periods.	Clean immediately with a damp cloth and mild detergent. For stubborn stains, use a ceramic-safe cleaning paste and a soft brush.
Minor Scratches	Abrasion from metal objects or abrasive cleaners.	Ceramic is scratch-resistant but not scratch-proof. Minor surface marks may be polished with specialized ceramic repair kits. Avoid abrasive cleaning pads.

Specifications

Brand	GoodHome
Model Number	101355589
Color	White
Material	Ceramic
Overall Dimensions (L x D x H)	56.5 cm x 46 cm x 20 cm
Bowl Dimensions (L x D x Depth)	49 cm x 39 cm x 18 cm

Weight	19.26 kg
Installation Type	Inset or Undermount
Finish Type	Polished
Shape	Rectangular
Tap Holes	1 (32 mm diameter)
Heat Resistance	Up to 180 °C
Country of Origin	Turkey
Included Components	1 sink bowl, instruction manual, fittings, and fixings

Warranty Information

Your GoodHome Hyssop ceramic sink comes with a manufacturer's warranty to ensure your peace of mind.

- **Manufacturer's Warranty:** 15 years.
- **Spare Parts Availability:** Spare parts are available for 20 years from the date of purchase.

Please retain your proof of purchase for any warranty claims. The warranty covers manufacturing defects under normal use and maintenance as outlined in this manual.



Image: Graphic displaying "15 years WARRANTY" for the product.

Customer Support

For further assistance, technical support, or warranty claims, please contact your retailer or GoodHome customer service. You can find more information about GoodHome products on their official website.
Visit the GoodHome Brand Store for additional product details and support resources.

© 2023 GoodHome. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question