

[Manuals.plus](#) /

› [MageGee](#) /

› MageGee TS68 Mini 60% Gaming Keyboard User Manual

MageGee TS68

MageGee TS68 Mini 60% Gaming Keyboard User Manual

Model: TS68

INTRODUCTION

Thank you for choosing the MageGee TS68 Mini 60% Gaming Keyboard. This ultra-compact keyboard is designed for both gaming and office use, featuring RGB backlighting, a waterproof circuit board, and an ergonomic design for comfortable, long-term use. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance.

MAGEGEE TS68

-  Support Win/Mac
-  Cool RGB Lighting
-  19-key Rollover
-  Ergonomics Design
-  68-keys
-  Anti-Ghosting
-  LED Backlit



Image: Overview of the MageGee TS68 keyboard highlighting its features like RGB lighting, 19-key rollover, ergonomic design, multifunctional knob, and 68 keys.

PACKAGE CONTENTS

- MageGee TS68 Mini 60% Gaming Keyboard
- USB-C Cable
- User Manual

SETUP INSTRUCTIONS

Follow these steps to set up your MageGee TS68 keyboard:

1. **Connect the Keyboard:** Plug the USB-C end of the provided cable into the keyboard's port and the USB-A end into an available USB port on your computer (PC, Mac, PS4, Xbox ONE).
2. **Driver Installation:** The keyboard is plug-and-play. Your operating system will automatically detect and install the necessary drivers. No additional software is required.
3. **Placement:** Position the keyboard comfortably on your desk. The compact 60% layout saves desk space.



Image: The MageGee TS68 keyboard showing its USB-C connection port and cable, indicating compatibility with Mac and Windows systems.

OPERATING INSTRUCTIONS

RGB Backlight Control

The TS68 keyboard features customizable RGB backlighting. Use the following key combinations to adjust the lighting effects:

- **FN + \|**: Switch between different backlight modes.
- **FN + BACK**: Turn the backlight On/Off.
- **FN + [{**: Increase backlight brightness.
- **FN +]}**: Decrease backlight brightness.
- **FN + <**: Decrease backlight speed.
- **FN + >**: Increase backlight speed.

FN+I=Backlight Switching	FN+2=F2
FN+BACK=Backlight On/Off	FN+3=F3
FN+↑=Backlight Brightness+	FN+4=F4
FN+↓=Backlight Brightness-	FN+5=F5
FN+←=Backlight Speed-	FN+6=F6
FN+→=Backlight Speed+	FN+7=F7
FN+DEL=Scr	FN+8=F8
FN+ESC=~	FN+9=F9
FN+WIN=Lock WIN Key	FN+10=F10
FN+W=WASD and directional keys switch	FN+11=F11
FN+1=F1	FN+12=F12



Image: A visual guide to the FN key combinations for controlling RGB backlight modes, brightness, speed, and other keyboard functions.

Multifunctional Knob

The rotary knob located on the upper-right corner of the keyboard provides convenient volume control:

- **Press FN, then scroll the knob:** Adjust system volume.



Image: A close-up view of the multifunctional knob, illustrating its use for volume adjustment by pressing FN and then scrolling.

Additional Key Functions

The TS68 keyboard utilizes FN key combinations for various functions due to its compact layout:

- **FN + DEL:** Scroll Lock (Scr)
- **FN + ESC:** Tilde (~)
- **FN + WIN:** Lock/Unlock Windows Key
- **FN + W:** Switch WASD and directional keys.
- **FN + F1 to F12:** Access multimedia and function keys.

Compatibility

The TS68 keyboard is compatible with a wide range of operating systems and devices, including:

- Windows 10 / 8 / 7 / Vista / XP

- Mac OS
- PS4 / PS5
- Xbox ONE



Image: The MageGee TS68 keyboard integrated into a gaming setup, illustrating its broad compatibility with various platforms including PC, PlayStation, Xbox, and macOS.

MAINTENANCE

To ensure the longevity and optimal performance of your keyboard, follow these maintenance guidelines:

- **Cleaning:** The keyboard's circuit board is IPX4 certified waterproof, allowing for easy cleaning of spills. However, the USB-C interface is not waterproof. Disconnect the keyboard before cleaning. Use a soft, damp cloth to wipe the surface. For deeper cleaning, keycaps can be carefully removed.
- **Avoid Extreme Conditions:** Do not expose the keyboard to extreme temperatures, direct sunlight, or high humidity.
- **Proper Storage:** When not in use, store the keyboard in a clean, dry environment.

TS68 RGB GAMING KEYBOARD



Image: The MageGee TS68 keyboard with some keycaps detached, demonstrating how they can be removed for cleaning or customization.

TROUBLESHOOTING

If you encounter issues with your MageGee TS68 keyboard, refer to the following common solutions:

- **Keyboard Not Responding:**

- Ensure the USB-C cable is securely connected to both the keyboard and your computer.
- Try connecting the keyboard to a different USB port on your computer.
- Test the keyboard on another computer to rule out system-specific issues.

- **Backlight Not Working:**

- Press **FN + BACK** to ensure the backlight is turned on.
- Adjust brightness using **FN + [** and **FN +]**.

- **Keys Not Registering:**

- Clean around the affected keys to remove any debris.
- Ensure the Windows key is not locked (**FN + WIN**).

• **Volume Knob Not Functioning:**

- Ensure you are pressing **FN** before scrolling the knob.

If the issue persists after trying these steps, please contact customer support.

SPECIFICATIONS

Feature	Detail
Brand	MageGee
Model Number	TS68
Connectivity Technology	USB-C
Keyboard Description	Compact (60% Layout)
Number of Keys	68
Switch Type	Mechanical Feeling (Membrane)
Backlighting	RGB Backlit
Special Features	Waterproof (IPX4 Circuit Board), Ergonomic Design, Volume Knob
Compatible Devices	Laptop, PC, Tablet, PS4, Xbox ONE
Compatible OS	Windows 10/8/7/Vista/XP, Mac OS
Material	Plastic



Image: The MageGee TS68 keyboard with its physical dimensions clearly marked, showing its compact size.

WARRANTY AND SUPPORT

MageGee provides a one-year warranty for the TS68 Mini 60% Gaming Keyboard. Should you have any questions about the product, require technical assistance, or need to claim warranty service, please contact our customer

support team. We offer round-the-clock consultation to assist you.
For support, please refer to the contact information provided on the product packaging or the official MageGee website.

PRODUCT VIDEO OVERVIEW

Your browser does not support the video tag.

Video: A brief overview of the MageGee TS91 Mini Keyboard, showcasing its design and features. Note: The product model is TS68, but this video is provided by the seller and is relevant to the product line.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question