



[Manuals.plus](#) /

› [IDEALHOUSE](#) /

› IDEALHOUSE Portable Basketball Hoop Outdoor - Model ZNN_POU_0A6HSDGQ7qdb Instruction Manual

IDEALHOUSE ZNN_POU_0A6HSDGQ7qdb

IDEALHOUSE Portable Basketball Hoop Outdoor Instruction Manual

Model: ZNN_POU_0A6HSDGQ7qdb

INTRODUCTION

Thank you for choosing the IDEALHOUSE Portable Basketball Hoop. This manual provides essential information for the safe assembly, operation, and maintenance of your new basketball system. Please read all instructions carefully before assembly and retain this manual for future reference.

SAFETY INFORMATION

- Always ensure the base is filled with water or sand to its maximum capacity (up to 143 lbs) before use to prevent tipping.
- Do not hang on the rim or backboard. This can cause serious injury and damage the product.
- Regularly inspect all bolts, nuts, and connections for tightness. Tighten as needed.
- Keep children away from the basketball system during assembly and adjustment.
- Avoid using the hoop in strong winds or severe weather conditions. Lay the system down or secure it if high winds are expected.
- Wear appropriate footwear and clothing when playing.

WHAT'S IN THE BOX

Please verify that all components are present before beginning assembly:

- Backboard
- Rim
- Net
- Pole Sections (Multiple)
- Base
- Screwdriver

- Wrench
- Screws and Fasteners
- Pump
- Instructions Manual

EASY TO INSTALL



Image: All components included for assembly.

SETUP AND ASSEMBLY

Assembly is straightforward and typically takes about 30 minutes. For visual guidance, please refer to the assembly video below.

Video: Detailed assembly instructions for the basketball hoop.

Step-by-Step Assembly:

1. **Attach Wheels to Base:** Insert the wheels (H) into the designated slots on the base (N) using the provided rod (I). Ensure they are securely in place.
2. **Connect Base Support Rods:** Attach the two support rods (G) to the main pole (Y) and the base (N) using bolts (E) and nuts (C). Tighten securely with the wrench.

3. **Assemble Backboard and Rim:** Attach the backboard support bracket (J) to the backboard (M) using bolts (A) and nuts (B). Then, attach the rim (K) to the backboard and bracket using bolts (A) and nuts (B). Secure the backboard pads (D) to the back of the backboard.
4. **Assemble Pole Sections:** Connect the upper pole section (O) to the middle pole section (X). Secure them with a bolt (E). Attach the height adjustment handle (P) to the upper pole section.
5. **Attach Backboard Assembly to Pole:** Carefully lift the backboard assembly and attach it to the top pole section (W) using bolts (E).
6. **Connect Pole to Base:** Insert the assembled pole into the base. Secure the pole to the base using the remaining bolts (E) and the height adjustment knobs (F).
7. **Attach Net and Base Cover:** Attach the net (L) to the rim hooks. Place the base cover (Z) over the base for added protection and aesthetics.

OPERATING INSTRUCTIONS

Height Adjustment:

This basketball hoop features an adjustable height mechanism, ranging from 5.2 ft to 10 ft, suitable for various ages and skill levels. To adjust the height:

1. Loosen the height adjustment knobs (F) on the main pole.
2. Use the height adjustment handle (P) to raise or lower the backboard to your desired height.
3. Once the desired height is reached, tighten the adjustment knobs securely to lock the pole in place.

ADJUSTABLE HEIGHT FOR KIDS & ADULTS

wiht 6 Adjustable Gears

5.2FT - 10FT



Image: Adjustable height settings for the basketball hoop.

Portability:

The base is equipped with built-in wheels for easy relocation. To move the hoop:

1. Ensure the base is filled for stability.
2. Tilt the hoop slightly to engage the wheels.
3. Carefully roll the hoop to your desired location.

EASY TO MOVE



Image: Built-in wheels for easy movement.

MAINTENANCE

- **Base Fluid Level:** Regularly check the water or sand level in the base. Refill as necessary to maintain stability. In freezing temperatures, use sand or add antifreeze to water to prevent cracking.
- **Cleaning:** Clean the backboard and pole with a mild soap and water solution. Avoid abrasive cleaners that could scratch the surface.
- **Hardware Inspection:** Periodically check all nuts, bolts, and connections for tightness. Tighten any loose hardware to ensure structural integrity.
- **Net Replacement:** Replace the net if it becomes worn or damaged to ensure continued playability.
- **Storage:** If storing the hoop for an extended period, especially during winter, consider draining the water from the base (if applicable) and storing it in a sheltered area to prolong its lifespan.

TROUBLESHOOTING

- **Hoop Instability:** Ensure the base is completely filled with water or sand. Check that all pole sections are securely connected and all bolts are tightened.

- **Difficulty Adjusting Height:** Loosen the adjustment knobs completely before attempting to raise or lower the backboard. Ensure the internal mechanism is free of obstructions.
- **Damaged Net:** The net is replaceable. Contact customer support for a replacement net.
- **Backboard Wobble:** Verify that the backboard support brackets are firmly attached to both the backboard and the main pole. Tighten all associated hardware.

SPECIFICATIONS

Brand	IDEALHOUSE
Model Name	rYkkwPFRv-0fpNCwF5tjTwQ172
Model Number	ZNN_POU_0A6HSDGQ7qdb
Material	Metal
Color	Black
Product Dimensions	19.69"D x 11.8"W x 74"H
Item Weight	22.88 Pounds
Special Feature	Adjustable Height
Mounting Type	Floor Mount
Minimum Height	5 Feet
Maximum Height Recommendation	10 Feet
Is Assembly Required	Yes






Image: Product dimensions and adjustable height range.

WARRANTY INFORMATION

This product comes with a **30-day manufacturer's warranty**. Please retain your proof of purchase for any warranty claims. The warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from misuse, accidents, unauthorized modifications, or failure to follow the instructions in this manual.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or encounter any issues with your IDEALHOUSE Portable Basketball Hoop, please contact our customer support team. Refer to your purchase documentation for specific contact details or visit the official IDEALHOUSE store page on Amazon.

Online Store: [Visit the IDEALHOUSE Store on Amazon](#)