

COLAMY VC-4840BS-24-BE3-FB-3B

COLAMY Swivel Counter Height Bar Stools (Set of 3, 25 Inch) - Instruction Manual

Model: VC-4840BS-24-BE3-FB-3B

Introduction	Safety Information	Package Contents	Setup & Assembly	Operation
Maintenance	Troubleshooting	Specifications	Warranty & Support	

1. INTRODUCTION

Thank you for choosing the COLAMY Swivel Counter Height Bar Stools. This manual provides essential information for the safe assembly, operation, and maintenance of your new bar stools. Please read these instructions carefully before use and retain them for future reference.

These bar stools feature a 360-degree swivel seat, an ergonomic backrest, and a sturdy wood frame, designed for comfort and durability in various indoor settings such as kitchens, dining rooms, or home bars.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Assembly is required. Ensure all parts are correctly installed and fasteners are tightened before use.
- Do not exceed the maximum weight limit of **300 lbs (136.08 kg)** per stool.
- Use caution to prevent tipping. Do not stand on the stool or lean excessively to one side.
- Keep children away from the assembly area. Small parts may pose a choking hazard.
- Regularly check all bolts and screws to ensure they remain tight. Retighten as necessary.
- Use the stools only on a flat, stable surface.
- Avoid exposing the stools to direct sunlight or extreme temperatures, which can damage the wood and fabric.

3. PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

Each package contains components for one bar stool. This set includes 3 packages.

◆◆ PRODUCT DISPLAY ◆◆




Figure 3.1: Product dimension diagram. This image illustrates the overall dimensions of the bar stool and indicates that the product ships in 3 boxes, with a weight capacity of 300 lbs.

Typical Components per Stool:

- Seat with backrest (1)
- Leg assembly (1)
- Footrest ring (1)
- Hardware pack (screws, washers, Allen wrench)
- User Manual (this document)

4. SETUP & ASSEMBLY

Assembly is required for these bar stools. It is recommended to assemble the stools on a soft, clean surface to prevent scratching. Two people may be required for easier assembly.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out and compare with the package contents list to ensure everything is present.
2. **Attach Legs to Footrest Ring:** Connect the four legs to the circular footrest ring using the provided screws and Allen wrench. Ensure all connections are secure but do not fully tighten yet.
3. **Attach Seat to Leg Assembly:** Align the seat with the top of the leg assembly. Secure the seat to the leg assembly using the designated screws. Ensure the swivel mechanism is correctly oriented.
4. **Attach Backrest to Seat:** Connect the backrest to the seat using the remaining screws. Ensure the holes align properly. *Note: Some users have reported alignment challenges in this step. If you encounter difficulty, gently adjust the components until the holes align. Do not force screws.*
5. **Final Tightening:** Once all components are loosely assembled, place the stool upright on a flat surface. Apply gentle pressure to ensure it is level, then fully tighten all screws and bolts. Do not overtighten.



Figure 4.1: Key features of the bar stool, including the ergonomic backrest, 360-degree swivel seat design, and strong rubber-wood frame with footrest. These elements are crucial for correct assembly.

5. OPERATION

Using Your Bar Stools:

- **Swivel Function:** The seat is designed to rotate 360 degrees. To swivel, simply turn the seat in the desired direction. Ensure there are no obstructions around the stool before rotating.
- **Footrest:** Utilize the integrated footrest ring for added comfort and support.
- **Placement:** Position the bar stools on a level surface. They are suitable for indoor use in kitchens, dining areas, home bars, or similar environments.



Figure 5.1: The 360-degree swivel function allows for easy movement and interaction. This image shows a user comfortably seated on the stool, highlighting its ergonomic design and swivel capability.

6. MAINTENANCE

Cleaning and Care:

- **Fabric Upholstery:** For general cleaning, gently vacuum the fabric to remove dust and loose debris. For spills, blot immediately with a clean, dry cloth. For stubborn stains, use a mild fabric cleaner according to the product instructions, testing on an inconspicuous area first. Do not saturate the fabric.
- **Wood Frame:** Wipe the wood frame with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish. Dry immediately with a clean cloth.
- **Hardware:** Periodically check all screws and bolts for tightness. Retighten as needed to maintain stability and prevent creaking.
- **Non-Slip Feet:** Ensure the non-slip feet are clean and intact to protect your floors and maintain stability.



Figure 6.1: Detailed view of material and construction. This image highlights the breathable fabric, high-density sponge, decorative nailhead trim, and non-slip feet, all of which require proper care.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stool is wobbly or unstable.	Loose screws or uneven assembly.	Ensure all screws are fully tightened. Place the stool on a flat surface and apply gentle pressure to level it before final tightening.
Difficulty aligning screw holes during assembly.	Components not perfectly aligned or slight manufacturing variations.	Do not force screws. Loosen adjacent screws slightly, gently adjust the components to align the holes, then re-tighten all screws once aligned.
Stool makes creaking noises.	Loose connections or friction between parts.	Check and tighten all assembly screws. If creaking persists, disassemble and reassemble, ensuring all parts are correctly seated.
Swivel mechanism is stiff.	Dust or debris in the swivel mechanism, or lack of lubrication.	Clean around the swivel mechanism. A small amount of silicone-based lubricant can be applied if necessary, avoiding contact with fabric.

8. SPECIFICATIONS

Feature	Detail
Brand	COLAMY
Model Name	VC-4840BS-24-BE3-FB-3B
Color	Beige
Material	Fabric, Sponge, Wood
Product Dimensions (D x W x H)	48D x 53W x 88H cm (18.9D x 20.87W x 34.65H inches)
Seat Height	25.39 inches (approx. 64.5 cm)
Item Weight (per stool)	11 kg (24.25 lbs)
Maximum Weight Capacity (per stool)	136.08 kg (300 lbs)
Back Style	Solid Back
Frame Material	Wood
Unit Count	3 count (Set of 3)
Indoor/Outdoor Usage	Indoor
Assembly	Required

9. WARRANTY & SUPPORT

COLAMY products are manufactured with quality and care. For specific warranty information regarding your bar stools,

please refer to the warranty card included with your purchase or visit the official COLAMY website.

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact COLAMY customer support:

- **Website:** [Visit the COLAMY Store on Amazon](#) (for general inquiries and product information)
- **Email/Phone:** Please refer to your product packaging or the COLAMY website for the most current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question