

Manuals.plus /

> MINISO /

> MINISO Disney Lilo & Stitch Blind Box Animal Party Series Figures Instruction Manual

MINISO B0G1LVJMFD

MINISO Disney Lilo & Stitch Blind Box Animal Party Series Figures Instruction Manual

1. INTRODUCTION TO YOUR BLIND BOX FIGURE

Welcome to the enchanting world of MINISO Disney Lilo & Stitch Blind Box Animal Party Series Figures. This product offers a unique collectible experience, where each box contains one randomly selected figure from a specific series. The excitement lies in the surprise of discovering which character you receive. This series features beloved characters Stitch and Angel reimagined as various animal friends, combining durable vinyl with soft plush elements for a delightful tactile and visual experience. Each figure is designed to be a charming display piece for collectors and Disney enthusiasts.



Illustration explaining the concept of a blind box, where the contents are a surprise until opened.




Visual guide to blind box rules, emphasizing that each box contains one random figure and contents are not visible from the outside.

2. SETUP AND UNBOXING

Your MINISO Disney Lilo & Stitch Blind Box figure comes individually packaged to preserve the element of surprise. Follow these simple steps to unbox your new collectible:

1. Carefully remove the outer plastic wrapping from the blind box packaging.
2. Locate the designated opening tab or seam on the box.
3. Gently open the box to reveal the inner packaging, which typically contains the figure sealed in an opaque bag.
4. Open the opaque bag to unveil your unique MINISO Disney Lilo & Stitch Animal Party Series Figure.
5. Retain the box and any included cards for collection reference, if desired.




The exterior packaging of the MINISO Disney Lilo & Stitch Blind Box, featuring the 'Party Animals' theme.

3. DISPLAY AND COLLECTION

These figures are designed for display and collection. Their stable base and compact size make them suitable for various settings.


- **Placement:** Position your figure on a flat, stable surface such as a desk, shelf, or display cabinet. Ensure it is away from direct sunlight, extreme temperatures, and high humidity to preserve its material and colors.
- **Collection:** The series includes 7 unique 'Party Animal' characters. Collecting the full set allows for a complete display. Note that blind boxes contain random designs, and obtaining a full set may require purchasing multiple boxes.
- **Tactile Experience:** Enjoy the unique combination of smooth vinyl and soft plush textures that each figure offers.




An illustration showcasing all seven unique figures available in the Animal Party Series, each with a distinct animal costume.



A collection of figures displayed in a beach environment, highlighting the variety and potential for a hidden model within the series.



The full collection of MINISO Disney Lilo & Stitch Animal Party Series figures arranged on a beach, showcasing their design and collectible nature.



The 'Good-Night Koala' Stitch figure displayed in a charming outdoor scene, demonstrating its suitability for decorative placement.

4. MAINTENANCE AND CARE

To ensure the longevity and appearance of your MINISO Disney Lilo & Stitch figure, follow these care guidelines:

- **Cleaning:** Gently wipe the vinyl parts with a soft, dry cloth. For plush areas, use a soft brush or a slightly damp cloth with mild soap, then air dry completely. Avoid harsh chemicals or abrasive materials.
- **Handling:** Handle figures with care to prevent damage to delicate parts or paint. Avoid dropping or subjecting them to strong impacts.
- **Storage:** If storing, keep figures in a clean, dry, and dust-free environment, ideally in their original packaging or a protective display case.

5. TROUBLESHOOTING AND COMMON QUESTIONS

Q: I received a duplicate figure. Is this normal?

A: Yes, as these are blind boxes, the figures are randomly selected. Receiving duplicates is a normal part of the blind box collecting experience, especially when purchasing multiple individual boxes. To increase your chances of getting a full set without duplicates, some retailers offer full cases, which typically guarantee a complete set of regular figures.

Q: My figure has a minor paint imperfection or a small mark. What should I do?

A: Minor variations in paint application or small marks can occasionally occur during the manufacturing

process of collectible figures. While quality control aims to minimize these, they are sometimes unavoidable. If the imperfection significantly impacts the figure's appearance or structural integrity, please refer to the support section for contact information.

Q: Are these figures suitable for young children?

A: The manufacturer recommends a minimum age of 15 years (180 months) for this product. This is due to the collectible nature and potential for small parts, making them more suitable for older teens and adult collectors rather than young children.

6. SPECIFICATIONS

Feature	Detail
Brand	MINISO
Model Number	B0G1LVJMFD (6936906765184)
Series Name	Disney Lilo & Stitch Animal Party Series
Toy Figure Type	Stuffed Toy / Collectible Figure
Material Type	Vinyl (Outer Material)
Item Dimensions (L x W x H)	5 x 5 x 3 inches (approximate packaging)
Figure Height	Approximately 3.15 – 3.94 inches (8-10 cm)
Item Weight	4.8 ounces (approximate)
Number of Pieces	1 (per blind box)
Recommended Age	15 years and up (180 months)
Assembly Required	No
Batteries Required	No



Detailed dimensions of the product packaging and a full display case.



Visual comparison of a figure's height (8-10cm) against a standard mobile phone.

7. WARRANTY INFORMATION

MINISO products are manufactured to high-quality standards. Specific warranty details for collectible figures may vary by region and retailer. Generally, these collectible figures do not come with an extended manufacturer's warranty beyond initial defects upon receipt.

Upon receiving your figure, please inspect it for any manufacturing defects. If you encounter any issues, please contact the retailer from whom you purchased the product within their specified return or exchange period.

8. SUPPORT AND CONTACT

For further assistance, inquiries, or to explore more MINISO products, please refer to the following

resources:

- **MINISO Official Store:** Visit the [MINISO Store on Amazon](#) for product information and customer service.
- **Retailer Support:** For purchase-specific questions, returns, or exchanges, contact the customer service department of the retailer where you bought your figure.