

[Manuals.plus](#) /

› [FZGhome](#) /

› FZGhome T144 Stainless Steel Litter Box with Lid, XL Extra Large - Instruction Manual

FZGhome T144

FZGhome T144 Stainless Steel Litter Box with Lid, XL Extra Large - Instruction Manual

Model: T144 | Brand: FZGhome



INTRODUCTION

The FZGhome T144 Stainless Steel Litter Box is designed to provide a comfortable and hygienic solution for your cat's needs. This extra-large litter box features a durable stainless steel pan, a multi-layer detachable plastic shell, and includes essential accessories. Its versatile design allows for multiple configurations to suit various preferences and simplifies cleaning.

INCLUDED COMPONENTS

Before assembly, please ensure all the following components are present:

- Stainless Steel Litter Pan
- Plastic Top Enclosure (multi-layer detachable shell)
- Lid for Top Entry
- Foot Pedal / Litter Tracking Guard
- Cat Litter Scoop
- Cat Litter Mat
- Non-Slip Mats (for the bottom of the stainless steel pan)
- User Manual (this document)

Advantages of Product Materials



Easy to Clean



Anti Scratch



Anti-slip Pad

Figure 1: All included components of the FZGhome T144 Litter Box.

SETUP INSTRUCTIONS

1. **Prepare the Stainless Steel Pan:** Place the stainless steel litter pan on a flat, stable surface. Attach the provided non-slip mats to the bottom of the pan to prevent movement.
2. **Assemble the Plastic Enclosure:** The plastic enclosure consists of multiple layers. Carefully align and snap the middle section onto the stainless steel pan. Ensure it is securely fastened.
3. **Attach the Top Cover:** Place the top cover onto the middle section of the plastic enclosure. Secure it using the latches or clips provided on the sides.
4. **Install the Foot Pedal:** If using the front entry configuration, attach the foot pedal (litter tracking guard) to the front opening of the litter box.
5. **Position the Litter Mat:** Place the cat litter mat in front of the litter box to help capture any tracked litter.
6. **Add Litter:** Fill the stainless steel pan with your preferred cat litter to a suitable depth, typically 2-3 inches.



Figure 2: Visual guide for assembling the litter box components.

OPERATING THE LITTER BOX

The FZGhome T144 litter box offers three versatile configurations to accommodate your cat's preferences and your convenience:

- **Fully Enclosed Mode:** This configuration provides maximum privacy for your cat and helps contain odors and litter scatter. Cats can enter and exit through the front opening or the top entry.
- **Semi-Enclosed Mode:** By removing the top cover, the litter box becomes semi-enclosed, offering a more open feel while still providing some containment. This mode can be easier for some cats to adapt to and simplifies scooping.
- **Open Litter Pan Mode:** For cats who prefer an entirely open environment, the plastic enclosure can be fully removed, leaving just the stainless steel pan. This provides the most accessible option.

To switch between modes, simply detach or reattach the top cover and/or the middle plastic section as needed. The top entry lid can be opened by pushing it back gently until it clicks, allowing it to stay open for easy access or cleaning.




Figure 3: The three versatile modes of the FZGhome T144 Litter Box.



Figure 4: Different entry and exit options for cats.


MAINTENANCE AND CLEANING

Regular maintenance is crucial for hygiene and odor control. The FZGhome T144 is designed for easy cleaning:

- **Daily Scooping:** Use the included cat litter scoop to remove solid waste and clumps daily. The smooth stainless steel surface of the pan prevents litter from sticking, making scooping easier than with plastic pans.
- **Litter Replacement:** For your cat's health and optimal odor control, replace all cat litter every 1-3 weeks, depending on usage and the type of litter.
- **Full Cleaning:** When changing the litter, thoroughly clean the stainless steel pan and all plastic components.
 - The foldable front module and the 125° flip-top design allow for convenient access to the interior for cleaning without fully disassembling the unit.
 - Wash the stainless steel pan with mild soap and water. Rinse thoroughly and dry completely before adding new litter.
 - Wipe down the plastic enclosure with a pet-safe cleaner.
- **Litter Tracking Prevention:** The foot pedal and cat litter mat are designed to collect stray litter. Regularly shake out or vacuum the mat and clean the foot pedal.
- **Odor Control:** The enclosed design helps contain odors. Regular cleaning and timely litter changes are the most effective methods for odor management.

Product List

One-stop shop for all your cat litter box needs



Cat Litter
Mat




Non-Slip
Mat



Cat Litter
Scoop



User manual




Litter Tracking
Guard

Figure 5: The 125° flip-top design simplifies daily cleaning.

Why Choose Us?



✓ 125° Flip-top Design



✓ Press the Lid to Keep it Open



✓ Helps Reduce Cat Litter From Falling Out



✗ Requires Removal of Whole Top Cover



✗ Lid Won't Stay Open



✗ Easy to Mess Up

VS

Figure 6: Extended baffles prevent urine leakage.

TROUBLESHOOTING

Issue	Possible Cause	Solution
Litter tracking outside the box	Cat exiting directly from the box; insufficient litter trapping.	Ensure the foot pedal and litter mat are correctly positioned. Consider using the top entry option if your cat adapts to it, as it helps dislodge litter from paws.

Issue	Possible Cause	Solution
Odor persists	Infrequent scooping or litter changes; inadequate cleaning.	Scoop daily. Replace all litter every 1-3 weeks. Perform a full cleaning of the pan and plastic components regularly.
Urine leakage from seams	Improper assembly of plastic components; cat urinating high.	Ensure all plastic sections are securely snapped together. The inverted plate and overlapping design are intended to prevent this; verify they are correctly aligned.
Lid does not stay open during cleaning	Lid not fully engaged in the open position.	Push the top lid back gently until it clicks into place. This mechanism is designed to keep it open.
Litter sticking to the stainless steel pan	Certain litter types or moisture issues.	While stainless steel is generally non-stick, some clumping litters or high moisture can cause sticking. Ensure the pan is completely dry after cleaning. You may try a different brand of clumping litter or a thin layer of non-stick cooking spray (ensure it's pet-safe and wiped clean before adding litter).

SPECIFICATIONS

- **Model Number:** T144
- **Product Dimensions (L x W x H):**23.65" x 15.75" x 15.3" (60.07 cm x 40.00 cm x 38.86 cm)
- **Item Weight:** 7.7 pounds (3.49 kg)
- **Materials:** Stainless Steel (pan), Plastic (enclosure, lid, accessories)
- **Litter Box Type:** Covered Litter Box (convertible to semi-enclosed or open)
- **Features:** High Sides, Lid, Top Entry, Front Entry, Anti-Leakage Design, Easy-to-Clean

3 in 1 Box

Catering to Cats' Different Preferences



Figure 7: Dimensions and interior space of the FZGhome T144 Litter Box.

WARRANTY INFORMATION

No specific warranty information is provided in the product details. Please refer to the retailer's return policy or contact FZGhome customer service for details regarding product warranty.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your FZGhome T144 Stainless Steel Litter Box, please contact FZGhome customer service through the retailer where the product was purchased. You may also visit the official FZGhome website for additional resources.

