

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Waleaf](#) /

› [Waleaf 70-inch Fluted Fireplace TV Stand with 23-inch Electric Fireplace Instruction Manual](#)

Waleaf XD-70TVS-23PC

Waleaf 70-inch Fluted Fireplace TV Stand with 23-inch Electric Fireplace Instruction Manual

Model: XD-70TVS-23PC

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions and safety warnings before assembling, installing, or operating this product. Failure to follow these instructions may result in electric shock, fire, property damage, or personal injury.

- Always disconnect the electric fireplace from the power supply before cleaning or performing any maintenance.
- Do not operate the fireplace with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Ensure the TV stand is placed on a stable, level surface.
- Do not overload the TV stand's top surface or shelves.

PRODUCT OVERVIEW


The Waleaf 70-inch Fluted Fireplace TV Stand is designed to accommodate televisions up to 80 inches and features an integrated 23-inch electric fireplace. This unit combines functional storage with an aesthetic focal point for your living space.



Image: The Waleaf 70-inch Fluted Fireplace TV Stand in a living room setting, showcasing its black finish, fluted design, and illuminated electric fireplace.

SETUP AND ASSEMBLY

This product is delivered in two separate packages: one for the TV stand components and one for the electric fireplace insert. These packages may arrive at different times. Please ensure you have both packages before beginning assembly.



7 CHANGEABLE FLAME COLOR



Image: Diagram illustrating the overall dimensions of the 70-inch TV stand (70"W x 15.75"D x 23.39"H) and indicating that the product ships in two boxes (Box A for the stand, Box B for the fireplace).

Assembly Instructions:

- Unpack Components:** Carefully remove all parts from the packaging. Verify that all components and hardware listed in the included instruction manual are present. The packaging includes protective foam to prevent damage during transit.
- Identify Parts:** All parts are labeled for easy identification. Refer to the assembly diagram provided in the separate instruction booklet.
- Assemble TV Stand Frame:** Follow the step-by-step instructions to construct the main frame of the TV stand. Pre-drilled holes are provided for accurate alignment.
- Install Shelves and Doors:** Attach the adjustable cabinet shelves and sliding side doors as per the instructions.
- Integrate Electric Fireplace:** Once the TV stand frame is complete, carefully insert the 23-inch electric fireplace into its designated opening. Ensure it is securely seated.
- Final Placement:** Position the assembled TV stand on a flat, stable surface in your desired location.

OPERATING THE ELECTRIC FIREPLACE

The electric fireplace offers realistic flame effects and adjustable heating. It can be controlled via the integrated control panel or the included remote control.



Image: Close-up of the electric fireplace control panel and the remote control, highlighting buttons for Power, Heater, Timer, Child Lock, Dimmer, Flame Speed, and Color.

Remote Control Functions:

- **Power:** Turns the fireplace ON/OFF.
- **Heater:** Activates the heating function. Choose between 750W or 1500W heat output. The heating can be used independently of the flame effect.
- **Timer:** Sets an automatic shutdown timer for the fireplace.
- **Child Lock:** Engages or disengages the child lock feature for safety.
- **Dimmer:** Adjusts the brightness of the flame effect.
- **Flame Speed:** Changes the speed of the flame animation.
- **Color:** Cycles through 7 changeable flame color options to match your ambiance.

The fireplace features realistic log effects and 3D flame technology for an enhanced visual experience. The heating function provides supplemental warmth for your room.

STORAGE AND DESIGN FEATURES

The TV stand is designed with both aesthetics and functionality in mind, offering ample storage and a distinctive curved profile.



Image: Diagram highlighting the 5-level adjustable shelves, sliding side doors, and stable base of the TV stand.

- **Adjustable Shelves:** The cabinet sections feature 5-level adjustable shelves, allowing you to customize storage space for various items, from media devices to decorative objects.
- **Sliding Side Doors:** Smooth-gliding side doors conceal storage compartments, maintaining a tidy appearance.
- **Curved Profile Design:** The unique wavy grooved panels and curved silhouette add a modern and sophisticated touch to your living room decor.
- **Stable Base:** The robust base ensures stability and durability for the entire unit.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your TV stand and electric fireplace.

- **Cleaning the TV Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.

- **Cleaning the Electric Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Use a soft, dry cloth to wipe the exterior. Do not spray liquids directly onto the unit.
- **Dusting:** Regularly dust all surfaces to prevent buildup.

TROUBLESHOOTING

If you encounter issues with your Waleaf TV stand or electric fireplace, refer to the following common solutions:

- **Fireplace Not Turning On:** Check if the power cord is securely plugged into a working outlet. Ensure the power switch on the unit (if applicable) is in the 'ON' position. Verify that the circuit breaker has not tripped.
- **No Heat Output:** Confirm the heater function is activated via the control panel or remote. Check if the thermostat setting is higher than the room temperature.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace's receiver.
- **Unstable TV Stand:** Verify that all assembly hardware is tightened securely. Ensure the stand is placed on a level floor.

For issues not resolved by these steps, please contact customer support.

SPECIFICATIONS

Brand	Waleaf
Model Name	XD-70TVS-23PC
Product Dimensions	15.75"D x 70"W x 23.4"H
Material	Wood (Console), Metal (Fireplace)
Color	Black
Power Source	Corded Electric
Ventilation Type	Vent Free
Item Weight	61.3 Pounds
Maximum TV Size Support	Up to 80 inches
Top Weight Capacity	Up to 300 lbs
Fireplace Heat Output	750W / 1500W


WARRANTY AND SUPPORT

Waleaf is committed to providing quality products and customer satisfaction. While specific warranty details are not provided here, our dedicated support team is available to assist you with any questions or concerns regarding your product.

For assistance, please contact Waleaf customer service. Our team aims to provide a solution within 24 hours.

Please retain your purchase receipt for any warranty claims or support inquiries.

Related Documents - XD-70TVS-23PC

 <p>MANUAL INSTRUCTIONS</p> <p>Mercer41 Luxury 70" Fluted TV Stand Assembly Instructions</p> <p>Comprehensive assembly manual for the Mercer41 Luxury 70-inch fluted TV stand. This guide provides detailed instructions, parts identification, hardware lists, and troubleshooting tips for building your modern entertainment center.</p> <p><small>(24/7) service@merc41usa.com (only us) 1-212-819-4788</small></p>	
 <p>IGNITE XL BOLD Installation and User's Guide</p> <p><small>Model: XLF5017-XD XLF6017-XD XLF7417-XD XLF8817-XD XLF10017-XD</small></p> <p>We value your feedback! Your input helps to create even better products and experiences. Share your thoughts and leave a review: dimplex.com/shareawards</p> <p><small>YouTube Dimplex Dimplex</small></p>	<p>Dimplex Ignite XL Bold Electric Fireplace: Installation and User's Guide</p> <p>Comprehensive guide for installing and operating the Dimplex Ignite XL Bold electric fireplace. Covers safety instructions, technical specifications, package contents, installation procedures, operation modes, maintenance, troubleshooting, and warranty information for models XLF5017-XD, XLF6017-XD, XLF7417-XD, XLF8817-XD, and XLF10017-XD.</p>
 <p>MANUAL INSTRUCTIONS</p> <p>KMC Globle H21419-01A-XD TV Stand with Fireplace - Assembly Manual</p> <p>Comprehensive assembly guide for the KMC Globle H21419-01A-XD TV Stand, featuring an integrated fireplace. Includes detailed steps, parts list, hardware identification, and safety instructions.</p> <p><small>(24/7) service@mcglobe.us.com (only us) 1-212-816-4788</small></p>	
 <p>Shenzhen Xiaodong Innovation Technology XD-CE10 User Manual</p> <p>User manual for the Shenzhen Xiaodong Innovation Technology XD-CE10 charging stand, providing information on components, specifications, usage, troubleshooting, and safety instructions.</p>	
 <p>RACKS BRAX. COMPATIBILITY POCKET GUIDE FOR Outback TOURER FAST ON! FAST OFF!</p>	<p>RacksBrax Outback Tourer Awning & Accessory Compatibility Guide</p> <p>Comprehensive compatibility guide for RacksBrax Outback awnings and accessories, detailing hitch and bracket requirements, and wall mount options. Includes models like the 180, 270, 270 Plus, and Shower Awning.</p>
 <p>Honda Center Stand Installation Instructions for NC750XA/XD</p> <p>Step-by-step guide to installing the Honda Center Stand (P/N 08M70-MKW-D00) on NC750XA/XD motorcycles. Includes parts list, required tools, torque specifications, and detailed instructions.</p>	

