

## Seesii PWQFT01

# SEESII 5-Gallon Battery Powered Backpack Sprayer Instruction Manual

Model: PWQFT01

## INTRODUCTION

Thank you for choosing the SEESII 5-Gallon Battery Powered Backpack Sprayer. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new sprayer. Please read all instructions carefully before use and retain this manual for future reference.

This electric sprayer is designed for various applications including weed control, lawn and garden maintenance, pest control, and general cleaning tasks. Its leak-proof design, dual battery system, adjustable pressure, and versatile nozzle kit ensure reliable performance and user comfort.

## PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 1 x 5-Gallon Leak-Proof Tank with Padded Straps
- 2 x 2.0Ah Rechargeable Batteries
- 1 x Battery Charger
- 1 x Extendable Brass Wand
- 1 x Valve Handle
- 1 x Hose
- 7 x Interchangeable Nozzles (Fan, Cone, Shower types)
- 1 x Screen Filter
- Spare O-Rings
- 1 x User Manual



Image: The SEESII 5-Gallon Battery Powered Backpack Sprayer with all its components, including the main unit, batteries, charger, wand, hose, and various nozzles, neatly arranged on a wooden surface.

Your browser does not support the video tag.

Video: This video demonstrates the unboxing and initial assembly steps for the SEESII Backpack Sprayer, showing how to connect the components and prepare the unit for use.

## SETUP AND ASSEMBLY

1. **Attach Shoulder Straps:** Securely attach the padded shoulder straps to the designated hooks on the sprayer tank. Adjust for a comfortable fit.
2. **Install Pressure Knob Cap:** Place the pressure knob cap onto the pressure adjustment dial.
3. **Connect Wand and Hose:** Securely attach the telescopic brass wand to the valve handle, then connect the hose to the valve handle and the sprayer unit. Ensure all connections are tight to prevent leaks.
4. **Mount Nozzle:** Select the desired nozzle from the 7-nozzle kit and mount it onto the wand, tightening it firmly.
5. **Install Wand Hook:** Attach the wand hook to the side of the sprayer tank for convenient storage of the wand when not in use.
6. **Insert Battery:** Open the battery compartment cover. Insert a charged 2.0Ah battery into the slot until it

clicks into place. Close the cover securely.

# Engineered to Prevent Leaks

## Seamless Tank

One-Piece Blow-Molded




Image: A hand is shown inserting one of the 2.0Ah rechargeable batteries into the designated compartment on the SEESII Backpack Sprayer, highlighting the easy installation process.

# 5-Gal

## High-Capacity Tank




-  Less Refilling
-  More Coverage
-  More Time Saved



Image: A close-up view of the seven interchangeable nozzles (fan, cone, shower types) that come with the SEESII Backpack Sprayer, demonstrating the variety available for different spraying needs.

### OPERATING INSTRUCTIONS

- 1. Fill Tank:** Unscrew the top cap and remove the screen filter. Fill the 5-gallon tank with your desired liquid (water, fertilizer, herbicide, etc.). Ensure the liquid is free of large debris. Replace the screen filter and securely fasten the cap.
- 2. Check Battery Level:** Press the power button to check the battery level indicator. Ensure sufficient charge for your task.
- 3. Power On:** Flip the main power switch to the 'ON' position.
- 4. Adjust Pressure:** Use the variable pressure knob to set the desired spray pressure, ranging from 0 to

100 PSI. A gentle mist is suitable for delicate plants, while higher pressure can reach tall trees (up to 20-26ft).

5. **Begin Spraying:** Squeeze the valve handle to start spraying. The handle can be locked for continuous spraying.
6. **Power Off:** After use, release the valve handle and flip the main power switch to the 'OFF' position.



Image: A person is shown filling the 5-gallon tank of the SEESII Backpack Sprayer with water from a hose, demonstrating the ease of refilling the unit.




Image: A detailed view of the adjustable pressure knob on the SEESII Backpack Sprayer, indicating the 0-100 PSI range for customizing spray intensity.

Your browser does not support the video tag.

Video: This video showcases the SEESII Leak-Proof 5-Gallon Backpack Sprayer in action, demonstrating its features and ease of use during various spraying tasks.

## FEATURES OVERVIEW

- **Leak-Proof Tank & Advanced Construction:** Features a one-piece blow-molded construction for a seamless, leak-proof experience. A unique diversion groove channels liquid away from the battery compartment.
- **Dual Battery System:** Equipped with two 2.0Ah rechargeable batteries, providing up to 1 hour and 48

minutes of continuous runtime per battery (approx. 66 gallons output).

- **0-100 PSI Adjustable Pressure:** Customize spray intensity from a gentle mist to a powerful jet for various applications.
- **Premium Telescopic Brass Wand:** Offers superior corrosion resistance and extends for reaching high areas. Includes a lockable handle for continuous spraying.
- **Versatile 7-Nozzle Kit:** Includes fan, cone, and shower nozzles for precision watering, broad coverage, and specialized tasks.
- **Ergonomic Comfort:** Designed with thickened, breathable mesh shoulder straps and a padded back to distribute weight evenly and ensure comfort during extended use.

## Leak-Resistant, Motor-Safe



**Drip Diversion Groove**  
Channels water away to  
keep the motor dry



Image: This image displays the different spray patterns achievable with the 7 interchangeable nozzles, illustrating the versatility for various gardening and spraying tasks.



## Adjustable Pressure Control 0-100 PSI

Image: A person is shown wearing the SEESII Backpack Sprayer, emphasizing the ergonomic comfort provided by its padded straps and back panel during use.

### MAINTENANCE

- **Cleaning:** After each use, rinse the tank thoroughly with clean water. Spray clean water through the wand and nozzles to prevent clogging.
- **Nozzle Care:** Regularly inspect nozzles for clogs or damage. Clean them with a soft brush or by soaking in warm, soapy water if necessary.
- **O-Ring Inspection:** Periodically check all O-rings and gaskets for wear or damage. Replace them with the provided spare O-rings if any leaks are detected.
- **Battery Storage:** Store batteries in a cool, dry place away from direct sunlight. Ensure batteries are

charged before long-term storage.

- **Unit Storage:** Store the sprayer in a dry, protected area, away from extreme temperatures.

## TROUBLESHOOTING

- **No Spray/Weak Spray:**

- Check battery charge.
- Ensure all hose connections are tight.
- Clean clogged nozzles or filter.
- Verify the power switch is ON and pressure knob is adjusted.

- **Leaking:**

- Tighten all connections (hose, wand, nozzle, tank cap).
- Inspect O-rings and gaskets for wear and replace if necessary.
- Note: Minor water residue inside the tank or hose upon arrival is normal due to factory testing for leak-proof assurance.

- **Battery Not Charging:**

- Ensure the charger is properly connected to the battery and a power outlet.
- Check for damage to the charger or battery.

## SPECIFICATIONS

Feature	Detail
Brand	Seesii
Model Name	SEESII Backpack Sprayer
Model Number	PWQFT01
Tank Volume	5 Gallons (19L)
Power Source	Battery Powered (2 x 2.0Ah batteries included)
Maximum Pressure	100 PSI
Hose Length	45.6 Inches
Item Weight	11.8 Pounds
Item Dimensions (W x H)	15"W x 18"H
Material	Brass Wand, Plastic Tank
Recommended Uses	Painting, Pest Control, Sanitizing, Vehicle Washing, Watering, Weed Control

## WARRANTY AND SUPPORT

SEESII stands behind its products with confidence. Your SEESII Backpack Sprayer comes with a comprehensive **3-Year Manufacturer Warranty**.

Additionally, lifetime technical assistance is available for your electric sprayer. For troubleshooting tips, usage guidance, or replacement inquiries, please contact our dedicated customer care team. We are committed to ensuring your garden and lawn maintenance continues smoothly without interruption.