

Klipsch 1073625

Klipsch ProMedia Lumina 2.1 Computer Gaming Speaker System Instruction Manual

Model: 1073625 | Brand: Klipsch

INTRODUCTION

Thank you for purchasing the Klipsch ProMedia Lumina 2.1 Computer Gaming Speaker System. This manual provides essential information for setting up, operating, and maintaining your new speaker system to ensure optimal performance and longevity. The ProMedia Lumina system is designed to deliver powerful audio with deep bass and customizable RGB lighting, enhancing your gaming, music, and movie experiences.

SAFETY INFORMATION

Please read all safety instructions before using this product. Keep this manual for future reference.

- **Power Source:** Connect the system only to the type of power source indicated on the marking label.
- **Ventilation:** Ensure proper ventilation around the speakers and subwoofer. Do not block any ventilation openings.
- **Water and Moisture:** Do not expose the system to water, rain, or moisture. Do not place objects filled with liquids on the system.
- **Heat:** Keep the system away from heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- **Cleaning:** Clean only with a dry cloth.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Klipsch ProMedia Lumina Subwoofer
- 2 x Satellite Speakers (Left and Right)
- 1 x Bluetooth Speaker (This is listed as "Included Components" in the product data, but typically refers to the system's Bluetooth capability rather than a separate speaker unit. The system itself has Bluetooth functionality.)
- Power Cable
- Speaker Connection Cables

- USB-C Cable
- 3.5mm AUX Cable
- User Manual (this document)

PRODUCT OVERVIEW

The Klipsch ProMedia Lumina system consists of a powerful subwoofer and two satellite speakers, designed for a rich 2.1 audio experience. The system features integrated controls and multiple connectivity options.



Figure 1: The complete Klipsch ProMedia Lumina 2.1 speaker system, showing the central subwoofer unit flanked by two satellite speakers. The speakers are black with silver accents and sit on small stands.

Satellite Speakers

The two satellite speakers feature a re-envisioned cabinet design with tiltable stands for optimal sound projection. They are equipped with Microtracrix horn tweeters for pinpoint clarity.



Figure 2: A close-up front view of the two Klipsch ProMedia Lumina satellite speakers, highlighting their black finish, silver base, and speaker cones.



Figure 3: A rear view of the two Klipsch ProMedia Lumina satellite speakers, showing the various ports and controls on their back panels. The left speaker has a settings button and a headphone jack, while the right speaker has a USB-C port and a power/Bluetooth button.

Subwoofer

The low-profile subwoofer delivers powerful low-end punch. It features an adjustable gain knob and cable management design for minimal floor space and maximum impact.



Figure 4: A side view of the Klipsch ProMedia Lumina subwoofer, showcasing its compact design and textured black finish.

Your browser does not support the video tag.

Video 1: An official product video from Klipsch showcasing the ProMedia Lumina Computer Speakers with LED Lighting. The video highlights the design and lighting features of the speaker system.

SETUP

Follow these steps to set up your Klipsch ProMedia Lumina speaker system:

1. **Placement:** Place the subwoofer on the floor or a sturdy surface near your computer. Position the satellite speakers on either side of your monitor, ensuring they are at ear level for the best audio experience.
2. **Connect Satellite Speakers:** Connect the left and right satellite speakers to the corresponding outputs on the back of the subwoofer using the provided speaker cables. Ensure a secure connection.
3. **Connect to Audio Source:**

- **USB-C:** Connect the USB-C cable from your computer to the USB-C input on the right satellite speaker.
- **AUX (3.5mm):** Connect the 3.5mm AUX cable from your audio source (e.g., computer, smartphone) to the AUX input on the left satellite speaker.
- **Bluetooth:** For wireless connection, ensure Bluetooth is enabled on your device and the speaker system. Press and hold the power/Bluetooth button on the right satellite speaker to enter pairing mode. Select "Klipsch ProMedia Lumina" from your device's Bluetooth settings.

4. **Power Connection:** Connect the power cable to the subwoofer and then plug it into a wall outlet.

5. **Power On:** Press the power/Bluetooth button on the right satellite speaker to turn on the system.



Figure 5: The Klipsch ProMedia Lumina speaker system integrated into a gaming desktop setup, showing the satellite speakers flanking a monitor and the subwoofer placed discreetly.

OPERATING

Once your system is set up, you can begin enjoying your audio. The main controls are located on the subwoofer and the right satellite speaker.

Basic Controls

- **Volume:** Use the volume knob on the subwoofer to adjust the overall sound level.
- **Treble/Bass:** Adjust the treble and bass knobs on the subwoofer to fine-tune your audio preferences.
- **Input Selection:** Use the input button (if available on the subwoofer or remote) to switch between connected sources (USB-C, AUX, Bluetooth).

Klipsch Control App

Enhance your experience with the Klipsch Control desktop app, available on all app stores. The app allows for precision command over various settings:

- **EQ Customization:** Adjust equalization settings to match your audio content.
- **Lighting Modes:** Customize RGB lighting effects, including night mode and music react mode.
- **Feature Control:** Access additional features and settings for personalized audio.



Figure 6: A laptop screen displaying the Klipsch Control App interface, with a satellite speaker visible next to it, illustrating the app's role in customizing the speaker system.



Figure 7: The rear of the Klipsch ProMedia Lumina satellite speakers displaying different customizable light patterns, showcasing the RGB lighting effects.

MAINTENANCE

To ensure the longevity and optimal performance of your Klipsch ProMedia Lumina system, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the speakers and subwoofer. Avoid using abrasive cleaners, waxes, or solvents.
- **Dusting:** Regularly dust the speaker grilles and vents to prevent dust buildup, which can affect sound quality and ventilation.
- **Cable Management:** Keep cables organized and untangled to prevent damage and ensure a tidy setup.
- **Environmental Conditions:** Avoid exposing the system to extreme temperatures, high humidity, or direct sunlight.

TROUBLESHOOTING

If you encounter any issues with your speaker system, refer to the following common troubleshooting steps:

Problem	Solution
No Sound	<ul style="list-style-type: none">• Ensure the system is powered on and the volume is turned up.• Check all cable connections (power, satellite speakers, audio source).• Verify the correct audio input source is selected.• Check your computer's audio output settings.

Problem	Solution
Static or Distortion	<ul style="list-style-type: none">• Reduce the volume of the audio source and the speaker system.• Ensure all cables are securely connected and not damaged.• Move the speakers away from other electronic devices that might cause interference.
Bluetooth Pairing Issues	<ul style="list-style-type: none">• Ensure the speaker system is in Bluetooth pairing mode.• Disable and re-enable Bluetooth on your device.• Forget the device from your Bluetooth list and try pairing again.• Ensure your device is within range of the speakers.

SPECIFICATIONS

Feature	Detail
Model Name	Klipsch ProMedia Lumina
Item Model Number	1073625
Speaker Type	Computer Speaker
Audio Output Mode	Surround
Connectivity Technology	Bluetooth (5.3), USB-C, AUX (3.5mm)
Special Feature	LED Light (Customizable RGB)
Speaker Maximum Output Power	10 Watts
Frequency Response	20 Hz
Product Dimensions	6.5"D x 4"W x 9.75"H
Item Weight	13.1 Pounds
Color	Black

WARRANTY AND SUPPORT

Klipsch products are designed for years of enjoyment. For warranty information and technical support, please refer to the official Klipsch website or contact their customer service. Keep your proof of purchase for any warranty claims.