

[Manuals.plus](#) /

› [Bellemave](#) /

› Bellemave Twin Over Twin Bunk Bed with Storage - Instruction Manual

Bellemave LT167AAP-1

Bellemave Twin Over Twin Bunk Bed with Storage - Instruction Manual

Model: LT167AAP-1

1. PRODUCT OVERVIEW

The Bellemave Twin Over Twin Bunk Bed with Storage is designed to maximize space and functionality in any bedroom. This sturdy wood loft bed features a twin-sized upper bunk and a twin-sized lower bunk, complemented by an integrated storage unit. The storage unit includes four spacious drawers and three open shelves, providing ample room for organizing books, toys, clothes, and other personal items. Constructed from solid pine wood, plywood, and MDF, this bunk bed ensures stability and durability for long-term use. Its versatile design makes it suitable for children, teenagers, and adults, offering a practical and aesthetic solution for various living spaces.



Image 1: Bellemave Twin Over Twin Bunk Bed with Storage in Espresso.

2. SAFETY INFORMATION

Please read and follow all safety warnings and instructions carefully to prevent injury. Keep this manual for future reference.

- **Age Restriction:** The upper bunk is not suitable for children under 6 years of age.
- **Guardrails:** Always use the guardrails on the upper bunk. Ensure they are properly installed and secured.
- **Mattress Size:** Use only mattresses that meet the recommended thickness and dimensions for each bunk. For the upper bed, a 6-inch thick mattress is recommended. For the bottom bed, an 8-inch thick mattress is recommended.
- **Weight Capacity:** Do not exceed the maximum weight capacity for each bunk. Upper bed: 350 LBS. Bottom bed: 300 LBS.
- **No Jumping:** Do not allow jumping on the bed.

- **Ladder Safety:** Always use the ladder for entering and exiting the upper bunk. Ensure the ladder is securely attached.
- **Assembly:** Assemble the bed strictly according to the instructions. Ensure all connections are tight before use. Periodically check and tighten all hardware.
- **Power Tools:** Avoid using power tools during assembly as they may overtighten fasteners and damage the wood.
- **Ventilation:** Ensure adequate ventilation around the bed.
- **Location:** Place the bunk bed against a wall to prevent accidental falls.

3. PACKAGE CONTENTS

Your Bellemave Twin Over Twin Bunk Bed is shipped in two packages. Please ensure you have received both packages and all components are present and undamaged before beginning assembly. Refer to the parts list provided in your physical assembly guide for detailed identification.

Expected Components:

- Bed frame components (headboards, footboards, side rails for upper and lower bunks)
- Ladder components
- Upper bunk guardrails
- Wood slats for upper bunk
- Storage unit components (panels for cabinet, drawer fronts, drawer sides, drawer bottoms)
- Drawer slides and handles
- Hardware pack (screws, bolts, nuts, washers, dowels, Allen wrench)

Note: If any parts are missing or damaged, do not proceed with assembly. Contact Bellemave customer support immediately for assistance.

4. ASSEMBLY INSTRUCTIONS

Assembly is estimated to take approximately 40 minutes with 2 people. All necessary tools are included. Please avoid using power tools to prevent damage to the wood components.

Pre-Assembly Checklist:

- Clear a spacious area for assembly.
- Lay out all components on a soft, clean surface to prevent scratches.
- Verify all parts are present using the package contents list.

General Assembly Steps:

1. **Assemble the Storage Unit:** Begin by assembling the cabinet frame for the drawers and shelves. Attach the side panels, back panel, and shelf dividers using the provided hardware. Install the drawer slides.
2. **Assemble Drawers:** Construct the four drawers by attaching the sides, front, and back panels to the drawer bottom. Install the drawer handles. Insert the completed drawers into the storage unit.
3. **Assemble Lower Bunk:** Attach the side rails to the headboard and footboard of the lower bunk. Ensure all

connections are secure.

4. **Assemble Upper Bunk:** Attach the side rails to the headboard and footboard of the upper bunk. Install the guardrails on all four sides of the upper bunk.
5. **Connect Bunks and Storage:** Carefully lift and position the upper bunk onto the lower bunk frame. Secure the upper bunk to the lower bunk and to the assembled storage unit using the designated hardware.
6. **Install Ladder:** Attach the ladder to the bunk bed frame. The ladder can be installed on either side of the bed as per your preference. Ensure it is firmly secured.
7. **Install Slats:** Place and secure the wood slats onto the upper bunk frame. The bottom bed does not require slats as the mattress rests directly on the floor or a separate foundation (not included).
8. **Final Check:** Once assembly is complete, double-check all bolts, screws, and connections to ensure they are tight and secure.



Image 2: Detailed dimensions for assembly and planning.

5. OPERATING INSTRUCTIONS

This bunk bed is designed for sleeping and storage. Follow these guidelines for proper use:

- **Using the Bunks:** The upper bunk is accessed via the attached ladder. Ensure the ladder is stable before climbing. The lower bunk is easily accessible from the side.
- **Storage Drawers:** The four drawers are designed for smooth operation. Pull them out gently to access contents and push them in fully to close. Avoid overloading the drawers to prevent damage to the slides.
- **Storage Shelves:** The three open shelves provide convenient access to items. Distribute weight evenly across the shelves.
- **Weight Distribution:** Ensure weight is distributed evenly on both bunks and within the storage compartments to maintain stability.

6. MAINTENANCE

Regular maintenance will help prolong the life and appearance of your bunk bed.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) check all bolts, screws, and connections. Tighten any loose hardware to ensure the bed remains stable and safe.
- **Wood Care:** Protect the wood from direct sunlight and extreme temperature changes to prevent warping or fading. Use coasters or pads under items placed on the top surface of the storage unit to prevent scratches.
- **Drawer Slides:** If drawers become stiff, apply a small amount of silicone lubricant to the drawer slides.

7. TROUBLESHOOTING

If you encounter issues with your bunk bed, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Bed feels wobbly or unstable.	Loose hardware connections.	Carefully re-tighten all bolts and screws throughout the entire bed frame and storage unit. Ensure all components are properly aligned.
Drawers do not slide smoothly.	Overloaded drawer, misaligned slides, or debris in slides.	Reduce the weight in the drawer. Check if the drawer is properly seated on its slides. Clean any dust or debris from the slides. Apply a silicone lubricant if necessary.
Missing parts during assembly.	Packaging error or lost during transit.	Do not proceed with assembly. Contact Bellemave customer support with your purchase details and the specific missing part number from the manual.

Problem	Possible Cause	Solution
Squeaking noises.	Loose connections or friction between wood parts.	Tighten all hardware. If squeaking persists, disassemble and reassemble the problematic section, ensuring all joints are flush.

If you experience issues not listed here or require further assistance, please contact Bellemave customer support.

8. SPECIFICATIONS

Detailed specifications for the Bellemave Twin Over Twin Bunk Bed with Storage:

Feature	Detail
Product Type	Bunk Bed
Size	Twin Over Twin
Color	Espresso
Overall Product Dimensions	92.4"L x 41.8"W x 50.6"H
Material	Plywood, MDF, Pinewood
Upper Bed Weight Capacity	350 LBS
Bottom Bed Weight Capacity	300 LBS
Recommended Upper Mattress Thickness	6 inches
Recommended Bottom Mattress Thickness	8 inches
Number of Slats (Upper Bed)	14
Box Spring Required	No
Assembly Required	Yes
Estimated Assembly Time	40 minutes
Suggested Number of People for Assembly	2
Additional Tools Required	None (All tools included)
Country of Origin	Vietnam

9. WARRANTY AND SUPPORT

Bellemave is committed to providing high-quality products. For any questions regarding assembly, missing parts, product defects, or general inquiries, please contact Bellemave customer support. Refer to your purchase documentation for specific warranty details and contact information.

When contacting support, please have your model number (LT167AAP-1) and purchase date available to expedite assistance.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G1Y7BPMJ>

More documents and user manuals: <https://manuals.plus/>