



[Manuals.plus](#) /

› [Lenovo](#) /

› [Lenovo ThinkPad E16 Business Laptop User Manual](#)

Lenovo ThinkPad E16

Lenovo ThinkPad E16 Business Laptop User Manual

Model: ThinkPad E16

Brand: Lenovo

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Lenovo ThinkPad E16 Business Laptop. Please read this manual thoroughly to ensure proper usage and to maximize the performance and longevity of your device.

Intuitive User Experience
Features like the TrackPoint Quick Menu and Tap-to-Select make multitasking and navigation simple on the ample display.

Up To **2TB**
PCIe M.2 SSD

Up To **64GB**
DDR5 SODIMM RAM

ThinkPad E16
Lenovo

Enjoy the Audiovisuals
Enjoy the Harman- and Dolby-optimized audio and rely on AI-based noise cancellation.

AMD RYZEN
AMD Ryzen 7 7735U
AMD Radeon Graphics

Windows 11 Pro

Figure 1.1: Lenovo ThinkPad E16 Business Laptop

2. SETUP

2.1 Unpacking and Initial Inspection

Carefully remove all components from the packaging. Verify that all items listed in the 'What's in the Box' section are present and undamaged. If any items are missing or damaged, contact your vendor immediately.

2.2 Connecting to Power

1. Connect the power adapter to the laptop's USB-C power port.
2. Plug the power adapter into a grounded electrical outlet.
3. Allow the battery to charge for at least 30 minutes before initial use, or until the battery indicator shows a sufficient charge.

2.3 Initial Boot-Up and Windows 11 Pro Setup

Press the power button to turn on your laptop. Follow the on-screen instructions to complete the Windows 11

Pro setup, including language selection, network connection, and user account creation.

2.4 Connecting Peripherals

Your ThinkPad E16 offers various ports for connecting external devices:




Figure 2.1: Laptop Ports and Slots

- **USB-A (USB 5Gbps, USB 10Gbps):** Connect USB devices such as the bundled wireless mouse receiver, external hard drives, or printers.
- **USB-C (USB 5Gbps, PD / DP 1.4, USB 10Gbps, PD / DP 1.4):** For power delivery, data transfer, and display output.
- **Ethernet (RJ45):** For wired network connection.
- **HDMI 2.1:** Connect to an external monitor or TV.
- **Headphone / mic combo (3.5mm):** For audio input/output.
- **Kensington Nano Security Slot:** For physical security locking.

2.5 Wi-Fi 6 Connection

During Windows setup, you will be prompted to connect to a Wi-Fi network. Select your network and enter the password. Your laptop supports Wi-Fi 6 for fast and reliable wireless connectivity.

2.6 Fingerprint Reader Setup

To enhance security, set up the integrated fingerprint reader through Windows Hello in your system settings. This allows for quick and secure login.

2.7 Bundled Accessories

Your laptop includes an A-DATA UC310 64GB USB Flash Drive and a Thunderobot ML101 Wireless Mouse. The USB drive provides additional storage and data transfer capabilities. The wireless mouse connects via a USB nano receiver for convenient navigation.



Figure 2.2: A-DATA UC310 64GB USB Flash Drive

3. OPERATING YOUR LAPTOP

3.1 Keyboard and Input Devices

The ThinkPad E16 features a backlit keyboard for comfortable typing in various lighting conditions. Utilize the TrackPoint Quick Menu and Tap-to-Select features for efficient navigation. The larger touchpad also enhances user interaction.

Intuitive User Experience

Features like the TrackPoint Quick Menu and Tap-to-Select make multitasking and navigation simple on the ample display. Typing is comfortable even in low light, thanks to the full-sized, keyboard. And the bigger touchpad enhances not only productivity, but the overall user experience. All with AI-based intelligent performance tuning.



Figure 3.1: Keyboard and Touchpad Features

3.2 Display Features

The 16-inch FHD+ (1920x1200) IPS anti-glare touchscreen display offers clear visuals. Its 16:10 aspect ratio provides more vertical screen space, beneficial for productivity. The 300-nit brightness and TÜV Low Blue Light certification contribute to reduced eye strain during extended use.



Figure 3.2: Display Specifications

3.3 Audio and Visuals

Experience Harman- and Dolby-optimized audio for enhanced sound quality. The AI-based noise cancellation feature improves clarity during video conferences and multimedia consumption.

Enjoy the Audiovisuals

The large display's aspect ratio is great for business apps, showing more pixels per screen. Choose from a rich selection of panels. Enjoy the Harman- and Dolby-optimized audio and rely on AI-based noise cancellation, background blurring, and more during video conferences.

16" FHD+ **1920*1200**

Figure 3.3: Audiovisual Experience

3.4 Performance

Powered by the AMD Ryzen 7 7735U processor with 8 cores and 16 threads, the laptop delivers responsive performance for everyday productivity, multitasking, and business workflows. The 32GB DDR5 RAM ensures smooth operation across multiple applications, and the 1TB PCIe NVMe M.2 Solid State Drive provides fast boot-up times and quick data access.



Figure 3.4: AMD Ryzen 7 Processor

4. MAINTENANCE

4.1 Cleaning Your Laptop

- Use a soft, lint-free cloth dampened with water or a screen cleaner to clean the display.
- Wipe the keyboard and chassis with a slightly damp cloth. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive cleaners.

4.2 Software Updates

Regularly check for and install operating system updates (Windows Update) and driver updates (Lenovo Vantage or Lenovo Support website) to ensure optimal performance and security.

4.3 Battery Care

- Avoid fully discharging the battery frequently.
- Store the laptop in a cool, dry place when not in use for extended periods.
- For optimal battery health, avoid continuous charging at 100% for long durations.

4.4 Security Features

The ThinkPad E16 incorporates several security features to protect your data:




Figure 4.1: Top-notch Security Features

- **ThinkShield Security Suite:** A comprehensive suite of security solutions.
- **Fingerprint Reader:** For biometric authentication.
- **dTPM (Discrete Trusted Platform Module):** Safeguards critical data with encryption.
- **Webcam Privacy Shutter:** Physically blocks the webcam for privacy.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your ThinkPad E16. For more detailed troubleshooting, refer to the Lenovo support website.

5.1 Power Issues

- **Laptop does not turn on:** Ensure the power adapter is securely connected and the outlet is functional. Check the battery charge level.
- **Battery not charging:** Verify the power adapter is working. Try a different outlet.

5.2 Display Issues

- **No display or blank screen:** Connect an external monitor to check if the issue is with the laptop's display. Adjust brightness settings.
- **Flickering screen:** Update graphics drivers. Check display cable connections if using an external

monitor.

5.3 Connectivity Issues

- **Wi-Fi not connecting:** Ensure Wi-Fi is enabled. Restart your router and laptop. Re-enter Wi-Fi password.
- **USB devices not recognized:** Try a different USB port. Update USB drivers.

5.4 Performance Issues

- **Slow performance:** Close unnecessary applications. Check for background processes. Ensure sufficient free storage space.
- **Overheating:** Ensure ventilation vents are clear. Use the laptop on a hard, flat surface.

6. SPECIFICATIONS

Feature	Specification
Brand	Lenovo
Model Name	ThinkPad E16
Processor	AMD Ryzen 7 7735U (8 Cores, 16 Threads, up to 4.75 GHz)
Graphics	AMD Radeon Graphics (Integrated)
RAM	32GB DDR5 RAM (5600 MHz)
Storage	1TB PCIe NVMe M.2 SSD
Display	16-inch FHD+ (1920x1200) IPS Touchscreen, Anti-glare, 16:10 aspect ratio, 300nit, TÜV Low Blue Light certified, 60 Hz Refresh Rate
Operating System	Windows 11 Pro
Connectivity	Wi-Fi 6 (802.11ax), Ethernet (RJ45)
Ports	2x USB-A (5Gbps, 10Gbps), 2x USB-C (5Gbps, 10Gbps, PD/DP 1.4), 1x HDMI 2.1, 1x Headphone/Mic Combo, 1x Kensington Nano Security Slot
Special Features	Backlit Keyboard, Fingerprint Reader, Numeric Keypad, HD 720p RGB Webcam with privacy shutter
Color	Black
Dimensions (L x W x Thickness)	12.32" x 8.63" x 0.71"

7. WARRANTY AND SUPPORT

7.1 Warranty Information

Your Lenovo ThinkPad E16 comes with a 1-year manufacturer's warranty. Additionally, for upgraded RAM/SSD components, a 1-year warranty is provided by PCOnline US. Please retain your proof of purchase

for warranty claims.

7.2 Technical Support

For technical assistance, driver downloads, or further troubleshooting, please visit the official Lenovo Support website or contact their customer service. For issues related to the upgraded components, contact PCOnline US support.