

[Manuals.plus](#) /

› [Norelco](#) /

› Philips Norelco All-in-One 9000 Series Trimmer MG9580/40 Instruction Manual

Norelco MG9580/40

Philips Norelco All-in-One 9000 Series Trimmer (MG9580/40) Instruction Manual

Model: MG9580/40

INTRODUCTION AND OVERVIEW

The Philips Norelco All-in-One 9000 Series Trimmer is a versatile grooming tool designed for comprehensive care of the face, beard, head, and body. This 25-piece kit features durable, self-sharpening steel blades for long-lasting precision and offers 27 length settings, ranging from 0.5 mm to 20 mm, to achieve a wide array of styles. Powered by a robust lithium-ion battery, it provides up to 6 hours of cordless runtime and includes a convenient 5-minute quick charge option for immediate use. The trimmer is 100% showerproof, allowing for comfortable wet or dry grooming and effortless cleaning under running water.

WHAT'S IN THE BOX

Your Philips Norelco All-in-One 9000 Series Trimmer package includes the following components:

- 1x Philips Norelco All-in-One Trimmer 9000 Series
- 1x Full Metal Blade
- 1x Body Groomer
- 1x Nose Trimmer
- 1x Wide Hair Clipper
- Premium Precision Comb (with 11 length settings from 1 to 3 mm)
- Adjustable Beard & Hair Combs (3-20 mm)
- Eyebrow Comb
- Detail Trimmer
- Precision Shaver
- Skin Protect Comb
- Hair Combs (2-16 mm)
- Fading Hair Combs
- Body Combs (3-5 mm)
- Travel Lock
- Toiletry Bag
- Cleaning Brush

- USB-A Charging Cable (power adapter not included)

What's in the box




Image: All components included in the Philips Norelco All-in-One 9000 Series Trimmer kit, neatly arranged.

KEY FEATURES

Self-Sharpening Metal Blades

The trimmer is equipped with self-sharpening steel blades that maintain their sharpness for long-lasting precision, ensuring consistent performance without the need for blade oil.



Self-sharpening metal blades

Long-lasting performance with self-sharpening metal blades



Image: Detailed view of the self-sharpening metal blades, highlighting their precision design.

Premium Precision Comb

Achieve your desired look with the premium precision comb, offering 11 length settings in 0.2 mm steps from 1 to 3 mm for an ideal finish.



Premium precision comb

Delivers maximum precision with 11 length settings in 0.2mm steps



Image: The premium precision comb with its adjustable dial for fine-tuning length settings.

BeardSense Technology

This innovative technology scans beard density 125 times per second, automatically boosting power when needed to efficiently tackle even dense, bushy, or longer beards, ensuring an even trim.



BeardSense technology

Scans beard 125x times and
adapts power to beard
density for even trim on most
demanding beards



Image: Graphic representation of BeardSense technology in action, adapting to beard density.

Long-Lasting Battery & Quick Charge

The powerful lithium-ion battery provides up to 6 hours of runtime on a full charge. A 5-minute quick charge option delivers enough power for one trimming session, ensuring you're always ready.

PHILIPS

NORELCO

All-in-One 9000

25 in 1

All-in-One trimmer



Image: Visual guide to the trimmer's 6-hour runtime, 5-minute quick charge, and USB-A charging cable (adapter not included).

100% Showerproof Design

Designed for convenience, the trimmer is fully showerproof, allowing for comfortable wet or dry use and easy cleaning under the tap.



100% Showerproof

Comfortable and convenient
grooming, wet or dry



Image: The trimmer being cleaned under running water, demonstrating its showerproof capability.

SETUP

Charging the Trimmer

Before first use, fully charge your trimmer. Connect the provided USB-A charging cable to the trimmer's charging port at the bottom and plug the USB-A end into a compatible power adapter (not included). The battery indicator will show charging status. A full charge provides up to 6 hours of runtime.

Attaching and Detaching Trimmer Heads

To change trimmer heads, gently pull the currently attached head upwards to detach it from the main body. Select the desired attachment and align it with the motor shaft on the trimmer body. Push down firmly until you hear a click, indicating it is securely in place. Ensure the attachment is properly seated before use.

OPERATING INSTRUCTIONS

The Philips Norelco All-in-One Trimmer is designed for versatile grooming. Always ensure the trimmer is clean and charged before use.

General Trimming Tips

- For best results, use the trimmer on clean, dry hair.
- Move the trimmer against the direction of hair growth for an even cut.
- Apply light pressure and use smooth, controlled strokes.
- Start with a longer length setting and gradually reduce it to achieve your desired style.


Using Specific Attachments

- **Beard & Hair Trimming:** Use the full metal blade with the adjustable beard & hair combs or the premium precision comb to achieve various beard and hair lengths. The precision comb offers fine-tuned settings for detailed styling.
- **Nose & Ear Trimming:** Attach the nose trimmer head to safely and comfortably remove unwanted nose and ear hair without nicks or cuts.
- **Body Grooming:** Utilize the body groomer attachment or the precision shaver with the skin protect comb and body combs for gentle and effective trimming and shaving below the neck.
- **Detailing & Edging:** The detail trimmer and precision shaver are ideal for creating sharp lines and edges around your beard, sideburns, and hairline.


**One tool,
ultimate
precision**



Face



Hair



Body

Image: The Philips Norelco All-in-One Trimmer being used for various grooming tasks on the face, head, and body.

MAINTENANCE

Cleaning

The trimmer is 100% showerproof and can be easily cleaned under running tap water. After each use, detach the trimmer head and rinse it thoroughly. Use the provided cleaning brush to remove any trapped hairs from the blades and inside the trimmer body. Ensure all parts are dry before reassembling or storing. No blade oil is required for maintenance.

Storage

Store the trimmer and all its attachments in the provided toiletry bag to keep them organized and protected. Store in a dry place away from direct sunlight.

TROUBLESHOOTING

- **Trimmer not turning on:** Ensure the trimmer is fully charged. If the battery is low, connect it to the charger.
- **Poor trimming performance:** Clean the blades and attachments thoroughly to remove any accumulated hair or debris. Ensure the chosen attachment is correctly secured.
- **Skin irritation:** Ensure blades are clean and free from damage. Use the appropriate comb for sensitive areas, such as the skin protect comb for body grooming.
- **Attachments not fitting:** Verify that you are using the correct attachments for your model and that they are aligned properly before pushing them onto the trimmer body.

If issues persist after following these steps, please refer to the warranty and support information.

SPECIFICATIONS

Brand	Norelco
Model Name	Philips Norelco Multigroom Series 9000
Item Model Number	MG9580/40
Power Source	Battery Powered
Battery Type	Lithium-ion
Runtime	Up to 6 hours
Quick Charge	5-minute option for one trimming session
Blade Material	Stainless Steel
Waterproof	100% Showerproof
Length Settings	27 (0.5-20 mm)
Item Weight	1.23 Pounds
UPC	075020115300

WARRANTY AND SUPPORT

The Philips Norelco All-in-One 9000 Series Trimmer comes with a limited manufacturer's warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the documentation included with your product or visit the official Philips Norelco support website.

Optional protection plans are available for purchase to extend coverage beyond the manufacturer's warranty. These plans may include 2-Year, 3-Year, or Complete Protect options, offering additional peace of mind.

For customer support, technical assistance, or to inquire about replacement parts, please contact Philips Norelco directly through their official channels.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0G22HZTT9>

More documents and user manuals: **<https://manuals.plus/>**