

[Manuals.plus](#) /

› [Norelco](#) /

› Norelco Philips All-in-One 9000 Series Trimmer MG9575/49 Instruction Manual

Norelco MG9575/49

Norelco Philips All-in-One 9000 Series Trimmer (MG9575/49) Instruction Manual

Your comprehensive guide to precision grooming.

[Box](#) [Setup](#) [Operation](#) [Overview](#) [What's in the](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

PRODUCT OVERVIEW

The Norelco Philips All-in-One 9000 Series Trimmer (MG9575/49) is a versatile grooming tool designed for face, beard, head, and body. Featuring 23 attachments and self-sharpening full metal blades, it offers 29 length settings (0.5-16 mm) for precise styling. Its durable lithium-ion battery provides up to 6 hours of runtime, with a 5-minute quick charge option. The trimmer is 100% showerproof for convenient wet or dry use and easy cleaning.



Image: Norelco Philips All-in-One 9000 Series Trimmer (MG9575/49) main unit.

WHAT'S IN THE BOX

Your Norelco Philips All-in-One 9000 Series Trimmer comes with a comprehensive set of tools to meet all your grooming needs:

- 1x Philips Norelco All-in-One Trimmer 9000 Series (MG9575/49)
- 1x Full metal blade
- 1x Body groomer
- 1x Nose trimmer
- 1x Wide hair clipper
- Premium precision comb (with 11 length settings from 1 to 3 mm)
- Various hair combs (5x, 2-16 mm)
- Fading combs (2x)
- Body combs (2x, 3-5 mm)
- Skin Protect comb
- Cleaning brush

- USB-A charging cable (power adapter not included)
- Travel case



Image: All 23 pieces included in the Norelco Philips All-in-One 9000 Series Trimmer kit, neatly arranged.

SETUP AND CHARGING

Initial Charge

Before first use, fully charge your trimmer. Connect the provided USB-A charging cable to the charging port at the bottom of the trimmer and plug the USB-A end into a compatible power adapter (not included). The battery indicator will show charging status. A full charge provides up to 6 hours of runtime. A 5-minute quick charge offers enough power for one trimming session.




Image: Illustration of the USB-A charging cable and battery life indicators for the trimmer.

Attaching/Detaching Blades and Combs

To attach a blade or comb, align it with the trimmer head and press firmly until it clicks into place. To detach, gently pull the attachment away from the trimmer head. Ensure the trimmer is turned off before changing attachments.

OPERATING INSTRUCTIONS

The Norelco Philips All-in-One 9000 Series Trimmer is designed for versatile grooming across your face, beard, head, and body. Always ensure your skin is clean and dry before trimming, unless using the showerproof feature.

General Trimming

- **Power On/Off:** Press the power button located on the handle to turn the trimmer on or off.
- **Selecting Length:** Use the premium precision comb for fine adjustments (11 settings from 1 to 3 mm in 0.2 mm steps). For longer lengths, select one of the various hair, fading, or body combs (0.5-16 mm).
- **Trimming Technique:** For best results, move the trimmer against the direction of hair growth. Apply

light pressure and use smooth, even strokes.



Premium precision comb

Delivers maximum precision with 11 length settings in 0.2mm steps



Image: Close-up of the premium precision comb, showing its adjustable length settings for accurate trimming.

BeardSense Technology

The trimmer features BeardSense technology, which scans beard density 125 times per second and automatically boosts power when needed. This ensures an even and consistent trim, even on dense, bushy, or longer beards, preventing pulling or snagging.



BeardSense technology

Scans beard 125x times and adapts power to beard density for even trim on most demanding beards



Image: Visual representation of BeardSense technology adapting power to beard density for an even trim.


Specific Attachments Usage

- **Full Metal Blade:** Ideal for sharp lines and detailing on your beard and hair.
- **Body Groomer & Skin Protect Comb:** Use for comfortable and effective trimming of body hair, protecting sensitive areas.
- **Nose Trimmer:** Gently insert the trimmer into your nostril or ear canal to remove unwanted hair without nicks or cuts.
- **Wide Hair Clipper:** Use with appropriate hair combs for maintaining hairstyles at home.


One tool,
ultimate
precision



Face



Hair



Body

Image: A man demonstrating the versatility of the trimmer for face, hair, and body grooming.

Your browser does not support the video tag.

Video: Official Philips Norelco video demonstrating the All-in-One Trimmer 9000 in use for various grooming tasks.

CARE AND MAINTENANCE

Cleaning

The Norelco Philips All-in-One 9000 Series Trimmer is 100% showerproof, allowing for easy cleaning. After each use, remove the attachment and rinse the blades and combs under running water. Use the provided cleaning brush to remove any stubborn hair particles. Ensure all parts are dry before reattaching or storing.



100% Showerproof

Comfortable and convenient
grooming, wet or dry



Image: The trimmer being rinsed under a faucet, highlighting its 100% showerproof design for easy cleaning.

Self-Sharpening Blades

The steel blades are self-sharpening, designed to maintain their precision and sharpness over time without the need for blade oil. This ensures long-lasting performance and consistent results.




Image: Detailed view of the self-sharpening metal blades, emphasizing their long-lasting performance.

Storage

Store the trimmer and all its attachments in the provided travel case to keep them organized and protected. Ensure the trimmer is dry before storing.

TROUBLESHOOTING

If you encounter any issues with your Norelco Philips All-in-One 9000 Series Trimmer, please refer to the following common solutions:

- **Trimmer not turning on:** Ensure the trimmer is fully charged. If the battery is completely depleted, it may take a few minutes of charging before the indicator lights up.
- **Poor trimming performance:**
 - Check if the blades or combs are clogged with hair. Clean them thoroughly.
 - Ensure the correct attachment is securely fitted.
 - The blades are self-sharpening, but if performance significantly degrades, contact customer support.
- **Battery not charging:**

- Verify the USB-A cable is properly connected to both the trimmer and the power adapter.
- Try a different USB-A power adapter or USB port.

PRODUCT SPECIFICATIONS

Feature	Detail
Model Number	MG9575/49
Brand	Norelco
Attachments	23 pieces (full metal blade, body groomer, nose trimmer, wide hair clipper, various combs)
Length Settings	29 (0.5-16 mm)
Blade Material	Alloy Steel (Self-sharpening)
Battery Type	Lithium-ion
Runtime	Up to 6 hours
Quick Charge	5-minute option for one trimming session
Charging	USB-A (adapter not included)
Waterproof	100% Showerproof
Item Weight	1.8 Pounds
Package Dimensions	9.61 x 6.3 x 4.76 inches

WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please visit the official Norelco Philips website or contact their customer service. Keep your purchase receipt as proof of purchase.

Online Support: [Visit the Norelco Store on Amazon](#)