Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

HOMCOM CA83A-432V80BK0231

HOMCOM 68-inch Pantry Cabinet with Charging Station Instruction Manual

Model: CA83A-432V80BK0231

1. Introduction

Thank you for choosing the HOMCOM 68-inch Pantry Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new kitchen storage unit. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information: Always secure the cabinet to the wall using the anti-tip kit provided to prevent tipping and potential injury. Ensure all connections are tight and stable before use.

2. Product Overview and Features

The HOMCOM Pantry Cabinet is designed to enhance your kitchen or dining area with versatile storage and a convenient charging station. Key features include:

- **Large Capacity & Flexible Storage:** Four cabinets and a drawer provide enclosed storage. Three adjustable shelves allow for customized organization, and four door spice racks offer easy access to smaller items.
- **Countertop Power Hub:** A spacious countertop is ideal for meal preparation or displaying kitchen appliances. The built-in power strip includes two US outlets, one USB port, and one USB-C port to keep your devices charged.
- **Timeless Country Charm:** Features arched doors, a beadboard design, and vintage alloy handles for an inviting, classic aesthetic that complements various home decors.
- **Seamless Access:** Cabinet doors are equipped with six electroplated alloy hinges for smooth operation, and four magnetic closures ensure secure closing. Silent drawer glides provide effortless and quiet drawer movement.
- **Reliable & Secure Build:** Constructed from MDF with painted doors and melamine-faced panels for durability and protection against dust and moisture. An anti-tip kit is included for enhanced safety.



Image: Overview of the pantry cabinet highlighting its large storage capacity, including four cabinets, a large drawer, a spacious countertop, and four door spice racks.



Image: Detail of the built-in charging station, showing USB ports (5V, 2A) and AC outlets (125V, 12A) for powering devices.



Image: Illustration of the 3-level adjustable shelves, demonstrating how they can be customized to fit items of different sizes.

3. Setup and Assembly

This cabinet requires assembly. Please follow the detailed instructions provided in the separate assembly guide included with your product packaging. Ensure all parts are present before beginning assembly.

3.1 Anti-Tipping Kit Installation

For safety, it is crucial to install the anti-tipping hardware. This prevents the cabinet from accidentally tipping over, especially in households with children or pets.

1. Locate the anti-tip kit components (brackets, screws, wall anchors).
2. Attach one bracket to the top rear edge of the cabinet using the provided screws.
3. Position the cabinet against the desired wall. Mark the wall through the hole in the second bracket, ensuring it aligns with the cabinet bracket.

4. Drill a pilot hole at the marked spot on the wall. Insert a wall anchor if necessary (for drywall).
5. Secure the second bracket to the wall using the appropriate screw.
6. Connect the two brackets with the provided strap or cable, ensuring it is taut.



Image: Detailed view of the anti-tipping hardware, showing how the bracket is secured to the cabinet and the wall for stability.

4. Operating Instructions

4.1 Using the Charging Station

The integrated power strip is located on the back panel of the countertop section. To use it:

1. Ensure the cabinet's power cord is securely plugged into a functional wall outlet.
2. Plug your appliances or devices into the available AC outlets or USB ports.
3. Do not overload the power strip. Refer to the specifications for maximum wattage.

4.2 Adjusting Shelves

The cabinet features adjustable shelves to accommodate items of various heights.

1. Empty the shelf you wish to adjust.
2. Carefully lift the shelf and remove the shelf pins from their current holes.
3. Reinsert the shelf pins into the desired new holes, ensuring they are level and fully seated.
4. Place the shelf back onto the pins.

4.3 Door and Drawer Operation

The cabinet doors open smoothly on electroplated alloy hinges and close securely with magnetic catches. The drawer operates on silent glides for quiet and easy access. Avoid forcing doors or drawers if they feel stiff; check for obstructions.

5. Maintenance

Proper care will extend the life and appearance of your HOMCOM pantry cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or moisture damage to the engineered wood and melamine panels.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Tighten as needed.
- **Environment:** Avoid placing the cabinet in direct sunlight or near heat sources, which can cause fading or warping.

6. Troubleshooting

If you encounter issues with your cabinet, refer to the following common solutions:

Problem	Possible Cause	Solution
Doors do not close properly	Misaligned hinges or magnetic catches. Obstruction.	Adjust hinge screws. Check for items blocking closure. Ensure magnetic catches are aligned.
Drawer sticks or is difficult to open/close	Misaligned glides. Obstruction.	Check that drawer glides are properly installed and aligned. Remove any items obstructing the drawer.
Cabinet feels wobbly	Loose fasteners. Uneven floor. Anti-tip kit not installed.	Tighten all assembly screws. Use shims under the base if the floor is uneven. Install the anti-tip kit as instructed.
Charging station not working	Power cord unplugged. Overload.	Ensure the cabinet's power cord is plugged into a live outlet. Reduce the number of devices plugged in. Check household circuit breaker.

7. Specifications

Feature	Detail
Brand	HOMCOM
Model Number	CA83A-432V80BK0231
Colour	Black
Product Dimensions	40D x 100W x 173H Centimetres (15.7D x 39.4W x 68.1H inches)
Maximum Weight Capacity	260 Pounds

Feature	Detail
Material	Engineered Wood, Melamine
Special Features	Adjustable Shelf, Anti-Tipping, Built-In Charging Station, Scratch Resistant
Item Weight	47.2 kg (104.06 lbs)
Recommended Uses	Crockery, Kitchen Storage
Mounting Type	Floor Mount (with anti-tip wall attachment)
Style	Farmhouse
Room Type	Dining Room, Kitchen, Living Room
Door Style	Shaker

8. Warranty and Support

This HOMCOM product is manufactured by Aosom Canada. For warranty information, product support, or to inquire about replacement parts, please contact Aosom Canada directly.

- **Manufacturer:** Aosom Canada
- **Place of Business:** Markham, Ontario, CA
- **Telephone:** 1-416-792-6088
- **Return Policy:** Eligible for Return or Refund within 30 days of receipt.

9. Product Video

Watch this short video for a visual overview of the HOMCOM Pantry Cabinet's features and functionality.

Your browser does not support the video tag.

Video: A brief demonstration showcasing the various storage compartments, the charging station, and the overall design of the HOMCOM pantry cabinet.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G23Q66GJ

More documents and user manuals: **https://manuals.plus/**