

HITWAY BK6SPLUS

HITWAY Electric Bicycle Lock Instruction Manual

Model: BK6SPLUS

INTRODUCTION

Thank you for choosing the HITWAY Electric Bicycle Lock. This universal accessory is designed to provide enhanced security for your electric bicycle, specifically compatible with the BK6SPLUS model. Please read this manual carefully before installation and use to ensure proper function and longevity of your lock.

SETUP AND INSTALLATION

The HITWAY Electric Bicycle Lock is designed for easy installation on your BK6SPLUS electric bicycle frame. Follow these steps for secure attachment:

- 1. Unpack the Lock:** Carefully remove all components from the packaging. You should have the lock unit and a frame mounting bracket.
- 2. Attach the Mounting Bracket:** Identify a suitable location on your bicycle frame, typically the seat post or down tube, where the bracket can be securely fastened without obstructing pedaling or other bike functions. Use the provided screws or straps to firmly attach the bracket. Ensure it is stable and does not move.
- 3. Insert the Lock into the Bracket:** Slide the lock unit into the mounting bracket until it clicks securely into place. Verify that the lock is held firmly by the bracket and does not rattle during movement.
- 4. Set Your Combination:** The lock comes with a preset combination (usually 0000 or similar). To set your personal combination, locate the reset button or dial (refer to the specific lock design, often a small button on the side or bottom). Press and hold the reset button, then rotate the number wheels to your desired 4-digit combination. Release the reset button. **Important:** Memorize your new combination immediately. Do not write it down where it can be easily found.



Image: The HITWAY Electric Bicycle Lock, shown securely mounted to a bicycle frame. The lock features a robust cable and a combination dial for security.

OPERATING INSTRUCTIONS

Using your HITWAY Electric Bicycle Lock is straightforward:

1. To Lock Your Bicycle:

- Find a secure, immovable object (e.g., a bike rack, lamppost).
- Thread the cable through the frame of your bicycle and around the immovable object. Ensure the cable also passes through at least one wheel for added security.
- Insert the end of the cable into the locking mechanism.
- Scramble the combination numbers to secure the lock.

2. To Unlock Your Bicycle:

- Align the number wheels to your personal 4-digit combination.
- Pull the cable end out of the locking mechanism.
- Remove the cable from your bicycle and the immovable object.

MAINTENANCE

Regular maintenance will ensure your HITWAY Electric Bicycle Lock remains in optimal working condition:

- **Cleaning:** Wipe the lock body and cable with a damp cloth to remove dirt and grime. Avoid harsh chemicals that may damage the finish or internal mechanisms.
- **Lubrication:** Periodically apply a small amount of silicone-based lubricant to the locking mechanism and combination wheels to ensure smooth operation. Do not over-lubricate.
- **Storage:** When not in use, store the lock in a dry environment to prevent rust and corrosion.
- **Check for Wear:** Regularly inspect the cable for any signs of fraying, cuts, or damage. Check the locking mechanism for any stiffness or unusual operation. Replace the lock if significant wear or damage is observed.

TROUBLESHOOTING

If you encounter issues with your HITWAY Electric Bicycle Lock, refer to the following common problems and solutions:

- **Lock is Stiff or Hard to Open/Close:**
 - Ensure the combination is correctly aligned.
 - Apply a small amount of lubricant to the combination wheels and locking mechanism.
 - Clean any dirt or debris from the mechanism.
- **Cannot Reset Combination:**
 - Ensure the lock is currently set to the correct previous combination before attempting to reset.
 - Verify you are pressing the reset button firmly and correctly according to the instructions.
- **Lock Appears Damaged:**
 - If the cable is cut or the mechanism is severely damaged, the lock's security may be compromised. It is recommended to replace the lock immediately.

SPECIFICATIONS

Feature	Detail
Brand	HITWAY
Model Compatibility	BK6SPLUS Electric Bicycle (Universal Accessory)
Type	Combination Cable Lock
Material	Metal (Cable and Locking Mechanism)
Color	Black
Locking Mechanism	4-Digit Resettable Combination
Mounting	Frame-mounted bracket included

Note: Specific dimensions for the lock are not provided in the product data. The lock is designed to be compact and

portable for bicycle use.

WARRANTY AND SUPPORT

Specific warranty information for this HITWAY accessory is not provided in the product details. For warranty claims, technical support, or further assistance, please contact HITWAY customer service directly or visit the official HITWAY website.

You can often find support information on the [HITWAY Brand Store on Amazon](#) or through the contact details provided with your purchase.