

[Manuals.plus](#) /

› [Zevemomo](#) /

› Zevemomo 5-Tier Glass Display Cabinet with Lights - Instruction Manual

Zevemomo Glass Display Cabinet

Zevemomo 5-Tier Glass Display Cabinet with Lights - Instruction Manual

Model: Glass Display Cabinet (2 Door-5 Tier-White)

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Zevemomo 5-Tier Glass Display Cabinet with Lights. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information: Do not exceed the weight limit of 110 lbs (50 kg). Secure the cabinet to the wall using the provided anti-tip device to prevent tipping. Always follow the assembly instructions for safe installation.

SETUP AND ASSEMBLY

The Zevemomo 5-Tier Glass Display Cabinet is designed for straightforward assembly. It is shipped in two separate packages and includes all necessary accessories and clear instructions for quick setup. An anti-tip device is included for enhanced stability and safety.

Package Contents

Before assembly, ensure all components are present:

- Tempered Glass Panels
- Wooden Top and Base Panels
- LED Lights and Remote Control
- Metal Handles
- Adjustable Feet
- Security Door Locks (with keys)
- Connectors and Fasteners
- Anti-Tip Device
- User Manual (this document)

Assembly Steps

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to

prevent scratches.

2. **Identify Parts:** Refer to the included parts list and diagrams to identify each component.
3. **Assemble Base:** Attach the adjustable feet to the wooden base panel.
4. **Install Side Panels:** Secure the tempered glass side panels to the base using the provided connectors.
5. **Insert Shelves:** Carefully slide the glass shelves into the designated slots.
6. **Attach Top Panel:** Secure the wooden top panel to the assembled structure.
7. **Install Doors:** Attach the glass doors and install the metal handles and security door locks.
8. **Connect LED Lights:** Install the LED lights in the top panel and connect them according to the wiring diagram.
9. **Secure Anti-Tip Device:** Attach the anti-tip device to the back of the cabinet and secure it to a wall stud. This step is crucial for safety.
10. **Final Check:** Ensure all connections are tight and the cabinet is stable.

Assembly Video Guide

For a visual guide on the assembly process, please refer to the video below:

Your browser does not support the video tag.

Video: Glass Display Cabinet Installation Guide. This video demonstrates the step-by-step assembly process for the Zevemomo glass display cabinet, including panel attachment, shelf insertion, and light installation.

Product Dimensions



Image: Product dimensions of the Zevemomo 5-Tier Glass Display Cabinet. The cabinet measures 30.91 inches in width, 13.58 inches in depth, and 73.74 inches in height. Each of the five shelves provides approximately 14.37 inches of vertical space.

Key Features

Applicable Scenarios



Image: Close-up details of the Zevemomo display cabinet, highlighting the integrated LED lights, security door lock, thickened wooden board construction, stainless steel handles, and adjustable feet for leveling.

OPERATING INSTRUCTIONS

LED Lighting System

The cabinet is equipped with LED lights located at the top, controlled by a remote. This system allows for selection of multiple colors to adjust the ambiance.

- **Power On/Off:** Press the "ON" or "OFF" button on the remote control to activate or deactivate the lights.
- **Color Selection:** Use the color buttons on the remote to choose your desired light color.
- **Brightness Adjustment:** Use the "+" and "-" buttons to increase or decrease the light intensity.
- **Mode Selection:** The remote may include buttons for various lighting modes (e.g., Flash, Strobe, Fade, Smooth) to create dynamic effects. Refer to the remote's specific markings for these functions.



Comes with A Remote for Easy Control of Lighting Modes

Image: The remote control for the LED lighting system, showing buttons for power, color selection, brightness adjustment, and various lighting modes. The cabinet is shown illuminated with different colors.

Security Door Locks

The cabinet features security door locks to protect your displayed items. Insert the key into the lock and turn to secure or unlock the doors.

MAINTENANCE

- **Cleaning Glass:** Use a soft, lint-free cloth and a glass cleaner to wipe glass surfaces. Avoid abrasive cleaners or materials that could scratch the glass.
- **Cleaning Wooden Panels:** Wipe wooden surfaces with a soft, damp cloth. Dry immediately. Avoid harsh chemicals.
- **Dusting:** Regularly dust all surfaces with a dry, soft cloth to prevent buildup.
- **Check Connections:** Periodically check all screws and connectors to ensure they remain tight. Tighten if necessary.
- **LED Lights:** The LED lights are designed for long life. If a light fails, contact customer support for replacement options.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Uneven floor; loose connections; anti-tip device not secured.	Adjust the leveling feet at the base. Tighten all assembly screws. Ensure the anti-tip device is properly installed and secured to a wall stud.

Problem	Possible Cause	Solution
LED lights do not turn on.	Power connection issue; remote control battery low; faulty LED strip.	Check if the power adapter is securely plugged in. Replace the remote control battery. If the issue persists, contact customer support.
Doors do not close properly.	Misaligned hinges; obstruction; cabinet not level.	Check hinge alignment and adjust if necessary. Remove any obstructions. Ensure the cabinet is level using the adjustable feet.

SPECIFICATIONS

Brand	Zeve momo
Model Name	Glass Display Cabinet
Style Name	2 Door-5 Tier-White
Color	White
Material	Tempered Glass, Wood
Product Dimensions (D x W x H)	13.58" x 30.91" x 73.74" (34.5 cm x 78.5 cm x 187.3 cm)
Item Weight	80 pounds (36.3 kg)
Weight Capacity (Maximum)	110 pounds (50 kg)
Number of Shelves	5
Number of Doors	2
Included Components	Glass doors, LED lights and remote control, Shelves, User Manual, Wooden panels, Anti-tip device
Features	Multi-color LED lighting, Lockable doors, Adjustable feet, Tempered glass



Image: A full front view of the Zevemomo 5-Tier Glass Display Cabinet, highlighting its five spacious shelves and double door design.

WARRANTY INFORMATION

Specific warranty details for the Zevemomo 5-Tier Glass Display Cabinet are typically provided with your purchase documentation. Please refer to the warranty card or contact the retailer for information regarding coverage and terms.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Zevemomo customer support through the retailer where the product was purchased. Please have your model number and purchase date available when contacting support.

Online Resources: For additional information and product updates, visit the official Zevemomo store [Zevemomo Store on Amazon](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question