

[Manuals.plus](#) /

> [InnoGear](#) /

> InnoGear Mic Stand Floor (Model TS325) Instruction Manual

InnoGear TS325

InnoGear Mic Stand Floor (Model TS325) Instruction Manual

Brand: InnoGear | Model: TS325

INTRODUCTION

Thank you for choosing the InnoGear Mic Stand Floor, Model TS325. This versatile and heavy-duty microphone stand is designed to provide stable and flexible microphone placement for various applications, including podcasting, streaming, recording, and live performances. Its modular design allows for multiple configurations, adapting to your specific needs. Please read this manual carefully to ensure proper assembly, operation, and maintenance of your new microphone stand.

PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Extendable Tube
- 2 x Height Tube
- 1 x Boom Arm
- 1 x Iron Base
- 1 x Mic Holder
- 1 x Mic Clip
- 1 x Fixing Knob
- 3 x Cable Clip
- 1 x 3/8" to 5/8" Adapter

MICROPHONE STAND FLOOR



Steady



Flexible



Compact



Image: All components of the InnoGear Mic Stand Floor, including tubes, boom arm, iron base, mic clips, and adapters.

SETUP AND ASSEMBLY

The InnoGear Mic Stand Floor offers a 3-in-1 versatile design, allowing for various configurations. Follow these steps for assembly:

- Assemble the Main Pole:** Screw the height tubes together and then attach them to the heavy cast iron base. Ensure all connections are tight for maximum stability.
- Attach the Boom Arm (Optional):** For extended reach and flexible microphone positioning, attach the boom arm to the main pole. The boom arm allows for 360° horizontal and vertical adjustment.
- Attach Microphone Clips/Adapters:** Depending on your microphone, use the provided 3/8" to 5/8" adapter or one of the two mic clips. The mic clips accommodate microphones with 1.18" to 2.36" outer diameter or a maximum 1.26" diameter.
- Cable Management:** Utilize the included cable clips to secure your microphone cable along the stand, ensuring a tidy and professional setup.

Your All-Scenes Stand

The one convertible floor stand that adapts to every age, stage, and setup.




Image: Demonstrates two primary installation options: with the boom arm for enhanced functionality and without the boom arm for a straightforward setup.

Stability Reminder:

For maximum stability, especially when the boom arm is extended, always center the arm over the iron base. This balances the microphone's weight and prevents tipping. Regularly check this alignment whenever you adjust your setup.

360° Flexible & Extendable



Image: Visual guide illustrating the importance of centering the boom arm over the base for optimal stability, especially when extended.

OPERATING AND ADJUSTMENTS

The InnoGear Mic Stand Floor offers extensive adjustability to suit various recording and performance scenarios:

- **Height Adjustment:** The stand can be configured in multiple heights:
 - **Desktop Mode:** Without height tubes, 17.6" to 29.0" (ideal for podcasting or low-profile miking).
 - **Standard Height:** With one height tube, 30.9" to 42.4" (for instruments or seated vocals).
 - **Maximum Height:** With all tubes, 44.3" to 55.8" (for standing vocals or overhead miking).

Adjust the height by loosening the appropriate knobs on the main pole, extending or retracting the sections, and then tightening the knobs securely.

- **Boom Arm Flexibility:** The boom arm provides full 360° horizontal and vertical adjustment. Additionally, mic clips offer an extra 180° of fine-tuning rotation, allowing you to capture the perfect audio angle from any position.
- **Microphone Compatibility:** The package includes a 3/8" to 5/8" adapter and two sizes of mic clips to ensure broad compatibility with popular microphones such as FIFINE AM8, HyperX SoloCast, HyperX QuadCast S, Razer Seiren V3 Mini, Blue Yeti, Shure SM58, Samson Q2U, and Fifine K669B.



Image: Illustrates the various height configurations from desktop to maximum height, highlighting arm extension and 360° rotation.

Compact Stand with Robust Stability & Durability

111 in² Coverage

Powder-coated to resist scratches, fading, and wear.



0.24" Sleek

Slim profile for easy, hidden storage.



Image: Demonstrates the high flexibility of the boom arm with 360° rotation and 180° mic clip adjustment for precise positioning.



Image: Details the included screw adapter, mic holder, and mic clip, along with examples of compatible microphones.

MAINTENANCE

To ensure the longevity and optimal performance of your InnoGear Mic Stand Floor, follow these maintenance guidelines:

- **Cleaning:** Wipe down the stand regularly with a soft, dry cloth to remove dust and debris. For stubborn dirt, use a slightly damp cloth and mild soap, then dry thoroughly. Avoid abrasive cleaners or solvents.
- **Joints and Knobs:** Periodically check all adjustable joints and knobs to ensure they are securely tightened. If any part feels loose, tighten it gently to prevent slippage or damage.
- **Storage:** When not in use, store the microphone stand in a dry, clean environment. Its modular design allows for compact disassembly, making storage convenient.

TROUBLESHOOTING

If you encounter any issues with your InnoGear Mic Stand Floor, refer to the following common troubleshooting tips:

- **Stand Tipping:** Ensure the boom arm is centered over the iron base, especially when extended. Verify that the base is on a flat, stable surface. If using a heavy microphone, consider adding additional weight to the base if necessary, though the 3.7 lb cast iron base is designed for substantial stability.
- **Boom Arm Slippage:** Check that all adjustment knobs on the boom arm are tightened securely. The rigid-grip shaft and robust tubing are designed to resist bending and vibration, but proper tightening is crucial.
- **Microphone Not Fitting:** Confirm you are using the correct mic clip or the 3/8" to 5/8" adapter. Ensure your microphone's dimensions are within the compatible range for the provided accessories.

PRODUCT SPECIFICATIONS

Brand	InnoGear
Model Number	TS325
Color	Black
Material	Alloy Steel
Base Type	Flat (3.7 lb cast iron base)
Maximum Height	55.8 Inches
Microphone Stand Thread Size	3/8 inch, 5/8 Inch
Included Components	Mic Clips, 3/8" to 5/8" adapter

WARRANTY INFORMATION

The InnoGear Mic Stand Floor comes with a 12-month warranty. For warranty claims or further details, please contact InnoGear customer support.

CUSTOMER SUPPORT

For any questions, technical assistance, or support regarding your InnoGear Mic Stand Floor, please visit the official InnoGear website or contact their customer service team. You can also refer to the [InnoGear Store on Amazon](#) for additional resources.