Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

STORAGE MANIAC IB-1005000082

STORAGE MANIAC Vertical Rolling Laundry Hamper

Model: IB-1005000082

1. Introduction

Thank you for choosing the STORAGE MANIAC Vertical Rolling Laundry Hamper. This 4-tier laundry sorter is designed to help you organize and transport your laundry efficiently, especially in compact living spaces. Its vertical design, multiple compartments, and rolling casters provide a practical solution for laundry management.



Image 1.1: The STORAGE MANIAC 4-Tier Vertical Rolling Laundry Hamper in a laundry room setting, with a user placing laundry into a basket.

2. Safety Information

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Assembly:** Keep small parts away from children during assembly. Ensure all connections are secure before use.
- **Weight Capacity:** Do not overload the baskets. Refer to the specifications for maximum capacity. Overloading may cause damage or instability.
- **Stability:** Always use the hamper on a flat, level surface. Engage the wheel brakes when the hamper needs to remain stationary.
- **Movement:** Exercise caution when moving the hamper, especially when full, to prevent tipping.
- **Maintenance:** Regularly check for loose parts and tighten as necessary.

3. Setup and Assembly

Follow these steps to assemble your laundry hamper:

1. **Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list (not provided in this manual, but typically included with product).
2. **Attach Casters:** Securely attach the four wheels (casters) to the designated holes on the base frame of the hamper. Ensure two of the casters with locking mechanisms are placed on the same side for easy access.
3. **Assemble Frame:** Connect the vertical support poles and horizontal crossbars according to the design. Ensure all screws or locking mechanisms are tightened to create a stable frame.
4. **Insert Baskets:** Place each of the four fabric laundry baskets into their respective tiers on the assembled frame. Ensure they are seated properly and securely.
5. **Final Check:** Confirm all connections are tight and the hamper is stable before first use.



Image 3.1: Detail view of the rust-resistant powder coating on the frame, the water-resistant inner lining of the baskets, and the 360-degree rotating wheels with locking brakes.

4. Operating Instructions

This section details how to effectively use your STORAGE MANIAC laundry hamper.

- **Sorting Laundry:** Utilize the four separate tiers to categorize your laundry. Common sorting methods include separating by color (lights, darks, colors) or by fabric type (towels, delicates).



Image 4.1: Visual guide for sorting clothes by type into the four distinct tiers of the hamper.

- **Easy Access:** The tilted opening design of each basket allows for convenient tossing in or grabbing out of laundry items.



Image 4.2: A close-up view demonstrating the slanted opening of a laundry basket for easy access.

- **Mobility:** The 360-degree rotating wheels allow you to effortlessly move the hamper between rooms, to the laundry area, or wherever needed.
- **Stability:** To keep the hamper stationary, engage the brakes on the two lockable casters. Push down the lever on the wheel to lock, and lift to unlock.

5. Maintenance

Proper care will extend the life of your laundry hamper.

- **Frame Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid abrasive cleaners that may damage the rust-resistant coating.
- **Basket Cleaning:** The woven fabric baskets feature a water-resistant inner lining. For minor spills or dirt, spot clean with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash or tumble dry the baskets.
- **Wheel Maintenance:** Periodically check the wheels for any accumulated lint or debris and remove it to ensure smooth rolling.

6. Troubleshooting

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hamper is unstable or wobbly.	Loose connections; uneven surface.	Ensure all screws and frame connections are tightened. Place the hamper on a flat, level surface.
Wheels are not rolling smoothly.	Brakes engaged; debris in wheels.	Disengage wheel brakes. Check wheels for lint, hair, or other debris and remove.
Baskets do not sit properly in the frame.	Incorrect placement; frame not fully assembled.	Ensure baskets are correctly aligned with the frame supports. Verify the frame is fully assembled and secure.

7. Specifications

Detailed product specifications for the STORAGE MANIAC Vertical Rolling Laundry Hamper.

Feature	Detail
Model Number	IB-1005000082
Product Dimensions (L x W x H)	20.5" x 13" x 62.5" (52.1 cm x 33 cm x 158.8 cm)
Capacity	42.3 gallons (160 Liters)
Number of Tiers	4
Color	Gray
Material	Woven Fabric (baskets), Metal (frame)
Special Features	Wheeled, Portable, Non-Slip, Handle (on frame)
Item Weight	4.42 kg (9.74 lbs)



Image 7.1: Dimensional overview of the hamper, highlighting its 62.5" height, 20.5" length, and 13" depth, along with its 160L capacity.

© 2023 STORAGE MANIAC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G25D66YC

More documents and user manuals: **https://manuals.plus/**