

[Manuals.plus](#) /

› [COZPAW](#) /

› COZPAW Corner Dog Crate Furniture Instruction Manual

COZPAW US-CZ-GL-2511-JG01-NE

COZPAW Corner Dog Crate Furniture Instruction Manual

Model: US-CZ-GL-2511-JG01-NE

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your COZPAW Corner Dog Crate Furniture. This versatile unit functions as both a comfortable dog kennel and a stylish piece of furniture, designed to fit seamlessly into corner spaces. Its robust construction ensures durability and stability for your pet.

Sturdy Iron Frame

Equipped with thick iron pipes to reduce chewing possibility



Easy Broken



Chew Resistance

Durable Design
Thick wooden boards and cross bold steel pipe



Image 1.1: The COZPAW Corner Dog Crate Furniture in a home environment.



Corner Shape Design

Better utilization of space, suitable for narrow corners

Image 1.2: The corner design optimizes space utilization.

Product Overview Videos



Video 1.1: A brief introduction to the COZPAW Corner Dog Crate Furniture, showcasing its features and design.



Video 1.2: An overall introduction to the product, highlighting its functionality and aesthetic appeal.

2. SAFETY INFORMATION

- Ensure all parts are securely fastened before allowing your pet to use the crate.
- Regularly inspect the crate for any loose or damaged components. Do not use if damaged.
- Place the crate on a level, stable surface to prevent tipping.

- Do not allow children to climb on or play inside the crate.
- Keep small children and pets away during assembly to avoid injury from small parts.
- This product is intended for indoor use only.
- Ensure the crate size is appropriate for your dog to stand, turn around, and lie down comfortably.


3. PARTS LIST

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Wooden Top Panels
- Metal Frame Sections
- Crate Door(s) with Latches
- Side Panels (Wood/Metal combination)
- Bottom Base
- Assembly Hardware (Screws, bolts, Allen wrench)
- Instruction Manual

4. SETUP AND ASSEMBLY

Please follow these steps carefully for proper assembly. It is recommended to have two people for assembly.



What should you do before ordering?

Step 1. Length

Measure the length from the nose to the tail by keeping your dog in normal standing.

Step 2. Height

Measure the height from the head to the paws by keeping your dog in normal sitting.

Warm Tips:

If you want your dog to stay comfortable, please measure them when laying down and stretching out like they normally sleep.




Image 4.1: Product dimensions for planning placement.



Image 4.2: Interior dimensions to ensure comfort for your pet.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Base Frame:** Connect the metal frame sections for the base using the provided hardware. Ensure all connections are snug but do not overtighten initially.
3. **Attach Side Panels:** Secure the side panels to the base frame. Pay attention to the orientation of the panels, especially those with wooden inserts.
4. **Install Crate Door(s):** Attach the crate door(s) to the designated openings using the hinges and hardware. Test the latch mechanism to ensure smooth operation.
5. **Place Top Panels:** Carefully position the wooden top panels onto the assembled frame. Secure them with the remaining hardware.
6. **Final Tightening:** Once all parts are assembled, go back and securely tighten all screws and bolts. Do not overtighten to avoid damaging the wood or stripping screws.
7. **Positioning:** Place the assembled crate in your desired corner location.

5. OPERATING INSTRUCTIONS

For Pet Confinement:

- Ensure the crate is placed in a comfortable, quiet area of your home.
- Place a soft bed or blanket inside for your pet's comfort.
- To open the door, unlatch the safety lock(s) and swing the door open.
- To close, gently push the door shut and engage the safety lock(s) to secure your pet.
- Never leave your pet unattended for extended periods, especially during initial training.



Image 5.1: A dog comfortably inside the crate.

As Furniture:

The sturdy wooden top can be used as an end table or TV stand. Avoid placing excessively heavy items on the top surface.

Multi-functional furniture-style dog crate


Can not only be used as a TV stand,
but also as a small coffee table and side table.



Image 5.2: The crate functions as a TV stand.

6. MAINTENANCE AND CARE

- **Cleaning the Wood Surfaces:** Wipe wooden surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish. Dry immediately with a clean cloth.
- **Cleaning the Metal Frame:** The metal frame can be cleaned with a damp cloth and mild soap. Rinse and dry thoroughly to prevent rust.
- **Pet Bedding:** Remove and wash pet bedding regularly according to its care instructions.
- **Inspection:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary.



Safety Lock



Easy to Clean



Round Corner Design



Scratch-resistant

Image 6.1: Features like easy-to-clean surfaces aid maintenance.

7. TROUBLESHOOTING

- **Crate feels wobbly:** Ensure all screws and bolts are fully tightened. Check that the crate is on a flat, even surface.
- **Door not closing properly:** Inspect hinges for damage or misalignment. Ensure no debris is obstructing the door path or latch mechanism.
- **Pet not adapting to the crate:** Introduce the crate gradually. Place familiar items like toys or blankets inside. Never use the crate as punishment. Consult a professional dog trainer if issues persist.
- **Scratches on wood surface:** Minor scratches can sometimes be minimized with wood repair markers or polishes. For deeper damage, contact customer support for advice.

8. SPECIFICATIONS



Image 8.1: Detail of material thickness for durability.

Feature	Detail
Brand	COZPAW
Model Name	US-CZ-GL-2511-JG01-NE
Product Dimensions (L x W x H)	52" x 29.1" x 29.9"
Internal Dimensions (L x W x H)	47.6" x 25.2" x 28.5"
Item Weight	212 Pounds
Material	Wood, Metal
Color	Cognac Brown
Specific Uses for Product	Indoor Pet Confinement, End Table, TV Stand

Breed Recommendation	Medium to Large Dogs (All Breed Sizes)
----------------------	--

9. WARRANTY AND SUPPORT

Warranty:

This product comes with a 30-day warranty from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

Customer Support:

For any questions, concerns, or issues regarding your COZPAW Corner Dog Crate Furniture, please contact our dedicated customer support team. We are committed to providing prompt responses and effective solutions to ensure your complete satisfaction.

Contact information can typically be found on the seller's page or your purchase documentation.

