

## Peiyuu Q30

# Peiyuu Q30 2-in-1 Rechargeable Fabric Shaver Instruction Manual

Model: Q30

## 1. INTRODUCTION

---

The Peiyuu Q30 Fabric Shaver is a versatile 2-in-1 device designed to refresh your garments and household fabrics. It combines an efficient electric fabric shaver for removing pills and fuzz with a built-in lint roller for a smooth finish. This rechargeable device features a powerful 6-blade system, multiple speed settings, and a digital display for ease of use. It is suitable for a wide range of materials, from delicate knits to heavier fabrics on furniture.



*Image: Peiyuu Q30 Fabric Shaver with its integrated lint roller.*

## 2. WHAT'S IN THE BOX

Upon unpacking, please ensure all items listed below are present:

- Fabric Shaver x 1
- Replacement Stainless Steel Blade x 2
- Refillable Lint Roller x 1 (Pre-installed)
- USB-C Cable x 1
- Cleaning Brush x 1

# WHAT'S IN THE BOX

- 1 Fabric shaver x 1
- 2 Replacement Stainless Steel Blade x 2
- 3 Refillable Lint Roller x 1(Already Installed)
- 4 USB-C Cable x 1
- 5 Clean Brush x 1
- 6 Use Mannual x 1




Image: All components included in the Peiyuu Q30 Fabric Shaver package.

## 3. SETUP

### 3.1 Charging the Device

Before first use, fully charge the fabric shaver. Connect the provided USB-C cable to the charging port on the device and plug the other end into a compatible USB power source (e.g., computer, wall adapter). The LED digital display will show the battery level (0-100%) and charging status. A full charge provides up to 3 hours of cordless use.



2600mAh Built-in  
Lithium Battery  
2H Fast Charging  
3H of Battery Life

## RECHARGEABLE LINT REMOVER

USB Charge  
Power Bank

*Image: Charging the Peiyuu Q30 Fabric Shaver using the USB-C cable.*

### 3.2 Installing/Replacing Blades

The device comes with a 6-leaf stainless steel blade pre-installed and two extra replacement blades. To replace a blade:

1. Ensure the device is turned off and unplugged.
2. Gently twist and remove the honeycomb mesh cover.
3. Carefully remove the old blade assembly.
4. Align the new blade assembly and press it firmly into place.
5. Reattach the honeycomb mesh cover by twisting it until it locks securely.

### 3.3 Attaching the Lint Roller

The refillable lint roller is integrated into the handle of the device. To use it, simply pull it out from the bottom of the handle. To reinsert, push it back into the handle until it clicks into place.

## 4. OPERATING INSTRUCTIONS

### 4.1 Power On/Off and Speed Adjustment


Press the power button once to turn on the device. The LED display will illuminate, showing the current battery level and speed mode. Press the button again to cycle through the three available speed settings (Level 1, Level 2, Level 3). Long-press the power button to turn off the device instantly.



*Image: LED Digital Display showing battery and speed settings.*

### 4.2 Using the Fabric Shaver

Lay the fabric flat on a hard, smooth surface. Gently glide the shaver head over the pilled or fuzzed area. Apply light pressure and move the shaver in circular motions or back and forth. Start with the lowest speed setting for delicate fabrics and increase as needed for thicker materials. The stainless steel honeycomb mesh protects the fabric from direct contact with the blades.



*Image: Fabric shaver in action, showing before and after results on a sweater.*

### **4.3 Using the Lint Roller**

After shaving, or for general lint removal, extend the lint roller from the handle. Roll it over the fabric to pick up any remaining fine fuzz, pet hair, or dust. Tear off used sheets as needed to expose a fresh adhesive surface.



*Image: The lint roller attachment collecting fuzz from fabric.*

#### **4.4 Safety Precautions**

- Do not press too hard on the fabric to avoid damage.
- Keep fingers and loose clothing away from the shaver head during operation.
- The device automatically stops if the mesh cover is loosened or removed, ensuring safety.
- Keep out of reach of children.

### **5. MAINTENANCE**

---

#### **5.1 Emptying the Lint Container**

The magnetic lint container cap allows for easy removal and reattachment. Simply pull off the cap to empty accumulated lint and fuzz. Ensure the cap is securely reattached before next use.

# Magnetic Lint Container

Easy to empty lint and reassemble



*Image: Removing the magnetic lint container for cleaning.*

## 5.2 Cleaning the Blades and Unit

Use the provided cleaning brush to remove any lint or debris from the blades and inside the shaver head. Do not rinse the unit or blades with water.

## 6. TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Check if the mesh cover is securely attached.
- **Poor shaving performance:** The lint container may be full and needs emptying. The blades might be dull and require replacement. Ensure the mesh cover is clean and free of debris.
- **Device stops unexpectedly:** The battery may be low, or the mesh cover might have become loose.

Recharge the device or reattach the cover securely.

## 7. SPECIFICATIONS

---

<b>Model Number</b>	Q30
<b>Brand</b>	Peiyuu
<b>Dimensions</b>	8.5 x 3.03 x 2.99 inches
<b>Item Weight</b>	10.5 ounces
<b>Battery</b>	2600mAh Rechargeable Li-ion (Built-in)
<b>Charging Time</b>	Approx. 2 hours
<b>Operating Time</b>	Up to 3 hours
<b>Blades</b>	6-leaf Stainless Steel (2 extra included)
<b>Speed Settings</b>	3 adjustable speeds
<b>Material</b>	Plastic
<b>Operation Mode</b>	Automatic

## 8. WARRANTY AND SUPPORT

---

For warranty information or product support, please refer to the contact details provided on the product packaging or visit the official Peiyuu website. Keep your purchase receipt as proof of purchase for any warranty claims.