

Pinmoco B0G29NGCW7

Pinmoco Electric Fireplace TV Stand (Model B0G29NGCW7) - Instruction Manual

1. SAFETY INFORMATION

Please read all safety instructions carefully before assembly and operation. Failure to follow these instructions may result in injury or damage to the product.

- Do not place heavy objects on the top shelf to prevent tip-over.
- Keep the fireplace at least 3 feet away from any flammable materials.
- Allow the fireplace to cool before touching any heated surfaces.
- Always unplug the unit before assembly or disassembly to prevent electrical shock.
- Keep the fireplace out of reach of children and pets.
- Do not use the fireplace in a damp or wet environment.
- The electric fireplace is ETL and FC certified and includes built-in timers and PTC overheating protection for enhanced safety.

2. PRODUCT OVERVIEW

The Pinmoco Electric Fireplace TV Stand is designed to accommodate TVs up to 70 inches, offering both entertainment and heating functionalities. It features a modern black marble texture design with integrated LED lighting.

Key Features:

- **Spacious Storage:** Includes a cabinet and 3-level adjustable LED open shelves for organizing media devices, games, and displaying decorative items.
- **Realistic Flames:** Offers 7 LED light colors and 20 dynamic modes for the flame visual, controllable via an integrated remote.
- **Modern Aesthetic:** Features a black marble texture with LED open spaces and clean-lined cabinets

with acrylic sides.

- **Efficient Heating:** The electric fireplace insert heats up to 400 square feet with an adjustable temperature range of 62°F to 92°F, controlled by a wireless remote or touch screen.
- **Enhanced Safety:** ETL and FC certified electric fireplace includes built-in timers and PTC overheating protection.





Image 2.1: Product dimensions and weight capacity. The stand measures approximately 63 inches in length and can support up to 200 lbs on the top surface.

Storage Cabinet for a Clutter-Free Look



Splice Panel Design for a Sleek Visual Touch



Open Shelves for Easy Access and Display

Image 2.2: Detailed view of the storage cabinet with a splice panel design and open shelves with 3-level adjustability for customizable storage.

3. ASSEMBLY INSTRUCTIONS

Assembly of the Pinmoco Electric Fireplace TV Stand requires careful attention to detail. It is recommended to have two people for assembly. All necessary hardware and tools are included.

Assembly Video Guide:

Your browser does not support the video tag.

Video 3.1: Official Pinmoco Fireplace TV Stand Installation Video. This video provides a step-by-step visual guide for assembling the TV stand and integrating the electric fireplace insert.

General Assembly Steps:

1. Unpack all components and verify against the parts list provided in the packaging.
2. Assemble the base frame of the TV stand using the designated screws and connectors.
3. Attach the side panels and internal dividers, ensuring all connections are secure.

4. Install the back panels and any necessary cable management features.
5. Secure the top panels to the assembled frame.
6. Install the electric fireplace insert into its designated compartment. Ensure proper wiring and secure fastening.
7. Attach the cabinet door and adjustable shelves.
8. For added stability and safety, secure the TV stand to the wall using the provided anti-tip hardware.

4. OPERATING INSTRUCTIONS

The electric fireplace and LED lighting features can be controlled via the integrated touch screen panel or the included wireless remote control.

Fireplace Operation:

- **Power On/Off:** Press the power button on the control panel or remote to turn the fireplace on or off.
- **Flame Settings:** Adjust flame colors (7 options), brightness (5 levels), and speed (5 settings) using the dedicated buttons on the remote or control panel.
- **Heating Function:** Activate the heater and set the desired temperature between 62°F and 92°F. The heater can warm areas up to 400 sq. ft.
- **Timer:** Utilize the built-in timer for automatic shut-off, ranging from 0.5 to 9 hours.
- **PTC Overheating Protection:** The unit is equipped with PTC overheating protection, which automatically shuts off the heater if it reaches an unsafe temperature.



Image 4.1: Remote control for the electric fireplace, showing options for 7 flame colors, 5 brightness levels, and 5 flame speed settings.

18" FIREPLACE INSERT



Safe for children
and pets



400 sq.ft
Heating Area



0.5-9
Hours Timer



Temperature Setting
From 62°F to 92°F



Overheat
Protection

Fireplace Flame and Heat Can Be Used Separately

Image 4.2: Features of the 18-inch fireplace insert, including 400 sq. ft. heating area, 0.5-9 hours timer, 62°F to 92°F temperature setting, and overheat protection.

LED Shelf Lighting:

The open shelves feature integrated LED lighting. Use the remote control to change LED colors and dynamic modes to suit your ambiance.

Product Feature Video:

Your browser does not support the video tag.

Video 4.3: Pinmoco LED Electric Fireplace TV Stand for TVs up to 70". This video showcases the various features and aesthetic appeal of the TV stand, including the LED lighting and fireplace effects.

5. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your TV stand and electric fireplace.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cleaning the Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Use a soft, dry cloth to wipe the exterior. Do not spray liquids directly into the unit.

- **Dusting:** Regularly dust the unit, especially around the air intake and exhaust vents of the fireplace, to maintain efficient heating.
- **Cord Management:** Periodically check power cords for any signs of damage or fraying. Keep cords neatly organized to prevent tripping hazards.

6. TROUBLESHOOTING

If you encounter any issues with your Pinmoco Electric Fireplace TV Stand, refer to the following common troubleshooting steps:

- **No Power:** Ensure the power cord is securely plugged into a working electrical outlet. Check the circuit breaker.
- **Fireplace Not Heating:** Verify that the heating function is activated and the temperature setting is above the ambient room temperature. Check for any obstructions in the air vents. The PTC overheating protection may have activated; allow the unit to cool down.
- **Flames Not Visible:** Ensure the flame effect is turned on and brightness is adjusted. Check if any internal components are obstructing the flame display.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the fireplace sensor.
- **Unstable Stand:** Recheck all assembly connections and tighten any loose screws. Ensure the stand is placed on a level surface. Utilize the anti-tip hardware for wall mounting.

If problems persist after attempting these steps, please contact customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	Pinmoco
Model Number	B0G29NGCW7
Color	Black
Style	Modern
Item Weight	67.7 pounds
Package Dimensions	37.68 x 16.97 x 12.99 inches
Assembled Height	20.87 inches
Assembled Width	13.78 inches
Assembled Length	62.99 inches
Heating Area	Up to 400 sq. ft.
Temperature Range	62°F to 92°F
Flame Colors	7
Flame Brightness Levels	5

Flame Speed Settings	5
Assembly Required	Yes

8. WARRANTY AND SUPPORT

Pinmoco products are designed for quality and durability. For specific warranty details, please refer to the documentation included with your purchase or contact Pinmoco customer support directly.

- **Returns:** This product is eligible for 30-day easy returns.
- **Customer Support:** For any questions, assistance, or to report issues, please contact Pinmoco Direct customer support.
- **Protection Plans:** Extended protection plans may be available for purchase.