

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [STRICH](#) /

› [STRICH Collapsible Piano Keyboard Stand & Bench Set Instruction Manual \(Models SKT-01 & SPB-M60\)](#)

STRICH SKT-01 & SPB-M60

STRICH Collapsible Piano Keyboard Stand & Bench Set Instruction Manual

Models: SKT-01 (Keyboard Stand) & SPB-M60 (Piano Bench)

INTRODUCTION

Thank you for choosing the STRICH Collapsible Piano Keyboard Stand and Bench Set. This set provides a stable, adjustable, and portable solution for your digital piano or keyboard. Designed for wide compatibility, it supports 54-key, 61-key, and 88-key instruments, ensuring an ergonomic playing experience. The stand and bench are constructed from high-strength aluminum alloy and reinforced plastic for durability and reliability.

This manual provides detailed instructions for assembly, operation, and maintenance to ensure optimal performance and longevity of your product.



Image: The STRICH keyboard stand and bench set supporting a digital piano in a home setting.

PACKAGE CONTENTS

- STRICH Collapsible Keyboard Stand (SKT-01)
- STRICH Adjustable Piano Bench (SPB-M60)
- Assembly Hardware (screws, washers, knobs)
- Instruction Manual

SETUP AND ASSEMBLY

Assembly of the STRICH Keyboard Stand and Bench Set is designed to be straightforward and typically

takes less than 20 minutes. Please follow the steps below carefully.

Keyboard Stand Assembly (SKT-01)

1. **Unfold the Stand:** Carefully unfold the main frame of the keyboard stand. Ensure all hinged parts are fully extended.
2. **Secure the Braces:** Lock the support braces into place. These braces provide the primary structural stability for the stand.
3. **Adjust Width:** Extend the horizontal support bars to the desired width to accommodate your keyboard. The stand is compatible with 54-key, 61-key, and 88-key digital pianos. Secure the width adjustment knobs.
4. **Adjust Height:** Adjust the height of the stand legs to your preferred playing position. The stand offers a height range of 22.8–27.6 inches. Secure the height adjustment knobs.
5. **Place Keyboard:** Position your digital piano or keyboard onto the stand. The top support arms feature high-density EVA foam padding to secure the instrument and reduce vibration.

COLLAPSIBLE DESIGN

Save 50% space, easy to carry and transport




Image: Visual guide for unfolding, securing, and adjusting the keyboard stand.

INSTALLATION INSTRUCTIONS



Image: Comprehensive diagram showing assembly steps for both the stand and bench.

Piano Bench Assembly (SPB-M60)

1. **Assemble H-Arm Bar Frame:** Attach the H-arm bar frame between the legs of the bench using the provided screws.
2. **Attach Leg Support to Saddle:** Connect the head of the leg support to the underside of the bench saddle.
3. **Assemble Foot Rod and Adjust Height:** Insert the foot rod and secure it with the knob. Adjust the bench height from 17.5–22 inches for comfortable seating.

EASY ASSEMBLY STEPS

Easy assembly in three steps



STEP 1:

THE H arm bar frame between the legs is assembled



STEP 2:

Link the head of the leg support to the saddle



STEP 3:

Finally, assemble the foot rod and knob and adjust the height

Image: Step-by-step visual guide for assembling the piano bench.

OPERATION

Adjusting the Keyboard Stand

- **Width Adjustment:** Loosen the width adjustment knobs located on the horizontal bars. Slide the bars to expand or contract the stand's width (28.7 to 42.1 inches) to fit your keyboard. Tighten the knobs securely once the desired width is achieved.
- **Height Adjustment:** Loosen the height adjustment knobs on each leg. Raise or lower the legs to set the stand's height (22.8–27.6 inches). Ensure both sides are adjusted evenly for a level playing surface. Tighten the knobs firmly.

FULLY ADJUSTABLE

Suitable for DJ equipment, keyboards, mixers, percussion tables



Image: Illustration of the adjustable dimensions for both the keyboard stand and bench.



Image: Detail showing how the keyboard stand's width can be adjusted.



Image: Detail showing the height adjustment feature of the keyboard stand legs.


Adjusting the Piano Bench

- **Height Adjustment:** Locate the height adjustment knob on the bench legs. Loosen the knob, adjust the bench to a comfortable height (17.5–22 inches), and then tighten the knob firmly to secure it.

Portability and Storage

The keyboard stand features a collapsible design for easy transport and storage. To collapse, loosen all adjustment knobs, fold the legs inward, and secure any locking mechanisms. This reduces the stand's storage space by over 50%.

INSTALLATION STEPS



STEP 1
UNFOLD



STEP 2
SECURE



STEP 3
ADJUST

Image: Visual representation of the keyboard stand's collapsible design for space-saving storage.

MAINTENANCE

- **Cleaning:** Wipe down the metal frame with a soft, damp cloth. For the padded bench seat, use a mild soap solution if necessary, and wipe dry immediately. Avoid abrasive cleaners or solvents.
- **Inspection:** Periodically check all screws, bolts, and adjustment knobs to ensure they are tight. Retighten as needed to maintain stability.
- **Storage:** When not in use, store the stand and bench in a dry environment to prevent rust or material degradation.

TROUBLESHOOTING

- **Stand is Wobbly:**

- Ensure all assembly screws and adjustment knobs are fully tightened.
- Verify that the stand is placed on a flat, stable surface.
- Check that the height adjustments on all legs are even.

- **Keyboard Slides on Stand:**

- Ensure the keyboard is centered and properly seated on the EVA foam padding.
- Verify the stand's width is adjusted snugly to the keyboard's dimensions.

- **Bench Feels Unstable:**

- Confirm all bench assembly screws and the height adjustment knob are securely tightened.
- Ensure the bench is on a level surface.

SPECIFICATIONS

Feature	Detail
Brand	STRICH
Model Numbers	SKT-01 (Stand), SPB-M60 (Bench)
Material	High-strength Aluminum Alloy, Reinforced Plastic, EVA Foam (Stand), High-quality Leather, High-density Soft Filler (Bench)
Keyboard Stand Width Adjustment	28.7 - 42.1 inches (73 - 107 cm)
Keyboard Stand Height Adjustment	22.8 - 27.6 inches (57.5 - 70 cm)
Piano Bench Height Adjustment	17.5 - 22 inches (44.5 - 56 cm)
Keyboard Stand Weight Capacity	Up to 88 lbs (40 kg)
Piano Bench Weight Capacity	Up to 270 lbs (122 kg)
Item Weight (Set)	24.2 pounds (10.98 kg)
Product Dimensions (Stand, collapsed)	Approx. 31.89 x 9.45 x 14.57 inches (81 x 24 x 37 cm)

SAFE AND STABLE

Provide reliable support for both you and your piano



88
LB

270
LB



Image: Visual representation of the weight capacities for the keyboard stand and bench.

WARRANTY AND SUPPORT

STRICH products are manufactured with quality and durability in mind. For specific warranty information regarding your Collapsible Piano Keyboard Stand and Bench Set, please refer to the warranty card included with your purchase or visit the official STRICH website.

If you encounter any issues, have questions about assembly, operation, or require technical assistance, please contact STRICH customer support through the retailer where the product was purchased or via the contact information provided on the official STRICH website.

Online Support: [Visit the STRICH Store on Amazon](#)

