

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [Moman](#) /

> [Moman CPX Motorcycle Group Mesh Intercom User Manual](#)

Moman CPX

Moman CPX Motorcycle Group Mesh Intercom User Manual

MODEL: CPX

Brand: Moman

1. Introduction

The Moman CPX Motorcycle Group Mesh Intercom is designed to provide seamless communication for motorcycle riders. Featuring advanced mesh technology, it supports up to 24 riders within a 2KM range. This device integrates Bluetooth 5.4 for stable connections, Quad AI Noise Cancellation for clear audio, and audio multitasking capabilities. It is built with a durable, IP65 waterproof design and a long-lasting 1000mAh battery to withstand various riding conditions.

2. Package Contents

Before installation, please verify that all components are present in your package:

- CPX Mesh Intercom Unit (x2 for 2-pack)
- Back Clip (x2)
- Changeable Microphone Speakers (x2 sets)
- Charging Cable (x2)
- User Manual (x1)
- Back Clip (Stick Style) (x2)
- Tape Kit (x2)
- Hexagon Key (x2)
- Interchangeable Shells (various colors)




Image: Detailed view of all components included in the Moman CPX Motorcycle Group Mesh Intercom package.

3. Setup and Installation

Proper installation ensures optimal performance and comfort. The Moman CPX offers flexible mounting options to suit various helmet types.

3.1 Speaker and Microphone Installation

The headset includes both boom and soft microphones for different helmet types. The boom mic is suitable for open-face helmets, while the soft mic is for full-face helmets.

1. Remove the helmet's inner padding to access the ear pockets.
2. Attach the speaker units to the inside of the helmet's ear pockets using the provided Velcro pads. Ensure they are positioned directly over your ears for best audio quality.
3. Route the speaker wires discreetly under the helmet padding to avoid discomfort.
4. Attach the chosen microphone (boom or soft) to the inside of the helmet near your mouth. Connect the microphone to the main unit's speaker cable.
5. Reinstall the helmet's inner padding, ensuring all wires are tucked away and do not interfere with comfort or safety.



Image: Illustration of dual microphone options (boom and soft) and compatibility with various helmet types.

3.2 Intercom Unit Mounting

Choose between the clip-on mount or the adhesive mount for the main intercom unit.

- **Clip-on Mount:** Slide the clip between the helmet shell and the inner padding on the left side of the helmet. Secure it firmly.
- **Adhesive Mount:** Clean the desired mounting area on the left side of the helmet. Peel off the protective film from the adhesive mount and firmly press it onto the helmet for at least 30 seconds. Allow 24 hours for the adhesive to fully cure before attaching the intercom unit.
- Slide the main CPX intercom unit onto the chosen mount until it clicks securely into place.

Your browser does not support the video tag.

Video: Detailed instructions on how to install a Bluetooth headset to a helmet, demonstrating speaker and microphone placement, and unit mounting.

4. Operating Instructions

The Moman CPX is designed for intuitive control, even with gloves on, thanks to its oversized knob and clear button layout.

4.1 Power On/Off

- **Power On:** Long press the power button (usually the main function button) for approximately 3 seconds until the indicator light flashes blue.
- **Power Off:** Long press the power button for approximately 3 seconds until the indicator light turns off.

4.2 Intercom Modes and Pairing

The CPX features two mesh intercom modes: Open Mesh and Group Mesh, supporting up to 24 riders.

- **Open Mesh Mode:** Connects up to 24 riders seamlessly. One-touch pairing for quick setup.
- **Group Mesh Mode:** Allows for 6 private groups with up to 24 riders each.
- **Pairing:** For initial pairing, ensure both devices are off. Long press the intercom button on both units until red and blue lights flash. Choose one as 'master' and click its intercom button to start searching. After 5-10 seconds, both devices will flash blue at the same rate, indicating successful pairing. Click the master's intercom button to enter intercom mode.




Image: Visual representation of Open Mesh and Group Mesh modes for 24 riders across 2KM.

Your browser does not support the video tag.

Video: Demonstrates the pairing operation for two EJEAS V6 Pro intercoms, showing how to power on, enter pairing

mode, and establish a connection.

4.3 Audio Multitasking and Adaptive Volume

The CPX supports simultaneous processing of multiple audio sources without frequent switching.

- **Simultaneous Audio:** Listen to music, navigation prompts, and intercom communication concurrently.
- **Adaptive Volume:** The 'Intercom Priority' system automatically lowers music/GPS/radio volume when intercom is active and restores it when inactive.



Image: Illustrates smart audio multitasking, allowing intercom use while listening to music, GPS, FM, or voice assistant.

4.4 Music Playback

- **Play/Pause:** Single press the main function button.
- **Volume Control:** Use the oversized knob to adjust volume up or down.
- **Track Skip:** Double tap the forward/backward buttons (if available) or use voice commands.

4.5 Phone Calls

- **Answer Call:** Short press the main function button.
- **Reject Call:** Long press the main function button for approximately 1 second.
- **End Call:** Short press the main function button during a call.
- **Voice Assistant:** Activate your phone's voice assistant (e.g., Siri, Google Assistant) via the oversized knob or a dedicated button.

Your browser does not support the video tag.

Video: Demonstrates various functions of the LEXIN B4FM Motorcycle Intercom, including power, pairing, music, and phone call controls.

4.6 FM Radio

- **Turn On/Off:** Use the oversized knob or voice command to activate/deactivate the built-in FM radio.
- **Scan Stations:** Use dedicated buttons or voice commands to scan for available FM stations.

4.7 Voice Control

The CPX supports intelligent voice operation for basic commands, including music, calls, GPS, and mesh communication.

- **Wake Word:** Say "Hi Max" to activate voice control.

- **Commands:** Use commands like "Music On", "Radio On", "Free Mode", "Phone Pairing", "Answer the Phone", "Next Track", "Previous Track", "Volume Up", "Volume Down", "Hang Up", "Group Mesh", "End Intercom".
- Offline commands are available without network connection. Online commands (e.g., weather, navigation) are available when paired with a phone connected to the internet.

Your browser does not support the video tag.

Video: Demonstrates the voice control features of the ASMAX S1 Motorcycle Helmet Bluetooth Headset, including activating voice commands for music, calls, and mesh communication.

Your browser does not support the video tag.

Video: Highlights the voice control capabilities of the MAXRUNON D10 4-Riders Helmet Bluetooth Headset, showing various commands and their functions.

5. Maintenance

To ensure the longevity and optimal performance of your Moman CPX intercom, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the unit with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the intercom in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** Fully charge the unit before extended storage. Recharge regularly even if not in use to maintain battery health.
- **Waterproof Rating:** The unit is IP65 waterproof, meaning it is protected against dust and low-pressure water jets. Avoid submerging the device in water.

6. Troubleshooting

If you encounter issues with your Moman CPX intercom, try the following solutions:

- **No Power:** Ensure the battery is charged. Connect the unit to the charging cable and allow it to charge for at least 2 hours.
- **Pairing Issues:** Ensure both units are in pairing mode (red and blue flashing lights). Try resetting both units to factory settings (refer to user manual for specific steps) and attempt pairing again.
- **Poor Audio Quality:** Check microphone and speaker connections. Ensure speakers are positioned correctly over your ears. Verify that the microphone is not obstructed and is close to your mouth.
- **Intercom Disconnection:** Ensure units are within range (2KM). Check for obstacles that might interfere with the signal. Re-establish the intercom connection.
- **Bluetooth Disconnection:** Ensure your phone's Bluetooth is enabled and the intercom is paired. Try unpairing and re-pairing the device with your phone.

7. Specifications

Model Name	Moman CPX
Brand	Moman
Connectivity Technology	Wireless (Bluetooth 5.4)
Noise Control	Adaptive Noise Cancellation (DSP, CVC, ENC)
Water Resistance Level	IP65 Waterproof
Battery Capacity	1000mAh
Battery Average Life	Up to 28 Hours
Intercom Range	Up to 2KM
Max Riders (Mesh)	24 Riders
Speaker Size	40mm High-Fidelity Speakers
Control Method	Push Button (Oversized Knob)
Special Features	AI Noise Reduction, Water Resistant, Long Battery Life, Mesh Intercom, Bluetooth 5.4, Audio Multitasking, FM Radio, Interchangeable Shells

8. Warranty and Support

Moman products are designed for durability and performance. For warranty information, technical support, or service inquiries, please refer to the contact details provided in your product packaging or visit the official Moman website. Keep your proof of purchase for warranty claims.