

[Manuals.plus](#) /

› [Bushnell](#) /

› [Bushnell Instant Pop-Up 3-Person Tent Instruction Manual](#)

Bushnell B0BLGQN1ZJ

Bushnell Instant Pop-Up 3-Person Tent Instruction Manual

Model: B0BLGQN1ZJ

[Introduction](#)

[What's Included](#)

[Setup](#)

[Features](#)

[Care & Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Safety Information](#)

[Warranty & Support](#)

1. INTRODUCTION

This manual provides instructions for the proper setup, use, and maintenance of your Bushnell Instant Pop-Up 3-Person Tent. Please read this manual thoroughly before using the tent to ensure safe and efficient operation.



Image: The Bushnell Instant Pop-Up 3-Person Tent, fully set up.

2. WHAT'S INCLUDED

Verify that all components are present before attempting to set up your tent.

- Tent
- Rainfly
- Stakes
- Carry Bag



Image: The Bushnell Instant Pop-Up Tent packed in its oversized carry bag.

3. SETUP INSTRUCTIONS

Follow these steps for quick and easy tent setup:

3.1. Prepare for Setup

Select a level site clear of rocks, branches, and other hard or sharp objects to set up your shelter. Lay the tent flat on the ground and check that there is no material twisted or overlapping the ends of any poles.




Image: The tent body laid flat on the ground, ready for initial setup.

3.2. Unfold and Open Tent

Grasp the orange webbed loop tied onto the steel ring located at the center of the wall and pull outward until the wall section pops open. Repeat on the opposite side. The tent frame poles are designed to bend outwards, giving the interior a dome-like feel.



Image: Demonstrating pulling the orange hub loops to expand the tent structure.

3.3. Install and Secure Rainfly

Fully open the rainfly, then drag it over the top of the tent. Secure the rainfly to the base of the tent corners using the buckles. The included rainfly and fully taped waterproof seams allow for all-weather camping.



INSTANT SET UP

INSTALL & SECURE RAINFLY

Fully open the rainfly, then drag it over the top of the tent. Secure the rainfly to base of tent corners using buckle.


Image: Attaching the rainfly to the tent body using the corner buckles.

Your browser does not support the video tag.

Video: A demonstration of pulling the rainfly over the tent and securing it with buckles. This video shows the process of setting up the rainfly for the Bushnell 3-Person Instant Pop-Up Tent.

3.4. Stake and Secure Tent

Move your completed tent to its final position. Secure the tent and guylines using the included stakes. For optimal stability, ensure all stake points and guylines are properly tensioned.



INSTANT SET UP

STAKE & SECURE TENT


Move your completed tent to its final position. Secure tent and guylines using the included stakes.

Image: The tent fully set up and staked down, ready for use.

4. KEY FEATURES

- **Instant Pop-Up Technology:** Allows for quick pitching in under a minute.
- **Durable Construction:** Features 210 denier fabric walls and a 300 denier floor for enhanced durability.
- **Ventilation:** Equipped with large windows, a 5050 no-see-um mesh door, and mesh wall panels to maximize airflow.
- **Maximum Interior Volume:** Frame poles bend outwards to create a spacious, dome-like interior.
- **Weather Preparedness:** Includes a rainfly and fully taped waterproof seams for protection against rain.

- **Electrical Port:** An integrated port allows for convenient power access while keeping elements out.
- **Oversized Carry Bag:** Provides ample space for easy packing and transport.



-
- **HUGE 5050 NO-SEE-UM MESH WINDOWS**
 - **WATER TIGHT UTILITY PORT**
 - **HEAVY DUTY 210D WALLS AND 300D FLOORS WITH FULLY TAPED SEAMS**

Image: Close-up views highlighting the mesh windows, electrical utility port, and waterproof fabric of the tent.

[Your browser does not support the video tag.](#)

Video: This video showcases various features of the Bushnell Instant Pop-Up Tent, including its spacious interior, ventilation, and durable materials.

5. CARE AND MAINTENANCE

- **Cleaning:** Hand wash the tent with mild soap and water. Do not use harsh detergents or bleach.
- **Drying:** Ensure the tent is completely dry before packing it away to prevent mildew and odor.
- **Storage:** Store the tent in its carry bag in a cool, dry place, away from direct sunlight and extreme temperatures.
- **Stakes:** Inspect stakes for damage before and after each use. Replace bent or broken stakes as needed.
- **Seams:** Periodically check seams for wear and tear. Re-seal seams if necessary to maintain waterproofing.

6. TROUBLESHOOTING

Issue: Water leakage during rain.

Solution: Ensure the rainfly is correctly installed and all buckles are secured. Check that all seams are properly taped and sealed. Consider applying an additional waterproofing spray if leakage persists, especially on older tents.

Issue: Condensation inside the tent.

Solution: Maximize ventilation by opening windows and mesh panels. Ensure the rainfly is not directly touching the tent body, allowing for airflow. Condensation is common in single-wall tents or tents with limited airflow in humid conditions.

Issue: Difficulty packing the tent back into the carry bag.

Solution: Fold the tent neatly and systematically. The carry bag is oversized and features zipper gussets to assist with packing. Ensure all air is expelled from the tent before attempting to zip the bag closed.

Issue: Snags or small holes in mesh screens.

Solution: Small snags can often be repaired with a mesh repair kit. For larger holes, consider professional repair or patching to prevent insect entry.

7. SPECIFICATIONS

Brand	Bushnell
Model	Instant Pop-Up 3-Person Tent
Product Dimensions (L x W x H)	84"L x 84"W x 55"H
Item Weight	14.3 Pounds
Occupancy	3 Person
Seasons	3 Season
Water Resistance Level	Waterproof (300 Inch rating for floor)
Number of Doors	1
Number of Windows	3
Fabric Type	Mesh, Polyester (210D walls, 300D floor)
Pole Material Type	Aluminum
Packed Dimensions	60 in x 8 in x 6 in



Image: Diagram showing the dimensions of the Bushnell Instant Pop-Up 3-Person Tent, including height and floor length.

8. SAFETY INFORMATION

- **Fire Safety:** Keep all flame and heat sources away from tent fabric. The tent material is not fireproof.
- **Ventilation:** Ensure adequate ventilation to prevent carbon monoxide buildup if using heating or cooking appliances inside or near the tent.
- **Weather Conditions:** Do not use the tent in extreme weather conditions beyond its 3-season rating. High winds or heavy snow can damage the tent and pose a safety risk.
- **Site Selection:** Avoid setting up the tent under trees with dead branches or in areas prone to flash floods.
- **Staking:** Always stake down your tent securely to prevent it from being blown away by wind.

9. WARRANTY AND SUPPORT

For warranty information or product support, please contact Bushnell customer service. Keep your purchase receipt as proof of purchase.

Manufacturer: I2D Licensed Brands, LLC

Visit the official Bushnell website for contact details and further assistance: www.bushnell.com



© 2024 Bushnell. All rights reserved.