Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Aiwa AWSBRK

Aiwa AWSBRK Bluetooth 2.0 CH Soundbar User Manual

Model: AWSBRK

1. Introduction

Thank you for purchasing the Aiwa AWSBRK Bluetooth 2.0 CH Soundbar. This soundbar is designed to enhance your audio experience with powerful 80W sound, versatile connectivity options including Bluetooth 5.3, HDMI ARC, Optical, USB, and Aux, all within a sleek, slim design. This manual provides essential information for setting up, operating, and maintaining your soundbar to ensure optimal performance and longevity.

2. Safety Information

Please read all safety instructions carefully before using this product. Keep this manual for future reference.

- Do not expose the soundbar to rain, moisture, or extreme temperatures.
- Ensure proper ventilation around the unit. Do not block any ventilation openings.
- Use only the power adapter supplied with the unit.
- Do not open the casing. Refer all servicing to qualified personnel.
- Keep the soundbar away from heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Clean only with a dry cloth.

3. Package Contents

Carefully unpack your soundbar and check that all the following items are included:

- Aiwa AWSBRK Soundbar
- Remote Control
- Power Adapter
- User Manual
- HDMI Cable (may vary by region)

- Optical Cable (may vary by region)



Figure 3.1: Aiwa AWSBRK Soundbar, front view. This image shows the overall design of the soundbar, which is the main component of the package.

4. Product Overview

4.1 Front and Top Panel



Figure 4.1: Direct front view of the Aiwa AWSBRK Soundbar, highlighting its slim profile and integrated LED display (when active).



Figure 4.2: Top-down angled view of the soundbar, showing the integrated control buttons on the top panel.

The top panel features intuitive buttons for power, volume control, and input selection. A discreet LED display on the front indicates the current input source and volume level.

4.2 Rear Panel Connections



Figure 4.3: Diagram illustrating the various connectivity options available on the Aiwa AWSBRK Soundbar, including Bluetooth, Aux In, Optical, and HDMI ARC.

The rear panel provides the following connection ports:

- **HDMI ARC:** For connecting to a TV with HDMI ARC support.
- **OPTICAL:** For connecting to a TV or other audio device via optical cable.
- **AUX IN:** For connecting external audio devices via a 3.5mm audio cable.
- **USB:** For playing audio files from a USB drive.
- **DC IN:** For connecting the power adapter.

4.3 Remote Control

The included remote control allows you to manage all functions of the soundbar from a distance. Key functions include:

- Power On/Off
- Volume Up/Down
- Input Source Selection (HDMI ARC, Optical, Bluetooth, USB, Aux)
- Mute
- Sound Mode Selection (e.g., Music, Movie)

5. Setup

5.1 Placement

Place the soundbar on a flat, stable surface directly in front of your TV, or mount it on the wall below your TV. Ensure there are no obstructions blocking the soundbar's speakers or the TV's remote sensor.



Figure 5.1: The soundbar placed on a media console directly beneath a television, demonstrating ideal placement.

5.2 Connecting to Your TV (HDMI ARC Recommended)

1. Connect one end of an HDMI cable to the HDMI ARC port on your soundbar.
2. Connect the other end of the HDMI cable to the HDMI ARC port on your TV.
3. Ensure your TV's HDMI ARC function is enabled in its audio settings.
4. Power on both the TV and the soundbar. Select the HDMI ARC input on the soundbar using the remote or top panel buttons.



Figure 5.2: An illustration showing the soundbar connected to a Roku TV via HDMI ARC, with on-screen instructions for simple setup.

5.3 Other Connections

- **Optical:** Connect an optical cable from your TV's optical output to the soundbar's OPTICAL input. Select OPTICAL input on the soundbar.
- **Aux In:** Connect a 3.5mm audio cable from your device's audio output to the soundbar's AUX IN port. Select AUX input on the soundbar.
- **USB:** Insert a USB drive containing audio files into the soundbar's USB port. The soundbar will automatically switch to USB mode and begin playback.

5.4 Power Connection

Connect the power adapter to the DC IN port on the soundbar, then plug the adapter into a wall outlet.

6. Operating Instructions

6.1 Power On/Off

Press the Power button on the soundbar's top panel or the remote control to turn the unit on or off.

6.2 Input Selection

Press the 'Input' button on the remote control or the 'Mode' button on the soundbar's top panel to cycle through available input sources: HDMI ARC, OPTICAL, BLUETOOTH, USB, AUX. The LED display will show the selected input.

6.3 Bluetooth Pairing

1. Switch the soundbar to Bluetooth mode. The LED display will show "BT" and flash, indicating it's in pairing mode.
2. On your mobile device, enable Bluetooth and search for available devices.

3. Select "AWSBRK" from the list. Once connected, the LED display will stop flashing and show "BT" steadily.
4. You can now play audio from your device through the soundbar.



Figure 6.1: The soundbar displaying "Bluetooth 5.3" connectivity, indicating its advanced wireless audio capabilities.

6.4 Volume Control

Use the Volume Up (+) and Volume Down (-) buttons on the soundbar or remote control to adjust the volume level.

6.5 Sound Modes

Press the 'EQ' or 'Sound Mode' button on the remote control to switch between different audio presets, such as "Music" and "Movie," to optimize the sound for your content.

7. Maintenance

7.1 Cleaning

To clean the soundbar, use a soft, dry cloth. Do not use liquid cleaners or aerosol sprays, as they may damage the

finish or internal components. Avoid using abrasive cleaners or solvents.

7.2 Storage

If you plan not to use the soundbar for an extended period, unplug it from the power outlet and store it in a cool, dry place, away from direct sunlight and extreme temperatures.

8. Troubleshooting

If you encounter issues with your soundbar, refer to the following common problems and solutions:

Problem	Possible Solution
No power	Ensure the power adapter is securely connected to the soundbar and a working power outlet.
No sound	Check if the soundbar is powered on and not muted. Verify the correct input source is selected on the soundbar. Ensure cables (HDMI, Optical, Aux) are securely connected. Adjust the volume on both the soundbar and the connected device/TV. If using HDMI ARC, ensure ARC is enabled in your TV's settings.
Bluetooth pairing issues	Ensure the soundbar is in Bluetooth pairing mode. Disable and re-enable Bluetooth on your device. Move your device closer to the soundbar. Clear the Bluetooth pairing list on your device and try pairing again.
Remote control not working	Check the battery in the remote control and replace if necessary. Ensure there are no obstructions between the remote and the soundbar. Point the remote directly at the soundbar's sensor.

9. Specifications



Figure 9.1: Visual representation of the soundbar's key dimensions and 80W power output.

Feature	Specification
Model	AWSBRK
Audio Channels	2.0 CH
Max Output Power	80 Watts
Connectivity Technology	Bluetooth 5.3, HDMI ARC, Optical, USB, Aux
Frequency Response	50 KHz
Control Method	Remote Control
Dimensions (L x D x H)	90 cm x 11.8 cm x 6.7 cm (approx.)
Material	Metal, Plastic
Color	Black
Power Input	240 Volts

10. Warranty and Support

10.1 Product Warranty

This Aiwa AWSBRK Soundbar comes with a**12-month limited warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external factors.
Please retain your proof of purchase for warranty claims.

10.2 Customer Support

For technical assistance, warranty service, or general inquiries, please visit the official Aiwa store or contact customer support through the retailer where you purchased the product.
You can find more information and support resources on theAiwa Brand Store.

© 2023 Aiwa. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0G2K85P49

More documents and user manuals: **https://manuals.plus/**