

[Manuals.plus](#) /

> [SOOPYK](#) /

> SOOPYK Water Cooler Dispenser with Ice Maker - Model LYCZ629BWT - Instruction Manual

SOOPYK LYCZ629BWT

SOOPYK Water Cooler Dispenser with Ice Maker


Model: LYCZ629BWT

INTRODUCTION

Thank you for choosing the SOOPYK Water Cooler Dispenser with Built-in Ice Maker. This appliance provides convenient access to hot, cold, and room temperature water, along with bullet-shaped ice. Designed for ease of use and maintenance, it features a bottom-loading water system, self-cleaning function, and child safety lock for hot water. Please read this manual thoroughly before operation to ensure proper use and maintenance.

Designed for Convenience

Bright LED indicator lights let you know when water is heating and chilling, ice is making and bottle is empty



Secure 2-step hot water dispensing



Image: Front view of the SOOPYK Water Cooler Dispenser, showcasing its sleek design and dispensing area.

SAFETY INFORMATION

- Always ensure the appliance is placed on a flat, stable surface.
- Do not operate the appliance with a damaged cord or plug.
- Keep the appliance away from direct sunlight and heat sources.
- Ensure proper ventilation around the unit.
- Unplug the unit before cleaning or performing any maintenance.
- The hot water dispenser is equipped with a child safety lock. Always engage this feature when not in use, especially in households with children.
- Do not immerse the appliance in water or other liquids.

PRODUCT OVERVIEW

The SOOPYK Water Cooler Dispenser features an intuitive control panel and a convenient bottom-loading design. Familiarize yourself with the components for optimal operation.

7 Mins
Fast Ice-making

9 PCS
Ice per cycle

22 Lbs
Daily capacity

Make Ice In 7 Mins
NOT KEEP ICE FROZEN

Image: Close-up of the control panel with icons for ice making, child lock, low water, hot water, fresh water, cold water, and power.

Key Components:

- **Control Panel:** Touch-sensitive buttons for various functions and indicator lights.
- **Ice Dispenser:** Located on the left side for bullet-shaped ice.
- **Water Spigots:** For hot, cold, and room temperature water.
- **Drip Tray:** Removable for easy cleaning.
- **Bottom-Loading Compartment:** Houses the 3 or 5-gallon water bottle.
- **Power Switches:** Two switches on the rear panel for hot and cold water functions.

SETUP

1. Unpacking and Placement:

Carefully remove the dispenser from its packaging. Place the unit on a level, sturdy surface, ensuring there is adequate space (at least 4 inches) from walls for proper ventilation. Avoid placing it near direct sunlight or heat sources.

2. Water Bottle Installation (Bottom Loading):

This dispenser features a convenient bottom-loading design, eliminating heavy lifting and spills.

1. Open the lower cabinet door of the dispenser.
2. Remove the cap from a standard 3 or 5-gallon water bottle.
3. Insert the probe from the dispenser into the opening of the water bottle. Ensure it is securely seated.
4. Slide the water bottle into the cabinet and close the door.



Image: The bottom-loading compartment with a 5-gallon water bottle inserted and the water probe connected.

3. Initial Startup:

After installing the water bottle, plug the dispenser into a grounded electrical outlet. Allow the unit to sit for at least 30 minutes before turning on the heating and cooling functions to allow the water to fill the internal tanks. Turn on the two switches on the rear panel for hot and cold water. The indicator lights on the control panel will illuminate as the unit begins to heat and cool the water.

Your browser does not support the video tag.

Video: A short clip demonstrating the factory testing process of the water cooler dispenser, ensuring quality before shipment.

1. Dispensing Water:

The dispenser offers hot, cold, and room temperature water options.

1. Place your cup under the desired water spigot.
2. Press the corresponding button on the control panel for Hot Water (red icon), Fresh Water (blue droplet icon for room temperature), or Cold Water (blue snowflake icon).
3. The water will dispense for up to 60 seconds or until you press the button again to stop.

2. Ice Making Function:

The built-in ice maker produces bullet-shaped ice.

- To activate ice making, ensure the ice-making button is illuminated.
- The unit can produce up to 22 lbs of ice daily and stores up to 0.88 lbs.
- When the ice bin is full, the machine will emit three beeps.
- Note: The ice storage is not designed to keep ice frozen for extended periods.



UV-Infused Cleaning

 Echnology

- Reduce harmful contaminants in water and tanks.
- Improves taste of water.
- Minimizes maintenance.

Image: Visual representation of the ice making process, highlighting 7 minutes for fast ice making, 9 pieces per cycle, and 22 lbs daily capacity.

3. Child Safety Lock:

To prevent accidental hot water dispensing, a child safety lock is integrated.

- To dispense hot water, first press the Child Lock button (lock icon), then press the Hot Water button.

4. ECO Mode:

Activate ECO mode to conserve energy by stopping water heating at night.

- Press the energy saving button (ECO icon) to turn on ECO mode.
- Press and hold the ECO button for 3 seconds to turn it off.

5. Empty Bottle Alert:

The empty bottle indicator light will illuminate when the water bottle needs to be replaced.

6. Nightlight Feature:

The nightlight feature illuminates the water spouts, making them visible in low-light conditions. It activates automatically when dispensing water or ice.



Image: The SOOPYK water cooler dispenser in a dimly lit room, with the dispensing area illuminated by a blue nightlight.

1. Self-Cleaning Function:

The dispenser includes a self-cleaning function to maintain hygiene.

1. To activate, press and hold the ice-making button for 3 seconds.
2. The self-cleaning cycle will run for 10 minutes and then shut off automatically.
3. During this cycle, the ice indicator will blink, and the power light will remain on.
4. A UV lamp is located in the cold water tank and operates continuously when the machine is plugged in, contributing to water purification.

BOTTOM LOADING DISPENSER



Self Cleaning

Press and hold the ice button for 3 seconds to activate self cleaning function. It will shut off automatically after 10 mins

Image: Diagram illustrating the UV-infused cleaning process within the water cooler, showing how UV technology reduces contaminants.




Image: An internal view of the water cooler, highlighting the UV lamp located within the cold water tank.

2. Drip Tray Cleaning:

Regularly empty and clean the drip tray to prevent overflow and maintain hygiene.

- Remove the drip tray from the dispensing area.
- Empty any collected water and wash the tray with mild soap and water.
- Rinse thoroughly and dry before reinserting.

3. Exterior Cleaning:

Wipe the exterior of the dispenser with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No water dispensing	Water bottle empty or not properly installed.	Check the empty bottle alert. Replace or re-install the water bottle.
No hot/cold water	Hot/cold switches on the rear panel are off.	Ensure both hot and cold water switches on the back of the unit are in the 'ON' position.
Ice maker not producing ice	Water level too low or ice maker function is off.	Ensure water bottle is full and the ice-making button is activated.

Problem	Possible Cause	Solution
Water has an unusual taste	First use or internal tanks need cleaning.	Run the self-cleaning cycle. Dispense and discard a few cups of water during initial use.

SPECIFICATIONS

Feature	Detail
Model Number	LYCZ629BWT
Brand	SOOPYK
Color	White
Material	Stainless Steel
Product Dimensions (D x W x H)	16.5" x 12.2" x 40.7"
Installation Type	Freestanding
Power Source	Corded Electric
Water Temperatures	Hot, Cold, Room Temperature
Ice Making Capacity	Up to 22 lbs daily
Ice Storage Capacity	0.88 lbs
Compatible Water Bottle Sizes	3 and 5-gallon

WATER DISPENSER WITH ICE MAKER

Fits standard 3-5 gallon bottles



Image: The SOOPYK water cooler dispenser with key dimensions (depth, width, height) indicated.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or contact SOOPYK customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.