

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [FAMAPY](#) /

› FAMAPY Large Entertainment Center with Light, TV Media Center, Type B White - Instruction Manual

FAMAPY Type B

FAMAPY Large Entertainment Center with Light, TV Media Center - Type B White

Instruction Manual

1. INTRODUCTION

Thank you for purchasing the FAMAPY Large Entertainment Center with Light, Type B White. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and proper use of your new furniture. Please read this manual thoroughly before beginning assembly and retain it for future reference.

2. SAFETY INFORMATION

- Always follow assembly instructions carefully. Incorrect assembly can lead to instability and injury.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- Do not overload shelves or cabinets. Refer to specifications for weight limits.
- Use the included anti-tip device to secure the entertainment center to a wall. This prevents accidental tipping, especially important in homes with children or pets.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Disconnect power to the light strips before cleaning or performing any maintenance.

3. PACKAGE CONTENTS

Your FAMAPY Large Entertainment Center will arrive in two separate boxes. Please ensure both boxes have been received before beginning assembly. Carefully unpack all components and verify that all parts are present and undamaged against the provided parts list in your assembly guide.

Note: The two boxes may not arrive simultaneously. Please wait patiently for both packages.

4. SETUP AND ASSEMBLY

Assembly is required for this product. It is recommended to have at least two people for assembly. Please follow the detailed manual included in your package for step-by-step instructions. Ensure you have adequate

space and the necessary tools (typically a screwdriver and hammer) before starting.

Key Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components on a soft, clean surface to prevent scratches. Match each part to the labeled diagrams in your manual.
2. **Assemble Base Units:** Begin by constructing the lower cabinet sections, ensuring all cam locks and screws are securely fastened.
3. **Install Vertical Supports:** Attach the side shelving units to the base.
4. **Mount Top Cabinets and Bridge:** Carefully lift and secure the top cabinets and the central bridge section. The top cabinets feature small hydraulic rods for smooth door operation; install these according to the manual.
5. **Install Doors and Shelves:** Attach all cabinet doors and insert adjustable shelves into their desired positions.
6. **Connect Lighting:** Install the light strips in the designated areas within the side cabinets. Follow the wiring instructions carefully.
7. **Secure Anti-Tip Device:** Attach the anti-tip device to the back of the entertainment center and to a wall stud using appropriate hardware.

For visual guidance on the overall dimensions and structure, please refer to the image below:




Image: Detailed dimensions of the entertainment center, including overall width (114.2"), height (78.7"), depth (11.8"), and specific measurements for TV opening and shelf compartments.

For a comprehensive assembly guide, please refer to the official video:

Your browser does not support the video tag.

Video: An official assembly guide for the FAMAPY Large Entertainment Center, demonstrating step-by-step construction. (Duration: 16:37)

5. OPERATING INSTRUCTIONS

5.1 Light Strips

The two side cabinets feature integrated light strips. These lights are typically controlled by a switch or remote (if included). Connect the power adapter for the light strips to a standard electrical outlet. Use the switch to turn the lights on or off, providing ambient white lighting for your display items.

5.2 Hydraulic Rod Doors

The top cabinets are equipped with small hydraulic rods to assist in opening and closing the doors smoothly. To open, gently pull the door downwards. The hydraulic rod will assist in a controlled opening. To close, gently push the door upwards until it latches securely.

An example of the product in use, showcasing the lighting and storage:



Image: The FAMAPY entertainment center fully assembled and decorated, showing the central TV area, side shelves with lighting, and closed cabinets.

6. MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as needed to maintain stability.
- **Light Strips:** If a light strip malfunctions, ensure the power connection is secure. If issues persist, contact customer support. Do not attempt to repair electrical components yourself.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Unit is wobbly or unstable	Loose hardware; uneven floor	Check and tighten all screws and fasteners. Ensure the unit is on a level surface; use shims if necessary. Verify anti-tip device is properly installed.
Light strips not working	Power not connected; faulty switch/strip	Ensure the power adapter is securely plugged into an outlet and the light strip. Check the switch. If still not working, contact customer support.
Cabinet doors do not close smoothly	Misaligned hinges; hydraulic rod issue	Adjust hinges as per assembly manual. Ensure hydraulic rods are correctly installed and not obstructed.
Missing or damaged parts	Shipping damage; packaging error	Do not proceed with assembly. Contact FAMAPY customer support immediately for replacement parts.

8. SPECIFICATIONS

- **Brand:** FAMAPY
- **Model:** Type B
- **Color:** White
- **Product Dimensions (Overall):** 114.2"W x 11.8"D x 78.7"H
- **Material:** Engineered Wood
- **Special Feature:** Integrated Lighting
- **Mounting Type:** Floor Mount (with anti-tip device for wall securing)
- **Room Type:** Living Room
- **Number of Shelves:** 3 (per side unit, plus central shelves)
- **Assembly Required:** Yes
- **Included Components:** Shelves, hardware, light strips, anti-tip device

9. WARRANTY AND SUPPORT

FAMAPY products are designed for quality and durability. For specific warranty information, please refer to the documentation included with your purchase or visit the official FAMAPY website. If you encounter any issues, require replacement parts, or have questions regarding assembly or operation, please contact FAMAPY customer support. Have your product model number (Type B) and purchase details ready when contacting support.

Contact Information: Please refer to your purchase receipt or the FAMAPY official website for the most current customer service contact details.

